


E *EVINRUDE* **NORSEMAN**




PARTS CATALOG

**MODEL
E1522**

25 CENTS PER COPY

HOOD & WINDSHIELD GROUP MODEL E1522




17243

REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
1	290545	HOOD ASSY., Complete	1	11	261975	. BRACKET, Hood clamp	2
2	261976	. RIVET, Bracket to latch	4	12	261740	. HEADLAMP	1
3	404838	. RIVET, Clamp hood bracket	6	13	261985	CLIP, Windshield	2
4	815782	. LATCH, Hood	2	14	403959	RAWL NUT, Windshield mtg.	5
5	405679	. GROMMET	1	15	308279	WASHER, Windshield mtg.	5
6	306531	. NUT, Clamp to hood	1	16	290576	CABLE ASSY., Headlamp	1
7	303952	. WASHER, Clamp to hood	1	17	314053	SCREW, Windshield	5
8	302104	. SCREW, Clamp to hood	1	18	290567	WINDSHIELD ASSY.	1
9	310441	. CLAMP, Harness to hood	1	19	261829	. TRIM, Windshield, outside	1
10	260389	. RIM, Headlamp	1	*	290683	DECAL SET	1

*Not shown

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
SPECIFY MODEL AND SERIAL NUMBER OF VEHICLE WHEN ORDERING PARTS

**MISCELLANEOUS GROUP
MODEL E1522**




17249

REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
1	404012	SCREW, Deflector	5	17	404954	. RUB BLOCK	1
2	303916	LOCKWASHER, Deflector	5	18	404955	. TEE NUT	2
3	800210	SPEEDNUT, Deflector	5	19	130934	SCREW, Rub block to main frame	4
4	112883	DEFLECTOR, Snow	1	20	309563	SCREW, Seat to frame, rear	2
5	405017	PAD, Gas tank	1	21	306407	WASHER, Seat brkt. to frame	2
6	261843	PLUG, Side	2	22	306396	LOCKWASHER, Seat to frame	2
7	405395	ANGLE, Reinforcing	1	23	306375	NUT, Muffler	8
8	113953	BRACKET, Muffler	2	24	306375	NUT, Seat bracket to frame	2
9	314957	WASHER, Bracket	8	25	260323	PLATE, Seat mount	2
10	306487	SCREW, Bracket	4	26	306991	LOCKWASHER, Taillight mtg.	2
11	260070	WASHER, Seat to frame, rear	2	27	306396	LOCKWASHER, Muffler	8
12	261811	BRACKET	1	28	290579	HOUSING, Taillight	1
13	290582	SEAT ASSY.	1	29	260143	BULB, Taillight	1
14	307163	SCREW, Seat bracket to seat	4	30	133079	NUT, Taillight mounting	2
15	162019	MUFFLER ASSY.	1	31	200622	SCREW, Short, taillight mtg.	2
16	487591	RUB BLOCK ASSY.	2	32	260142	LENS, Taillight	1

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY

ORDER ALL PARTS FROM YOUR LOCAL AUTHORIZED DEALER

FRAME & STEERING GROUP MODEL E1522



INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
SPECIFY MODEL AND SERIAL NUMBER OF VEHICLE WHEN ORDERING PARTS


FRAME & STEERING GROUP **MODEL E1522**

REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
1	290701	FRAME ASSY.	1	26	487713	CABLE ASSY., Throttle	1
2	405355	SCREW, Steering arm to ski column	2	27	404130	CLAMP, Brake cable	1
3	403864	LOCKNUT	2	28	311474	SCREW, Saddle to column	2
4	404863	SPRING, Steering arm to ski column	2	29	403864	NUT, Saddle to column	2
5	404839	SPRING, Tie rod	4	30	306388	NUT, Adj. R.H. thread	2
6	306405	WASHER	4	31	103515	FITTING, Grease	2
7	290561	SKI COLUMN ASSY., R.H.	1	32	552499	WASHER, Fitting	2
7	290562	SKI COLUMN ASSY., L.H.	1	33	404837	NUT, Adj. L.H. thread	2
8	403855	BUSHING, Ski saddle	2	34	120196	WASHER	4
9	405349	ARM, Steering	2	35	306956	COTTER PIN	4
10	302103	NUT, Throttle cable to man.	1	36	404261	WEAR PLATE, Spring	2
11	487724	STEERING COLUMN ASSY.	1	37	404262	PIN, Retaining, spring, rear ...	2
12	132520	NUT, Brake lever	2	38	404263	PIN, Retaining, spring, front. ...	2
13	314688	SCREW, Brake lever	2	39	487598	RUNNER ASSY.	2
14	403826	GRIP, Handle	2	40	290597	SKI ASSY.	2
15	403944	LEVER, Hand brake	1	41	800290	NUT	4
16	261306	LOCK, Brake lever	1	42	405733	TIE ROD END, L.H. thread	2
17	403973	LEVER, Throttle	1	43	112615	NUT, Ski spring	4
18	403975	RIVET	1	44	312855	SCREW, Ski spring	4
19	404060	CAP, Brake lever	1	45	404270	LEAF, Center	2
20	487571	BUSHING ASSY., Lower	1	46	404271	LEAF, Top	2
21	487409	SCREW & NUT	1	47	403859	PLATE	2
22	133175	NUT, Brake cable	2	48	405734	TIE ROD END, R.H. thread	2
23	403945	FITTING, Brake cable	1	49	112550	LEAF, Main	2
24	112230	SPRING, Brake return	1	50	487555	SADDLE & NUT ASSY.	2
25	113551	CABLE ASSY., Brake	1	51	405737	ROD, Column to arm	2
				52	306956	COTTER PIN	4

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY

ORDER ALL PARTS FROM YOUR LOCAL AUTHORIZED DEALER

POWER TRANSMISSION GROUP MODEL E1522



17246

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
SPECIFY MODEL AND SERIAL NUMBER OF VEHICLE WHEN ORDERING PARTS


**POWER TRANSMISSION GROUP
MODEL E1522**

REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
*	162013	PRIMARY SHEAVE ASSY.	1	39	302471	WASHER, Stud, chain case	2
1	306860	. SCREW, Lockplate	2	40	405122	SCREW, Eccentric adj.	1
2	306396	. LOCKWASHER, Lockplate ...	2	41	121025	WASHER, Eccentric screw	1
3	112282	. DISC, Primary	1	42	103519	FITTING, Lubrication	1
4	405305	. SPRING, Activating	1	43	404941	SEAL, Eccentric	1
5	405742	. LOCKPLATE	1	44	487634	CONE & CUP ASSY.	2
6	113937	. BOLT, Cap to shaft	1	45	551041	KEY	1
7	487901	. END CAP & PULLEY ASSY. .	1	46	404831	ECCENTRIC, Secondary drive..	1
8	162015	. SHEAVE, Sliding	1	47	404914	O-RING, Eccentric	1
9	111441	. SPRING	1	48	404916	SPROCKET, Drive, 13 tooth ...	1
10	112278	. CUP, Spring	1	49	405386	CASTLE NUT, Secondary shaft .	1
11	111439	. BEARING, Drive belt	1	50	120219	COTTER PIN, Nut, sec. shaft ..	1
12	162014	. SHAFT & SHEAVE, Main ...	1	*	487615	CALIPER BRAKE ASSY.	1
13	487727	CHAIN CASE ASSY.	1	51	112424	. PIN, Caliper brake	2
14	405015	. STUD	2	52	112425	. SPRING, Brake cam	1
15	405397	. RIVET	5	53	112428	. NUT, Cam to body	1
16	487701	. CUP & PLATE, Bearing	1	54	112482	. PIN, Cam	1
17	404876	NUT, Wing, cover to case	2	55	113481	. PIN, Cotter, cam to body	1
18	306992	LOCKWASHER, Chain case cover	2	56	113482	. SPACER, Caliper brake brkt..	4
19	405016	WASHER, Chain case cover ...	2	57	113486	. WASHER, Thrust	1
20	404928	COVER, Chain case	1	58	113487	. LOCK NUT	2
21	405347	PLUG, Cover plate	2	59	405187	. CAM, Caliper brake	1
22	404931	SEAL, Chain case cover	1	60	487674	. BRACKET, Caliper brake ...	1
23	405182	BELT, Drive	1	61	261166	. WASHER, Puck back-up	1
24	309512	SCREW, Brake mounting	2	62	405188	. PUCK, Caliper brake	1
25	306416	SCREW, Case to frame	4	63	405189	. PUCK, Caliper brake	1
26	306325	LOCKWASHER, Brake mtg. ...	2	64	261169	. BODY, Cam side	1
27	120196	WASHER, Chain case to frame .	8	65	405186	. BODY, Carrier side	1
28	306932	NUT, Chain case to main frame.	4	66	315148	. SCREW, Hex head cap	2
29	306378	NUT, Eccentric screw	1	67	405190	. BUSHING, Step	1
30	405385	WASHER, Sprocket	1	68	405191	. SCREW, Fillister head	1
31	162026	FACE & SHAFT, Fixed	1	69	405192	. NUT, Elastic stop	1
32	161587	FACE, Movable	1	70	306283	WASHER, Brake brkt. screw...	4
33	113934	SPACER, Shaft	1	71	405178	BRACKET, Mounting	1
34	121025	WASHER, Support stud	1	72	306416	SCREW, Brake bracket	2
35	112912	SPRING	1	73	306325	LOCKWASHER, Brake bracket .	2
36	112749	CAP, Spring	1	74	306932	NUT, Bracket	2
37	112143	SHOE, Ramp	3	75	404969	STUD, Support, chain case	1
38	308805	RING, Retaining	1	76	306378	NUT, Chain case support stud ..	4

*Not shown

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
ORDER ALL PARTS FROM YOUR LOCAL AUTHORIZED DEALER

TRACK GROUP MODEL E1522



17247

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
SPECIFY MODEL AND SERIAL NUMBER OF VEHICLE WHEN ORDERING PARTS


TRACK GROUP **MODEL E1522**

REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
*	290574	AXLE & SPROCKET ASSY., Frt. .	1	31	404832	BEARING, Axle	2
1	160888	. SPROCKET ASSY.	2	32	261824	AXLE, Pivot, front	1
2	312298	. PIN, Roll	2	33	260011	ARM, Pivot	10
3	404844	. PLUG	1	34	260018	BUSHING, Long	6
4	261914	. AXLE	1	35	261821	SPACER, Pivot, front axle	2
*	487698	AXLE & SPROCKET ASSY., Rear.	1	36	260010	BUSHING, Short	4
5	307030	. SCREW, Rear axle, pivot . . .	2	37	260008	SPACER, Axle, outer	4
6	112610	. SCREW, Set	2	38	260027	NUT, Truck axle	10
7	487641	. SPROCKET ASSY.	2	39	261817	SPACER, Front axle, outer . . .	4
8	405147	. AXLE, Rear	1	40	290591	WHEEL ASSY	6
9	405153	. RETAINER, Bearing	2	41	260007	AXLE, Pivot, main	2
10	405351	. RING, Retaining	2	42	261818	AXLE, Main truck, rear	2
11	404832	. BEARING, Axle	2	43	261815	AXLE, Main truck, front	2
12	404864	. BRACKET, Track adj., L.H. .	1	44	306419	SCREW, Brg. plate to frame . . .	3
12	404865	. BRACKET, Track adj., R.H. .	1	45	306396	LOCKWASHER, Brg. plt. to frame	3
13	404852	. BUSHING, Rear axle pivot arm	2	46	487702	BRG. CUP PLATE ASSY., R.H.	1
14	487643	. ARM, Pivot, L.H.	1	47	404833	SEAL, Axle, front	2
14	487642	. ARM, Pivot, R.H.	1	48	113936	SPROCKET, Driven, 33 teeth . .	1
15	404958	. NUT, Rear axle pivot	2	49	405412	CHAIN, 89 pitch	1
16	307561	. PLATE, Swivel	2	50	261816	SPACER, Front axle, center . . .	2
17	405469	. SPRING, Rear axle, R.H. . . .	1	51	261820	SPACER, Front truck, outer . . .	2
17	405470	. SPRING, Rear axle, L.H. . . .	1	52	261825	AXLE, Truck, front	1
18	261819	SPACER, Main axle, rear	4	53	261851	SPACER, Truck axle, front . . .	1
19	306375	NUT, Bearing plate to frame . .	3	54	261823	SPRING, Pivot axle, L.H.	1
20	306394	COTTER PIN, Front axle	1	54	261822	SPRING, Pivot axle, R.H.	1
21	261813	SPRING, Main truck, R.H.	2	55	404892	WASHER, Track adjusting brkt. .	4
21	261814	SPRING, Main truck, L.H.	2	56	405032	WASHER, Driven chain sprkt. . .	2
22	261812	SPACER, Pivot axle, main	4	57	306834	SCREW, Truck to frame	6
23	290580	WHEEL ASSY., Main track	2	58	120177	LOCKWASHER, Truck to frame .	6
24	120196	WASHER, Track adj. bracket . .	4	59	290598	TRACK ASSY.	1
25	306862	SCREW, Bracket to frame	2	60	403865	. RIVET, Long	40
26	113620	ANCHOR, Track adjusting	2	61	403782	. RIVET, Short	266
27	306325	LOCKWASHER, Brkt. to frame . .	4	62	260242	. BAR, Tread, joint	4
28	306320	NUT, Bracket to frame	4	63	112225	. BAR, Tread	44
29	112945	SCREW, Track adjusting	2	64	112226	. BAR, Tread, outer	16
30	306390	NUT, Adjusting screw	2				

*Not shown

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
ORDER ALL PARTS FROM YOUR LOCAL AUTHORIZED DEALER

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
SPECIFY MODEL AND SERIAL NUMBER OF VEHICLE WHEN ORDERING PARTS



17248

**FUEL TANK & SUPPORT GROUP
MODEL E1522**

REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
1	261842	BUCKLE, Strap	2	25	306407	WASHER, Belt guard	3
2	120196	WASHER, Strg. support to frame .	2	26	290596	GASOLINE TANK ASSY.	1
3	261832	HOOK, Fuel tank	2	27	262081	. CLAMP, Hose to adapter	1
4	405214	SUPPORT, Ignition coil	1	28	262024	. HOSE, Fuel pickup	1
5	405252	SPEED NUT, Bolt	1	29	471121	. PICKUP HEAD ASSY.	1
6	405253	BOLT, Carriage, ignition coil . .	1	30	487891	. ADAPTOR, Tank	1
7	290563	SUPPORT, Steering column	1	31	405290	PLATE, Connector	1
8	262022	HOSE, Fuel tank to pump	1	32	405644	NUT, Wing, belt guard	3
9	261841	PANEL	1	33	290577	HARNESS, Wire, engine	1
10	290575	SWITCH & KEY, Ignition	1	34	112931	COIL, Ignition	2
11	*	. KEY	1	35	112940	CLAMP, Ignition coil	1
12	262081	CLAMP, Hose, tank	1	36	112987	WIRE JUMPER, Ignition coil . .	1
13	290487	GAS CAP ASSY.	1	37	306325	LOCKWASHER, Coil mount ing .	1
14	261831	STRAP, Tank hold down	2	38	310445	RETAINER, H.T. lead	1
15	309041	CLAMP	2	39	405289	BOLT, Main frame to eng. fr. . .	4
16	306932	NUT, Coil mounting	1	40	306405	WASHER, Belt guard	1
17	132520	NUT, Coil	4	41	120177	LOCKWASHER, Belt guard	1
18	262081	CLAMP, Hose, pump	1	42	262147	WING SCREW, Belt guard	1
19	303916	LOCKWASHER, Plate	2	43	260407	SCREW, Panel to support	3
20	161677	LEAD ASSY., H.T., long	1	44	310439	CLAMP, Fuel lines to support . .	2
21	260407	SCREW, Plate and clamp	5	45	306487	SCREW, Strg. support to frame .	2
22	306561	WASHER	3	46	303916	LOCKWASHER, Instr. panel . . .	3
23	161676	LEAD ASSY., H.T., short	1	47	405176	NUT, Strg. support to frame . . .	2
24	290688	BELT GUARD ASSY.	1				


*For each replacement key, send vehicle model number and \$.50 to:

Stevens Experimental
2015 Grand Ave.
Waukegan, Ill. 60085

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY

ORDER ALL PARTS FROM YOUR LOCAL AUTHORIZED DEALER

CYLINDER & CRANKSHAFT GROUP MODEL E1522



17250

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
SPECIFY MODEL AND SERIAL NUMBER OF VEHICLE WHEN ORDERING PARTS

CYLINDER & CRANKSHAFT GROUP
MODEL E1522


REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
1	113842	SPARK PLUG, Champion J 7 J .	2	15	378251	NEEDLE BRG. ASSY., Wrist pin	2
2	162011	CYLINDER & STUD	2	16	378275	CONNECTING ROD ASSY.	2
3	113530	. STUD	4	17	308186	. SCREW, Connecting rod	2
4	113531	. STUD, Exhaust manifold	2	18	378528	RETAINER ASSY., Rod bearing .	2
5	120177	LOCKWASHER, Cylinder	8	19	378515	BEARING ASSY., Conn. rod . . .	2
6	113545	GASKET, Cylinder	2	20	113517	SEAL, Crankshaft	2
7	113501	GASKET, Exhaust manifold	2	21	161785	CRANKSHAFT, Bearing & shim.	1
8	162023	MANIFOLD, Exhaust, front	1	22	111413	. BEARING, Crankshaft	2
9	162024	MANIFOLD, Exhaust, rear	1	23	112494	KEY, Cam and flywheel	1
10	306319	NUT, Cylinder	8	24	306422	NUT, Manifold	4
11	162007	RING SET, Piston	2	25	306325	LOCKWASHER, Manifold	4
12	162008	PISTON & PIN ASSY.	2	26	113925	CLAMP, Exhaust pipe	2
13	113930	WRIST PIN	2	*	162080	ENGINE GASKET SET	1
14	302577	RETAINING RING, pin	4				

*Not shown

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY

ORDER ALL PARTS FROM YOUR LOCAL AUTHORIZED DEALER

CARBURETOR ASSEMBLY GROUP MODEL E1522



17252

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
SPECIFY MODEL AND SERIAL NUMBER OF VEHICLE WHEN ORDERING PARTS

CARBURETOR ASSEMBLY GROUP MODEL E1522


REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
*	384938	CARBURETOR ASSY.	1	†36	113946	GASKET, Air cleaner	1
1	384939	. BODY ASSY.	1	37	262081	CLAMP, Hose, fuel pump to carb .	1
2	304201	. . LEAD SHOT	1	38	303049	COTTER PIN	1
3	317056	. . VALVE, Throttle	1	39	262023	HOSE, Pump to carburetor	1
†4	307542	. . PLUG, Core	2	40	551953	WASHER, Pin	1
†5	306442	. . PLUG, Core	1	41	262081	CLAMP, Hose, fuel pump to carb .	1
6	313379	. . NIPPLE, Fuel	1	42	306862	SCREW, Carburetor mounting ..	2
7	312852	. . SCREW, Valves	4	43	317365	SCREW, Fuel pump mounting ...	2
8	317048	. . SPRING, Throttle return ..	1	44	113544	GASKET, Intake manifold	1
9	317055	. . VALVE, Choke	1	45	113821	PIVOT PIN, Lever	1
10	307901	. . ROLL PIN	1	46	306418	SCREW, Intake manifold	6
11	384936	. . SHAFT, Choke	1	47	306396	LOCKWASHER, Intake manifold .	6
12	384937	. . SHAFT, Throttle	1	48	306799	LOCKWASHER, Carb. to manifold	2
13	317050	. . BRACKET	1	49	303615	GASKET, Fuel pump	1
14	307019	. . SCREW, Bracket	2	50	113948	SCREW, Air horn mounting ...	3
15	307596	. . WASHER, Throttle shaft. ...	1	51	113947	WASHER, Air horn screw	3
16	308780	. . BUSHING	1	52	113940	MANIFOLD, Intake	1
17	309781	. . PLUG	1	53	113949	HOUSING, Air cleaner	1
18	309449	. . PIN, Detent	1	†54	314477	GASKET, Carb. to manifold ...	1
19	303236	. . SPRING, Pin	1	55	306390	NUT, Carburetor mounting	2
†20	316332	. GASKET, Nozzle	1	56	405331	CAP, Retaining, filter	1
21	384941	. NEEDLE VALVE & PIN	1	57	405329	FILTER, Air horn	1
†22	316331	. GASKET, Float bowl	1	58	405328	SCREEN, Back up, filter	2
23	317057	. SPRING, Needle	1	59	382354	FUEL PUMP & FILTER ASSY. .	1
24	309462	. SCREW, Idle adjustment	1	60	312678	. GASKET	1
25	307175	. SCREW, Float bowl	4	61	312675	. SCREEN	1
†26	317059	. PACKING	1	62	312679	. CAP	1
†27	378895	. FLOAT VALVE & SEAT ASSY. .	1	63	310302	. SCREW	4
28	301996	. . WASHER, Float valve	1	64	312677	. SCREW	1
29	309473	. SPRING, Screw	1	*	161815	LEAF PLATE & BASE ASSY. ...	1
30	317051	. VALVE, Needle, slow speed. .	1	65	161814	. LEAF PLATE ASSY.	2
†31	382363	. FLOAT ASSY.	1	66	307129	. . SCREW, Leaf stop	8
†32	302661	. PIN, Float hinge	1	67	113542	. GASKET, Leaf plate to base .	1
33	384940	. FLOAT CHAMBER ASSY.	1	68	113543	. BASE, Leaf plate	1
34	309781	. . PLUG, Fuel passage	1	69	307609	. SCREW, Base to leaf plate ..	4
35	307553	. PACKING NUT	1	70	303916	LOCKWASHER, Pump mtg.	2

†Contents of Carburetor Repair Kit Part No. 385160

*Not shown

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
ORDER ALL PARTS FROM YOUR LOCAL AUTHORIZED DEALER

ARMATURE GROUP MODEL E1522




17253

REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
*	161997	ARMATURE PLATE ASSY. . . .	1	18	510204	. . CLIP, Spring	1
1	161798	. PLATE, Armature	1	19	307594	. . RETAINER	1
2	113824	. CLAMP, Armature plate wires	1	20	302812	. SCREW, Breaker mounting . .	1
3	113784	. WIRE, Armature to ground . .	1	21	510194	. SCREW, Condenser lead	1
4	510391	. WASHER, Bow, eccentricscrew	1	22	510185	. SCREW, Eccentric	1
5	510803	. TUBING, Coil	1	23	510644	CAM.	1
6	510684	. HOUSING	1	24	161908	FLYWHEEL & WEIGHT ASSY. .	1
7	111510	. GROMMET	1	25	113762	. WEIGHT, Timer	1
8	310572	. HOUSING, Coil leads	1	26	307193	. SCREW	2
9	113763	. WIRE, Points to conn.	1	27	425114	. RING, Retaining.	1
10	161925	. COIL ASSY., Lighting	1	28	510646	. SPRING, Flywheel	1
11	580749	. COIL ASSY., Ignition	1	29	510649	. CAM, Retainer	1
12	510397	. SCREW, Coil mounting	6	30	510650	. SUPPORT, Flywheel.	1
13	580573	. CONDENSER	1	31	304104	NUT, Flywheel	1
14	307019	. SCREW, Condenser mounting .	2	32	310856	LOCKWASHER, Flywheel	1
15	510480	. CLIP, Oiler	1	33	308742	SCREW, Armature plate	2
16	112699	. WICK, Oiler	1	34	306396	LOCKWASHER, Armature plate .	2
17	580148	. POINT SET, Breaker	1				

*Not shown

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY
SPECIFY MODEL AND SERIAL NUMBER OF VEHICLE WHEN ORDERING PARTS

REWIND STARTER GROUP MODEL E1522



17254

REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.	REF. NO.	PART NO.	NAME OF PART	QTY. PER ASSY.
†	487896	REWIND STARTER ASSY.	1	13	304325	ANCHOR	1
1	306422	NUT, 5/16-24, pulley to hsg. .	1	14	427370	HANDLE	1
2	306325	LOCKWASHER, 5/16	1	15	*	ROPE, Starter	1
3	306283	WASHER	1	16	161969	STR. HOUSING & PIN ASSY. .	1
4	379067	SPINDLE & PIN ASSY.	1	17	133128	SCREW, 5/16-24 x 1-1/4 ...	1
5	309515	WASHER, Spring	1	18	113783	SPACER, Rewind starter...	1
6	309516	RING, Friction	1	19	405689	GUARD, Housing	1
7	309513	BUSHING, Spindle	1	20	306409	SCREW, Housing mounting ...	3
8	307163	SCREW, 10-24 x 5/8, retainer to pulley	3	21	306325	LOCKWASHER, 5/16	3
9	202317	RETAINER	3	22	306435	SCREW, 5/16-18 x 1-1/4	3
10	202470	PAWL	3	23	113880	MOUNT, Ratchet	1
11	160464	STR. PULLEY & PIN ASSY. .	1	24	202111	RATCHET	1
12	375836	STARTER SPRING ASSY. ...	1	25	306396	LOCKWASHER, 1/4	4
				26	112789	SCREW, 1/4-20 x 5/8	3

*Cut from 100 ft. roll 316705, cutting length 73-3/4"

†Not shown

INDENTED PART NAMES INDICATE THAT THESE PARTS ARE INCLUDED IN PRECEDING ASSEMBLY

ORDER ALL PARTS FROM YOUR LOCAL AUTHORIZED DEALER