

GENERAL INFORMATION

This Parts catalog has been prepared for your convenience when ordering parts for 1971 to 1974 SNOWMOBILE Models Y398 and Y440. In some cases only the latest part is shown in the illustrations, however, parts lists cover all parts used from 1971 to 1974.

Number in parenthesis following description of part is the quantity needed for complete assembly shown in illustration. If there is no number in parenthesis, only one is used.

Prices of all parts and accessories listed in this catalog are published separately in the latest RETAIL PRICE LIST.

The following instructions should be followed very carefully when ordering parts:


- Specify the correct part number on each item. Check the "Used On" column of the parts list which shows the model and year on which the part fits. Whenever in doubt, refer to the vehicle identification number stamped on the engine crankcase.

Vehicle Identification Number (V.I.N.) is located on the engine crankcase and is the same as the frame number located on the left side of the frame forward of the seat, or on the right side of the track tunnel. The V.I.N. (vehicle identification number) for SNOWMOBILE models are as follows:

SNOWMOBILE (Model)	First Two Digits (Model)	Next Five Digits (Sequential Number)	Second Last Digit (Manufacturer)	Last Digit (Model Season)
Y398 Y440	1B 9C	10000 and up	H (Harley-Davidson)	0-1970 1-1971 (etc.)

Example: 1974 Y398 (1B 12150 H4)

- An asterisk (*) in the "Used On" column indicates part is used up to and including 1974 models (the latest model year covered by this catalog).
- Part-Numbers are to be used when ordering by TELEGRAM or CABLE.
- When ordering parts use our standard parts order blank Part No. 99511-62, for all parts except engines and crankcases. Order blank Part No. 99514-69 must be used for engines and crankcases. The use of these blanks will enable us to fill and ship your order more promptly. These blanks are furnished free of charge upon request.
- Do not order snowmobiles or advertising matter on Parts Order Blanks. Write nothing on the order blank except the order itself, as any other correspondence will not be answered until the order is shipped and billed.
- Freight, Express and Parcel Post orders should be on separate order blanks.
- For your own records, number and date all orders, also keep a carbon copy for reference in case of misunderstanding.



CRANKSHAFT, CYLINDER AND PISTON

CRANKSHAFT. CYLINDER AND PISTON


INDEX NO.	PART NO.	NAME	USED ON
1	6043	THRUST WASHER, connecting rod - lower (stepped) (4)	Late 74 to * - Y398, Y440 (Above 1B-10638-H4 & 9C-11351-H4)
2	6044	THRUST WASHER, connecting rod - lower (4)	Early 74 - Y398, Y440 (Below 1B-10638-H4 & 9C-11351-H4)
3	6229W	WASHER, 5/16 x 1 x 5/8 (2)	73 - Y398, Y440
4	6329W	WASHER, 5/16 x 7/8 x 1/16 (2)	71 & 72 - Y398
5	7041	LOCKWASHER, 5/16 (2)	71 to 73 - Y398, Y440
6	7657P	NUT, 8 mm. (10)	71 to * - Y398, Y440
	16097-73	ENGINE ASSEMBLY, less recoil starter & primary drive	73 - Y398
	16097-74	ENGINE ASSEMBLY, less recoil starter & primary drive	74 to * - Y398
	16098-73	ENGINE ASSEMBLY, less recoil starter & primary drive	73 - Y440
	16098-74	ENGINE ASSEMBLY, less recoil starter & primary drive	74 to * - Y440
7	16490-72	CYLINDER AND PISTON ASSEMBLY, aluminum (2)	Late 72 - Y398
	16539-73	CYLINDER AND PISTON ASSEMBLY (2)	73 - Y440
	16539-74	CYLINDER AND PISTON ASSEMBLY (2)	74 to * - Y440
	16540-73	CYLINDER AND PISTON ASSEMBLY (2)	73 to Early 74 - Y398 (Below 1B-10392-H4)
	16540-74	CYLINDER AND PISTON ASSEMBLY (2)	Late 74 to * - Y398 (Above 1B-10392-H4)

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.

CRANKSHAFT, CYLINDER AND PISTON (CONT'D)

INDEX NO.	PART NO.	NAME	USED ON
8	16601-71	STUD, cylinder head (6) (8 - 1974 & later)	71 to * - Y398, Y440
9	16606-71	STUD, cylinder head (2)	71 to 73 - Y398, Y440
10	16607-71	SPACER, cylinder head stud (2)	71 to 73 - Y398, Y440
11	16692-71A	CYLINDER HEAD (2)	71 & 72 - Y398
	16695-73	CYLINDER HEAD (2)	73 to * - Y440
12	16781-71	GASKET, cylinder base (2)	71 & 72 - Y398
	16781-73	GASKET, cylinder base (2)	73 to * - Y398, Y440
13	16782-71	GASKET, cylinder head (2)	71 to * - Y398
	16783-73	GASKET, cylinder head (2)	73 to * - Y440
14	16823-71	WASHER, cylinder head (8)	71 to * - Y398, Y440
15	22038-71	CYLINDER AND PISTON ASSEMBLY (2)	71 & 72 - Y398 (except last 100)
16	22039-71	PISTON PIN (2)	71 to * - Y398
	22040-73	PISTON PIN (2)	73 to * - Y440
17	22041-73	PISTON AND RINGS ASSEMBLY - standard (2)	73 - Y440
	22041-74	PISTON AND RINGS ASSEMBLY - standard (2)	74 to * - Y440
	22090-71	PISTON AND RINGS ASSEMBLY - standard (2)	71 & 72 - Y398 (except last 100)
	22090-72	PISTON AND RINGS ASSEMBLY - standard (2)	Late 72 to Early 74 - 398 (Below 1B-10392-H4)
	22090-74	PISTON AND RINGS ASSEMBLY - standard (2)	Late 74 to * - Y398 (Above 1B-10392-H4)
	22092-71	PISTON AND RINGS ASSEMBLY - .2 mm. O.S. (2)	71 & 72 - Y398 (except last 100)
	22094-71	PISTON AND RINGS ASSEMBLY - .4 mm. O.S. (2)	71 & 72 - Y398 (except last 100)
	22096-71	PISTON AND RINGS ASSEMBLY - .6 mm. O.S. (2)	71 & 72 - Y398 (except last 100)
	22098-71	PISTON AND RINGS ASSEMBLY - .8 mm. O.S. (2)	71 & 72 - Y398 (except last 100)
18	22310-72	PISTON RING SET - standard (2)	Late 72 to Early 74 - Y398 (Below 1B-10392-H4)
	22310-74	PISTON RING SET - standard (2)	Late 74 to * - Y398 (Above 1B-10392-H4)
	22311-73	PISTON RING SET - standard (2)	73 - Y440
	22311-74	PISTON RING SET - standard (2)	74 to * - Y440
	22420-71	PISTON RING SET - standard (2)	71 & 72 - Y398 (except last 100)
	22422-71	PISTON RING SET - .2 mm. O.S. (2)	71 & 72 - Y398 (except last 100)
	22424-71	PISTON RING SET - .4 mm. O.S. (2)	71 & 72 - Y398 (except last 100)
	22426-71	PISTON RING SET - .6 mm. O.S. (2)	71 & 72 - Y398 (except last 100)
	22428-71	PISTON RING SET - .8 mm. O.S. (2)	71 & 72 - Y398 (except last 100)
19	22579-66F	LOCK RING, piston pin (4)	71 to * - Y398, Y440
20	24205-71	CONNECTING ROD ASSEMBLY (2)	71 to 73 - Y398, Y440; Late 74 to * - Y398, Y440 (Above 1B-10638-H4 & 9C-11351-H4)
	24205-74	CONNECTING ROD ASSEMBLY (2)	Early 74 - Y398, Y440 (Below 1B-10638-H4 & 9C-11351-H4)
21	24382-71	NEEDLE BEARING, piston pin (2)	71 to * - Y398, Y440
22	24485-71	CRANKSHAFT ASSEMBLY	71 & 72 - Y398
	24485-73	CRANKSHAFT ASSEMBLY	73 - Y398, Y440
	24485-74	CRANKSHAFT ASSEMBLY	74 to * - Y398, Y440
23	24486-71	MAINSHAFT, center - with two flywheels	71 to 73 - Y398, Y440; Late 74 to * - Y398, Y440 (Above 1B-10638-H4 & 9C-11351-H4)
	24486-74	MAINSHAFT, center - with two flywheels	Early 74 - Y398, Y440 (Below 1B-10638-H4 & 9C-11351-H4)
24	24487-71	MAINSHAFT, alternator side - with flywheel	71 & 72 - Y398; Late 74 to * - Y398, Y440 (Above 1B-10638-H4 & 9C-11351-H4)
	24487-73	MAINSHAFT, alternator side - with flywheel	73 - Y398, Y440
	24487-74	MAINSHAFT, alternator side - with flywheel	Early 74 - Y398, Y440 (Below 1B-10638-H4 & 9C-11351-H4)
25	24488-71	MAINSHAFT, drive side - with flywheel	71 to 73 - Y398, Y440; Late 74 to * - Y398, Y440 (Above 1B-10638-H4 & 9C-11351-H4)
	24488-74	MAINSHAFT, drive side - with flywheel	Early 74 - Y398, Y440 (Below 1B-10638-H4 & 9C-11351-H4)

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




CRANKCASE

CRANKCASE

INDEX NO.	PART NO.	NAME	USED ON
1	374P	DOWEL PIN (2)	71 to * - Y398, Y440
2	368	DOWEL PIN, roller bearing bushing (2)	71 to * - Y398, Y440
3	705P	PLUG, crankcase impulse hole, 8 mm. x 10 hex. hd.	71 to * - Y398, Y440
4	3836P	BOLT, 5 mm. x 20 hex. hd. (2)	71 to * - Y398, Y440
5	4115P	BOLT, 8 mm. x 30 hex. hd. (2)	71 to * - Y398, Y440
6	4447P	BOLT, 8 mm. x 70 hex. hd. (12)	71 to * - Y398, Y440
7	5974	SPACER, roller bearings - crankshaft ends (2)	71 to * - Y398, Y440
8	6254P	WASHER, 5 mm. (2)	71 to * - Y398, Y440
9	6259P	FIBER WASHER, 8 mm. (2)	71 to * - Y398, Y440
10	6326P	WASHER, 8 mm. (14)	71 to * - Y398, Y440
11	7028P	LOCKWASHER, 6 mm. (2)	71 to * - Y398, Y440
12	7693P	NUT, 6 mm. (2)	71 to * - Y398, Y440
13	9019	BALL BEARING, crankshaft ends (2)	71 to * - Y398, Y440
14	11042	RETAINING RING, roller bearing oil seals (2)	71 to * - Y398, Y440
15	12032	O-RING, roller bearing bushing (2)	71 to * - Y398, Y440
16	12033	OIL SEAL, roller bearings (2)	71 to * - Y398, Y440
17	11423	GROMMET, crankcase	71 to * - Y398, Y440
18	17613-71	ROLLER BEARING, crankshaft ends (2)	71 to * - Y398, Y440
19	23965-71	ROLLER BEARING AND RACE SET, center mainshaft (2)	71 to * - Y398, Y440
20	24380-71	RETAINING PIN, roller bearing (3)	71 to * - Y398, Y440
21	24381-71	RETAINER, ball bearings (2)	71 to * - Y398, Y440
22	24474-71	SHIM, ball bearing, .4 mm.	71 to * - Y398, Y440
	24476-71	SHIM, ball bearing, .6 mm.	71 to * - Y398, Y440
	24478-71	SHIM, ball bearing, .8 mm.	71 to * - Y398, Y440
23	24484-71	CRANKCASE SET, without bearings	71 & 72 - Y398
	24484-73	CRANKCASE SET, without bearings	73 to * - Y398, Y440
24	24489-71	SEAL, center mainshaft bearings, with dowel pins	71 to * - Y398, Y440
25	24492-71	DOWEL PIN, alternator stator (2)	71 to * - Y398, Y440
26	24504-71	DOWEL PIN, center mainshaft bearing seal (2)	71 to * - Y398, Y440
27	24508-71	FITTING, crankcase - impulse hose	71 to * - Y398, Y440
28	39612-71	BUSHING, roller bearing - fan end	71 to * - Y398, Y440
29	39613-71	BUSHING, roller bearing - drive end	71 to * - Y398, Y440
30	63501-68	HOSE, 1/4 I.D. x 1/2 O.D., fabric reinforced rubber, 25 ft. lg.	71 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



**AIR SILENCER, INTAKE
MANIFOLD AND CARBURETOR CONTROL**


AIR SILENCER, INTAKE MANIFOLD AND CARBURETOR CONTROL

INDEX NO.	PART NO.	NAME	USED ON
1	2752W	PINCH SCREW, No. 10-32 x 1-3/8 rd. hd.	71 to * - Y398, Y440
2	2831	SCREW, No. 6-32 x 3/8 Pozidriv hd. (2)	71 to * - Y398, Y440
3	3432	BOLT, 1/4-20 x 3-1/2 (3)	74 to * - Y398, Y440
4	3728	SCREW, 1/4-20 x 1/2 hex. hd. (3)	72 - Y398
5	3767B	BOLT, 1/4-20 x 5/8 hex. hd. (3)	73 - Y398, Y440
6	6316W	WASHER, 5/16 x 5/8 x 1/16 (4 & 2)	71 to * - Y398, Y440
7	7036	LOCKWASHER, 1/4 (3)	72 to * - Y398, Y440
8	7626W	LOCKNUT, No. 10-32	71 to * - Y398, Y440
9	7710W	LOCKNUT, 5/16-18 (2)	71 to * - Y398, Y440
10	7739	LOCKNUT, 5/16-18 (4)	71 to * - Y398, Y440
11	9996	CLAMP, carburetor boot	71 to 73 - Y398, Y440
12	11427	GROMMET, carburetor baffle plate (high altitude)	74 to * - Y398, Y440
13	27016-71	GASKET, intake manifold to cylinder (2)	71 to Early 74 - Y398, Y440 (Below 1B-10392-H4 & 9C-10100-H4)
14	27016-74	GASKET, intake manifold to cylinder (2)	Late 74 to * - Y398, Y440 (Above 1B-10392-H4 & 9C-10100-H4)
15	27017-71	INTAKE MANIFOLD, w/carburetor studs	71 to Early 74 - Y398, Y440 (Below 1B-10392-H4 & 9C-10100-H4)
16	27017-74	INTAKE MANIFOLD, w/carburetor studs	Late 74 to * - Y398, Y440 (Above 1B-10392-H4 & 9C-10100-H4)
17	27056-71	STUD, intake manifold to cylinder - short (3)	71 to Early 74 - Y398, Y440 (Below 1B-10392-H4 & 9C-10100-H4)
18	27056-74	STUD, intake manifold to cylinder (4)	Late 74 to * - Y398, Y440 (Above 1B-10392-H4 & 9C-10100-H4)
19	27057-71	STUD, intake manifold to cylinder - long	71 to Early 74 - Y398, Y440 (Below 1B-10392-H4 & 9C-10100-H4)
20	27072-71	GASKET, carburetor to intake manifold (2)	71 to * - Y398, Y440
21	27073-71	INSULATING SPACER, carburetor	71 to * - Y398, Y440
22	27074-71	BUSHING, carburetor mounting stud (2)	71 to * - Y398, Y440
23	27075-71	SILENCER, air intake	71 to 73 - Y398, Y440
24	27075-74	SILENCER, air intake	74 to * - Y398, Y440
25	27076-71	WASHER, air silencer to carburetor (3)	71 to 73 - Y398, Y440
26	27076-74	LOCKPLATE, silencer mounting bolts	74 to * - Y398, Y440
27	27151-71A	BOOT, carburetor	71 to 73 - Y398, Y440
28	27287-71	THROTTLE CABLE ASSEMBLY	71 to * - Y398, Y440
29	27790-74	BAFFLE PLATE KIT, carburetor (high altitude)	74 to * - Y398, Y440
31	56032-74	THUMB LEVER	71 to * - Y398, Y440
32	56034-71B	THUMB CONTROL ASSEMBLY, complete	71 to * - Y398, Y440
33	56039-71	CLAMP, thumb control	71 to * - Y398, Y440
34	56041-71	SPACER, thumb lever (2)	71 to * - Y398, Y440
35	56092-71	SPACER, under thumb control	71 to * - Y398, Y440
36	60330-71	STUD, intake manifold to carburetor (2)	71 to * - Y398, Y440

CARBURETOR

1	711	WELCH PLUG (2)	71 to * - Y398, Y440
2	1058W	SCREW, No. 8-32 x 5/16 rd. hd.	71 to * - Y398, Y440
	27119-74	CARBURETOR, HD 141A	Late 74 to * - Y398 (Above 1B-10392-H4)
	27138-71	GASKET SET	71 to * - Y398, Y440
	27140-71	REPAIR PARTS KIT	71 to * - Y398, Y440
	27150-71A	CARBURETOR, HD 77B	71 to Early 74 - Y398, Y440 (Below 1B-10392-H4 & 9C-10100-H4)
	27150-74	CARBURETOR, HD 139A	Late 74 to * - Y440 (Above 9C-10100-H4)


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



CARBURETOR (CONT'D)

INDEX NO.	PART NO.	NAME	USED ON
3	27247-72	CHOKE KNOB	72 - Y398
4	27353-66	PACKING, idle and high speed mixture screws (2)	71 to * - Y398, Y440
5	27354-66	WASHER, idle and high speed mixture screws (3)	71 to * - Y398, Y440
6	27406-26	BALL, choke shaft friction spring	71 to * - Y398, Y440
7	27598-66	GASKET, inlet seat	71 to * - Y398, Y440
8	27601-63	GASKET, inlet cover	71 to * - Y398, Y440
9	27643-71	BODY, fuel pump	71 to * - Y398, Y440
10	27671-55	FRICTION SPRING, choke shaft	71 to * - Y398, Y440
11	27689-61	SPRING, idle and high speed mixture screws (2)	71 to * - Y398, Y440
12	27691-59	SPRING, idle speed screw	71 to * - Y398, Y440
13	27696-66	SCREW, inlet valve lever pin	71 to * - Y398, Y440
14	27698-61	GASKET, high speed mixture screw	71 to * - Y398, Y440
15	27714-86	THROTTLE DISC	71 to * - Y398, Y440
16	27717-59	SCREW, idle speed	71 to * - Y398, Y440
17	27720-61	SCREW WITH LOCKWASHER, throttle and choke discs (2 or 4)	71 to * - Y398, Y440
18	27732-61	SCREW, throttle shaft clip	71 to * - Y398, Y440
19	27732-63	SCREW, inlet cover	71 to * - Y398, Y440
20	27733-61	LOCKWASHER, throttle shaft clip screw and throttle cable bracket retainer screw (1 & 2)	71 to * - Y398, Y440
21	27740-66	LEVER, inlet valve	71 to * - Y398, Y440
22	27760-71A	THROTTLE SHAFT AND LEVER ASSEMBLY	71 to * - Y398, Y440
22A	27775-74	SCREW WITH LOCKWASHER, No. 4-40 x 1/4 rd. hd. (2)	74 to * - Y398, Y440
23	27813-63	SPRING, inlet valve lever	71 to * - Y398, Y440
24	27817-71	DIAPHRAGM	71 to * - Y398, Y440
25	27824-71	SPRING, throttle shaft return	71 to * - Y398, Y440
26	27825-71	CLIP, throttle shaft	71 to * - Y398, Y440
27	27826-71	LOCKNUT, throttle cable clamp screw	71 to * - Y398, Y440
28	27827-71	SCREW, throttle cable clamp	71 to * - Y398, Y440
29	27828-71	CLAMP, throttle cable	71 to * - Y398, Y440
30	27829-71A	THROTTLE CABLE CLAMP ASSEMBLY	71 to * - Y398, Y440
31	27830-71	GASKET, main fuel jet	71 to * - Y398, Y440
32	27831-71	SCREEN, inlet	71 to * - Y398, Y440
33	27832-71	CHECK VALVE ASSEMBLY	71 to * - Y398, Y440
34	27833-71	MAIN FUEL JET, .089	71 to Early 74 - Y398, Y440 (Below 1B-10392-H4 & 9C-10100-H4)
	27833-74	MAIN FUEL JET, .0635	Late 74 to * - Y398, Y440 (Above 1B-10392-H4 & 9C-10100-H4)
35	27834-71	GLAND, high speed mixture screw	71 to * - Y398, Y440
36	27835-71	SCREW, high speed mixture	71 to * - Y398, Y440
37	27836-71	BODY, inlet valve	71 to * - Y398, Y440
38	27837-71	DIAPHRAGM, fuel pump - lower	71 to * - Y398, Y440
39	27838-71	GASKET, fuel pump - lower	71 to * - Y398, Y440
40	27839-71	SPRING, elbow hose fitting screen	71 to * - Y398, Y440
41	27840-71	SCREEN, elbow hose fitting	71 to * - Y398, Y440
42	27841-71	INLET VALVE NEEDLE, SEAT AND GASKET	71 to * - Y398, Y440
43	27842-71	PIN, inlet valve lever	71 to * - Y398, Y440
44	27843-71	SCREW, idle mixture	71 to * - Y398, Y440
45	27844-71	COVER, inlet	71 to * - Y398, Y440
46	27845-71	DIAPHRAGM, upper	71 to * - Y398, Y440
47	27846-71	GASKET, diaphragm cover - upper	71 to * - Y398, Y440
48	27847-71	FITTING, return line - elbow	71 to * - Y398, Y440
49	27848-71	BODY, impulse fitting	71 to * - Y398, Y440
50	27849-71	GASKET, impulse fitting body	71 to * - Y398, Y440
51	27850-71	CHOKE DISC	71 to * - Y398, Y440
52	27851-71	CHOKE SHAFT	71 to * - Y398, Y440
53	27852-71	SCREW WITH LOCKWASHER, fitting plug	71 to * - Y398, Y440
54	27853-71	SCREW, throttle cable bracket retainer (2)	71 to * - Y398, Y440
55	27854-71	SCREW WITH LOCKWASHER, pump body (5)	71 to * - Y398, Y440
56	27870-73	CHOKE CONTROL ASSEMBLY	73 - Y398, Y440
	27870-74	CHOKE CONTROL ASSEMBLY	74 to * - Y398, Y440


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



ALTERNATOR, FAN HOUSING AND ENGINE SHROUD

INDEX NO.	PART NO.	NAME	USED ON
1	3798P	BOLT, 6 mm. x 25 hex. hd. (6)	71 to * - Y398, Y440
2	3800P	SCREW, 6 mm. x 14 socket hd. (2)	71 to * - Y398, Y440
3	4017	BOLT, 5/16-18 x 1 hex. hd.	74 to * - Y398, Y440
4	4103	SCREW, 5 mm. x 25 socket hd. (4)	71 to * - Y398, Y440
5	4115P	BOLT, 8 mm. x 30 hex. hd.	71 to * - Y398, Y440
6	5927	RUBBER WASHER, heat shield mounting	74 to * - Y398, Y440
7	6254P	WASHER, 6 mm. (8)	71 to * - Y398, Y440
8	6326P	WASHER, 8 mm.	71 to * - Y398, Y440
9	6702	WASHER, 5/16 x 11/16 x 1/16	74 to * - Y398, Y440
10	7028P	LOCKWASHER, 6 mm. (8)	71 to * - Y398, Y440
11	7075	LOCKWASHER, 3/4	71 to * - Y398, Y440
12	7118	LOCKWASHER, No. 10 internal tooth (4)	71 to * - Y398, Y440
13	7710W	LOCKNUT, 5/16-18 x 1/4 x 1/2 hex.	74 to * - Y398, Y440
14	7811	NUT, 18 mm.	71 to * - Y398, Y440
15	8683	POP RIVET, nameplate (2)	73 to * - Y398, Y440
16	11213	WOODRUFF KEY, rotor mounting	72 - Y398
17	11214	SQUARE KEY, rotor mounting	73 to * - Y398, Y440
18	16206-73	NAMEPLATE - "Harley-Davidson 398 cc"	73 to * - Y398
19	16206-73	NAMEPLATE - "Harley-Davidson 440 cc"	73 to * - Y440
20	20013-71	FAN HOUSING	71 to * - Y398, Y440
21	20015-71	AIR SHROUD, cylinder head	71 & 72 - Y398 (except last 100)
22	20015-72	AIR SHROUD, cylinder head	Late 72 to 73 - Y398, Y440
23	20015-74	AIR SHROUD, cylinder head	74 to * - Y398, Y440
24	20016-71	SHIELD PLATE, fan housing	71 to * - Y398, Y440
25	27783-74	AIR BAFFLE, engine front	74 to * - Y398, Y440
26	27786-74	HEAT SHIELD, engine right side	74 to * - Y398, Y440
27	29973-72A	STATOR	72 to * - Y398, Y440
29	29976-73	ROTOR, with fan	71 to * - Y398, Y440
30	29982-71	CLAMP, stator cable	71 to * - Y398, Y440
31	29987-72	CONNECTOR PLUG, with wires - stator	72 to * - Y398, Y440
32	72034-71	CONNECTOR, double socket - stator	71 to * - Y398, Y440
33	72035-71	CONNECTOR, double pin - stator	71 to * - Y398, Y440
34	72036-71	CONNECTOR, triple pin - stator	71 to * - Y398, Y440
35	91886-73	CLAMP, heat shield	74 to * - Y398, Y440


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



ELECTRIC STARTER

INDEX NO.	PART NO.	NAME	USED ON
1	3967P	SCREW, 8 mm, x 30 socket hd. (2)	71 to * - Y398, Y440
2	7025W	LOCKWASHER, No. 10 (2)	72 to * - Y398, Y440
3	7036	LOCKWASHER, 1/4 (2)	72 to * - Y398, Y440
4	7041	LOCKWASHER, 5/16 (4)	71 to * - Y398, Y440
5	7756P	NUT, 8 mm (2)	72 to * - Y398, Y440
	31454-71A	STARTER MOTOR, with solenoid	71 to * - Y398, Y440
6	31459-71	COVER, starter motor hole	71 to * - Y398, Y440
7	31509-72	BRUSH PLATE ASSEMBLY	72 to * - Y398, Y440
8	31510-72	COVER, commutator end - with bushings	72 to * - Y398, Y440
9	31511-72	BUSHING, drive end flange & commutator end cover (2)	72 to * - Y398, Y440
10	31513-72	ARMATURE	72 to * - Y398, Y440
11	31514-72	FIELD COIL	72 to * - Y398, Y440
12	31543-72	SCREW, solenoid mounting (2)	72 to * - Y398, Y440
13	31544-72	RUBBER PACKING	72 to * - Y398, Y440
14	31545-72	FLANGE, drive end, complete with bushings	72 to * - Y398, Y440
16	31547-72	DRIVE ASSEMBLY	72 to * - Y398, Y440
17	31548-72	SNAP RING, armature shaft	72 to * - Y398, Y440
18	31549-72	ENGAGING LEVER	72 to * - Y398, Y440
19	31552-72	PLUG, armature shaft ends (2)	72 to * - Y398, Y440
20	31553-72	BRUSH (2)	72 to * - Y398, Y440
21	31554-72	BRUSH SPRING (2)	72 to * - Y398, Y440
22	31555-72	SCREW, field coil (4)	72 to * - Y398, Y440
23	31556-72	COLLAR, pinion stop	72 to * - Y398, Y440
24	31558-72	THRU-BOLT (2)	72 to * - Y398, Y440
25	31559-72	SCREW, engaging lever pivot	72 to * - Y398, Y440
26	31560-72	PIN, engaging lever pivot screw	72 to * - Y398, Y440
27	31561-72	SOLENOID	72 to * - Y398, Y440
28	31562-72	WASHER, armature shaft (2)	72 to * - Y398, Y440
29	31563-72	THRUST WASHER, armature shaft - .012	72 to * - Y398, Y440
30	31564-72	THRUST WASHER, armature shaft - .004	72 to * - Y398, Y440
31	33228-72	SHIM, starter motor mounting, .040	72 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




MANUAL STARTER - 1973 & LATER

MANUAL STARTER - 1973 & LATER

INDEX NO.	PART NO.	NAME	USED ON
1	3974P	SCREW, 8 mm. x 25 socket hd. (4).....	73 to * - Y398, Y440
2	7041	LOCKWASHER, 5/16 (4).....	73 to * - Y398, Y440
3	11000	RETAINING RING (3).....	73 to * - Y398, Y440
	33241-73	STARTER ASSEMBLY, complete (no finish).....	73 to * - Y398, Y440
	33271-73	STARTER ASSEMBLY, complete (black & polished).....	73 to * - Y398, Y440
4	33275-73	CORD, only.....	73 to * - Y398, Y440
5	33280-73	HOUSING (black & polished).....	73 to * - Y398, Y440
6	33281-73	HOUSING (no finish).....	73 to * - Y398, Y440
7	33282-73	PULLEY.....	73 to * - Y398, Y440
8	33283-73	PAWL (3).....	73 to * - Y398, Y440
9	33285-73	RECOIL SPRING.....	73 to * - Y398, Y440
10	33286-73	SPRING, pawl (3).....	73 to * - Y398, Y440
11	33287-73	HANDLE.....	73 to * - Y398, Y440
12	33288-73	CENTER SCREW.....	73 to * - Y398, Y440
13	33289-73	SPRING, cam.....	73 to * - Y398, Y440
14	33290-73	WASHER, cam spring.....	73 to * - Y398, Y440
15	33291-73	RETAINER, cord handle.....	73 to * - Y398, Y440
16	33292-73	BUSHING, pulley.....	73 to * - Y398, Y440
17	33293-73	CAM.....	73 to * - Y398, Y440
18	36445-71	EMERGENCY STARTER CORD.....	73 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover


TRANSMISSION PRIMARY DRIVE



TRANSMISSION PRIMARY DRIVE

INDEX NO.	PART NO.	NAME	USED ON
1	1665W	SCREW, No. 6-32 x 1/4 self-tapping ctsk. hd. (5)	71 to * - Y398, Y440
2	5927	SPACER (2)	71 to * - Y398, Y440
3	6242W	WASHER, 1/4 x 9/16 x 1/32 (3)	71 to * - Y398, Y440
4	6319HW	WASHER, 5/16 x 11/16 x 1/16 (2)	72 to * - Y398, Y440
5	6647	SHIM, stationary flange, .020 (as req'd. to .060)	71 to * - Y398, Y440
6	6648	SHIM, stationary flange, .007 (as req'd. to .060)	71 to * - Y398, Y440
7	7704	ACORN NUT, 1/4-28 (3)	71 to * - Y398, Y440
8	7988	NUT, 5/8-18	71 to * - Y398, Y440
9	8109W	WING NUT, drive shield mounting (2) (1971 - upper only)	71 to * - Y398, Y440
10	8529	POP RIVET (7)	72 to * - Y398, Y440
11	11108	O-RING, floating flange hub	71 to * - Y398, Y440
12	11109	O-RING, drive cup cover	71 to * - Y398, Y440
13	23733-72	SLEEVE, front floating flange	72 to * - Y398, Y440
14	23747-71B	LOCKWASHER, transmission shaft nut	71 to * - Y398, Y440
15	34862-61B	COVER, drive cup, with plug	71 to * - Y398, Y440
16	34863-63	RUBBER PLUG, drive cup cover	71 to * - Y398, Y440
17	34958-71	DRIVE BELT	71 to 73 - Y398, Y440
	34959-74	DRIVE BELT	74 to * - Y398, Y440
18	36428-72A	DRIVE SHIELD, with 36477-72A trim	72 & 73 - Y398, Y440
19	36432-71A	FLOATING FLANGE	71 to * - Y398, Y440
20	36442-72A	DRIVE SHIELD, w/36469-71 label	72 & 73 - Y398, Y440
	36442-74	DRIVE SHIELD, w/36469-71 label	74 to * - Y398, Y440
21	36456-71A	STATIONARY FLANGE	71 to * - Y398, Y440
22	36460-61	SLIDE STRIP, floating flange (3)	71 to * - Y398, Y440
23	36466-61	RETAINER, floating flange o-ring	71 to * - Y398, Y440
24	36469-71	LABEL, drive shield "For your safety"	71 to * - Y398, Y440
25	36476-72	BUSHING, floating flange	72 to * - Y398, Y440
26	36477-72A	LABEL & TRIM, drive shield "For your safety"	72 & 73 - Y398, Y440
27	36487-72A	BEARING, belt idler	71 to * - Y398, Y440
27A	36497-72	WASHER, .060 (used when .060 or over Shims are needed)	71 to * - Y398, Y440
28	36515-71	DRIVE CUP ASSEMBLY	71 to * - Y398, Y440
29	36538-71	COLLAR, drive cup spring (3)	71 to * - Y398, Y440
30	36540-61	CUP, drive cup spring (3)	71 to * - Y398, Y440
31	36541-71	SPRING GUIDE, inner (3)	71 to * - Y398, Y440
32	36542-59	SPRING, drive cup - inner (3)	71 to * - Y398, Y440
33	36544-59	SPRING, drive cup - outer (3)	71 to * - Y398, Y440
34	36549-59	BUSHING, drive cup (3)	71 to * - Y398, Y440
35	36556-71	STRIP, drive cup weight (3)	71 to * - Y398, Y440
36	36559-72A	SET OF 3 DRIVE CUP WEIGHTS	71 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




TRANSMISSION SECONDARY DRIVE—1973 & EARLIER

TRANSMISSION SECONDARY DRIVE - 1973 & EARLIER

INDEX NO.	PART NO.	N A M E	U S E D O N
1	612	ROLL PIN, floating flange, 3/32 x 3/4 (2)	71 to 73 - Y398, Y440
2	1960W	SCREW, 5/16-24 x 7/8 ctsk. flat Phillips hd. (4)	71 & 72 - Y398
3	1961	SCREW, 5/16-24 x 7/8 ctsk. socket hd. (4)	73 - Y398, Y440
4	7714W	LOCKNUT, 5/16-24 (4)	71 & 72 - Y398
5	7725	LOCKNUT, 5/16-24 (4)	73 - Y398, Y440
6	11054	RETAINER, spring cup (2)	71 to 73 - Y398, Y440
7	11102	O-RING, stationary flange shaft	73 - Y398, Y440
8	23745-47	RETAINING RING, floating flange	71 to 73 - Y398, Y440
9	34958-71	DRIVE BELT	71 to 73 - Y398, Y440
10	36392-73	SPRING, inner	73 - Y398, Y440
11	36395-73	BRAKE DISC AND SHAFT AND STATIONARY FLANGE ASSEMBLY ..	73 - Y398, Y440
12	36402-71	BRAKE DISC AND SHAFT	71 & 72 - Y398
13	36406-70	PIN, floating flange ramp shoe (2)	71 to 73 - Y398, Y440
14	36429-59A	SPRING CUP, outer	71 to 73 - Y398, Y440
15	36430-59	SPRING, outer	71 & 72 - Y398
16	36430-62	SPRING, outer	73 - Y398, Y440
17	36431-61	SPRING, inner	71 & 72 - Y398
18	36433-71	FLOATING FLANGE	71 & 72 - Y398
19	36433-73	FLOATING FLANGE	73 - Y398, Y440
	36434-71	SECONDARY DRIVE SHEAVE, complete	71 & 72 - Y398
	36434-73	SECONDARY DRIVE SHEAVE, complete	73 - Y398, Y440
20	36436-71	RAMP SHOE, reverse - floating flange (2)	71 to 73 - Y398, Y440
21	36437-71	RAMP SHOE, floating flange (2)	71 & 72 - Y398
22	36437-73	RAMP SHOE, floating flange (2)	73 - Y398, Y440
23	36458-71	STATIONARY FLANGE	71 & 72 - Y398, Y440
24	36471-73	SPRING CUP, inner	73 - Y398, Y440
25	36474-71A	BUSHING, floating flange	71 to 73 - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




TRANSMISSION SECONDARY DRIVE-1974 & LATER

TRANSMISSION SECONDARY DRIVE - 1974 & LATER

INDEX NO.	PART NO.	N A M E	U S E D O N
1	1961	SCREW, 5/16-24 x 7/8 ctsk. socket hd. (4)	74 to * - Y398, Y440
2	7725	LOCKNUT, 5/16-24 (4)	74 to * - Y398, Y440
3	11073	RETAINING RING, spring cup	74 to * - Y398, Y440
4	11102	O-RING, stationary flange shaft	74 to * - Y398, Y440
5	11206	WOODRUFF KEY	74 to * - Y398, Y440
6	23745-47	RETAINING RING, floating flange	74 to * - Y398, Y440
7	34959-74	DRIVE BELT	74 to * - Y398, Y440
	36370-74	SECONDARY DRIVE SHEAVE, complete	74 to * - Y398, Y440
8	36371-74	BRAKE DISC AND SHAFT AND STATIONARY FLANGE ASSEMBLY ..	74 to * - Y398, Y440
9	36377-74	FLOATING FLANGE	74 to * - Y398, Y440
10	36379-74	RAMP SHOE, floating flange (3)	74 to * - Y398, Y440
11	36380-74	SPRING CUP	74 to * - Y398, Y440
12	36382-74	SPRING	74 to * - Y398, Y440
13	36474-71A	BUSHING, floating flange	74 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




CHAIN DRIVE AND CASE

CHAIN DRIVE AND CASE

INDEX NO.	PART NO.	NAME	USED ON
1	559	COTTER PIN, 1/8 x 1-1/4	73 to * - Y398, Y440
2	2567	BOLT, 5/16-18 x 2 hex. hd. (8)	73 to * - Y398, Y440
3	2827W	SCREW, 3/8-16 x 1-3/4 ckn. flat hd.	71 & 72 - Y398
4	2890W	BOLT, 5/16-18 x 1-1/2 hex. hd. (2)	71 & 72 - Y398
5	4354	BOLT, 3/8-16 x 1-3/8 hex. hd.	71 & 72 - Y398
6	4710W	BOLT, 3/8-16 x 1-1/4 hex. hd.	73 to * - Y398, Y440
7	4721	BOLT, 3/8-16 x 1-1/2 hex. hd.	73 to * - Y398, Y440
8	5445W	CARRIAGE BOLT, 5/16-18 x 1-1/4 (3)	71 & 72 - Y398
9	5447	CARRIAGE BOLT, 5/16-18 x 1-7/16 (3)	73 to * - Y398, Y440
10	5971B	SPACER, large sprocket	71 to * - Y398, Y440
11	6520W	WASHER, 3/8 x 13/16 x 1/16	71 to 73 - Y398, Y440
12	6590HW	WASHER, 1/2 x 1-1/8 x 3/32	72 to * - Y398, Y440
13	6612B	WASHER, 1/2 x 3/4 x 3/32 (if req'd.)	73 to * - Y398, Y440
14	6922	SHIM, secondary shaft bearing, .002	71 to * - Y398, Y440
	6923	SHIM, secondary shaft bearing, .005	71 to * - Y398, Y440
	6924	SHIM, secondary shaft bearing, .007	71 to * - Y398, Y440
	6925	SHIM, secondary shaft bearing, .015	71 to * - Y398, Y440
15	7140W	LOCKWASHER, 3/8	72 - Y398
16	7739	LOCKNUT, 5/16-18 (7)	71 to * - Y398, Y440
17	7776	LOCKNUT, 3/8-16 (2)	71 to * - Y398, Y440
18	7812W	LOCKNUT, 1/2-20	72 - Y398
19	7814	CASTLE NUT, 1/2-20	73 to * - Y398, Y440
20	7859W	LOCKNUT, 3/4-16	72 - Y398
21	9042	BALL BEARING	73 to * - Y398, Y440
22	11066	RETAINING RING, large sprocket	73 to * - Y398, Y440
23	35151-52A	SEAL, front axle bearing - left	71 to * - Y398, Y440
24	37740-57	OIL SEAL, chain case - upper	73 to * - Y398, Y440
25	39970-71	CHAIN ADJUSTER, complete	71 to * - Y398, Y440
26	39978-58	LINING, chain adjuster	71 to * - Y398, Y440
27	39979-58A	RETAINER, chain adjuster lining	71 to * - Y398, Y440
28	39984-71	STUD, chain case - long	71 & 72 - Y398
29	40001-73	CHAIN, 85 pitches	73 to * - Y398, Y440
	40001-74	CHAIN, 86 pitches	74 to * - Y398, Y440
	40006-71	CHAIN, 84 pitches	71 to * - Y398, Y440
30	40055-29	CONNECTING LINK	71 to * - Y398, Y440
31	40057-72	OFFSET REPAIR LINK	71 to * - Y398, Y440
32	40096-29	DOUBLE REPAIR LINK	71 to * - Y398, Y440
33	40201-72	SPROCKET, 17 T.	72 to * - Y398, Y440
34	40202-71	SPROCKET, 14 T.	71 to * - Y398, Y440
35	40203-71	SPROCKET, 16 T. (standard in 71 & 72)	71 to * - Y398, Y440
36	40204-74	SPROCKET, 32 T. (standard in 74)	74 to * - Y398, Y440
37	40205-72	SPROCKET, 35 T. (standard in 72)	72 to * - Y398, Y440
38	40205-73	SPROCKET, 34 T. (standard in 73 & later)	73 to * - Y398, Y440
39	40207-71	SPROCKET, 15 T. (standard in 73)	71 to * - Y398, Y440
40	40212-73	SPROCKET, 13 T.	73 to * - Y398, Y440
41	40213-73	SPROCKET, 18 T.	73 to * - Y398, Y440
42	60314-71	COVER, chain case	71 & 72 - Y398
	60314-73	COVER, chain case	73 to * - Y398, Y440
43	60330-71	STUD, chain case - short (3)	71 & 72 - Y398
44	60339-71A	CHAIN CASE	71 & 72 - Y398
	60339-73A	CHAIN CASE	73 to * - Y398, Y440
45	60349-71	VIEW GAGE, chain cover	71 & 72 - Y398
46	60349-73	VIEW GAGE, chain cover	73 to * - Y398, Y440
47	60351-71	PLUG, chain adjustment access hole	71 to * - Y398, Y440
48	60553-71	FILLER PLUG, chain case	71 to * - Y398, Y440
49	60566-71	GASKET, chain case cover	71 & 72 - Y398
	60566-73	GASKET, chain case cover	73 to * - Y398, Y440
50	60568-71	SPACER, secondary drive shaft bearings	71 & 72 - Y398
	60568-73	SPACER, secondary drive shaft bearings	73 to * - Y398, Y440
51	60571-71	SEALED BALL BEARING (3 - 1971 & 1972, 2 - 1973 & later)	71 to * - Y398, Y440
	99890-61	TRANSMISSION LUBRICANT (chain case) - 12 oz. can	71 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



TRACK AND BOGIE SUSPENSION


INDEX NO.	PART NO.	NAME	USED ON
1	2551W	BOLT, 1/4-20 x 1 hex. hd. (16)	71 & 72 - Y398
2	2649	SCREW, 5/16-18 x 3/4 crsk. socket hd. (6)	74 to * - Y398, Y440
3	2822	BOLT, 3/8-16 x 3-3/4 hex. hd. (2)	74 to * - Y398, Y440
4	2826W	BOLT, 3/8-16 x 2-3/4 hex. hd. (2)	71 to 73 - Y398, Y440
5	2828W	BOLT, 3/8-16 x 3 hex. hd. (2)	71 & 72 - Y398
6	2879W	BOLT, 3/8-16 x 1 hex. hd. (2)	73 - Y398, Y440
7	2891W	BOLT, 5/16-18 x 1 hex. hd. (6)	71 to 73 - Y398, Y440
8	2897	BOLT, 5/16-18 x 1-1/4 hex. hd. (6)	74 to * - Y398, Y440
9	4410	BOLT, 1/4-28 x 7/8 hex. hd. (36)	73 to * - Y398, Y440
10	4435W	BOLT, 3/8-24 x 3-1/2 hex. hd. (2)	74 to * - Y398, Y440
11	5446W	CARRIAGE BOLT, 5/16-18 x 3/4 (2 & 3)	71 to 73 - Y398, Y440
12	5448	BOLT, 5/16-24 x 1-1/4 special hd. (4)	74 to * - Y398, Y440
13	5898	SPACER, sprocket flange (20)	71 & 72 - Y398
14	5967B	SPACER, torsion rod support (2)	71 & 72 - Y398
15	5971B	SPACER, front axle bearing - left	71 to * - Y398, Y440
16	5992	SPACER, torsion spring mounting (2)	74 to * - Y398, Y440
17	6112	WASHER, 3/8 x 1-1/2 x 3/32 (4)	74 to * - Y398, Y440
18	6329W	WASHER, 5/16 x 7/8 x 5/64 (18) (4 - 1974 & later)	71 to * - Y398, Y440
19	6379W	WASHER, 3/8 x 5/8 x 3/64 (4)	71 to 73 - Y398, Y440
20	6701	WASHER, 3/8 x 13/16 x 1/16 (4)	74 to * - Y398, Y440

TRACK AND BOGIE SUSPENSION (CONT'D)

INDEX NO.	PART NO.	NAME	USED ON
21	7041	LOCKWASHER, 5/16 (6)	71 to * - Y398, Y440
22	7045	LOCKWASHER, 3/8 (2)	71 to 73 - Y398, Y440
23	7685	LOCKNUT, 1/4-28 (36)	73 to * - Y398, Y440
24	7686	LOCKNUT, 1/4-20 (18)	71 & 72 - Y398, Y440
25	7712W	LOCKNUT, 5/16-18 (6)	71 & 72 - Y398
26	7725	LOCKNUT, 5/16-24 (6)	73 to * - Y398, Y440
27	7739	LOCKNUT, 5/16-18 (27)	71 to 73 - Y398, Y440
28	7775	LOCKNUT, 3/8-24 (2)	74 to * - Y398, Y440
29	7783	NUT, 3/8-16 x 5/16 x 9/16 hex. (2)	74 to * - Y398, Y440
30	11058	RETAINING RING, front axle bearing left shield	72 & 73 - Y398, Y440
31	12035	SEAL, rear axle bearing (2) front axle bearing - right	71 to * - Y398, Y440
32	35151-52A	SEAL, front axle bearing - left	71 to * - Y398, Y440
33	39299-74	CLIP, suspension unit to frame (5)	74 to * - Y398, Y440
	39301-71B	SUSPENSION UNIT, (4 bogie wheels each) (3)	71 to * - Y398, Y440
34	39302-71	SUPPORT FRAME, bogie wheel (6)	71 to * - Y398, Y440
35	39306-71	CLIP, torsion spring (12)	71 to * - Y398, Y440
36	39307-71	AXLE, secondary (6)	71 & 72 - Y398
37	39307-73	AXLE, secondary (6)	73 to * - Y398, Y440
38	39309-71A	AXLE, main (3)	71 to * - Y398, Y440
39	39310-71	BOGIE WHEEL (12)	71 & 72 - Y398
40	39310-73	BOGIE WHEEL (12)	73 to * - Y398, Y440
41	39311-71	SPACER, secondary axle (12)	71 & 72 - Y398
42	39312-71	TORSION SPRING, bogie wheel (6)	71 to * - Y398, Y440
43	39313-72	TRACK	72 - Y398
44	39313-73	TRACK	73 to * - Y398, Y440
45	39315-73	CLEAT, track	73 to * - Y398, Y440
46	43748-72	RETAINER, front axle bearing - right	72 & 73 - Y398, Y440
47	43840-72	FRONT AXLE	72 - Y398
48	43840-73	FRONT AXLE	73 - Y398, Y440
49	43840-74	FRONT AXLE	74 to * - Y398, Y440
50	43849-71	FLANGE, sprocket - front axle (2)	71 & 72 - Y398
51	43849-73	FLANGE, sprocket (4)	73 to * - Y398, Y440
52	43868-72	BOLT, rear sprocket flange (20)	72 - Y398
53	43878-71	REAR AXLE, only	71 & 72 - Y398
54	43878-73	REAR AXLE, only	73 - Y398, Y440
55	43878-74	REAR AXLE, only	74 to * - Y398, Y440
56	43879-71	ROD, torsion spring	71 & 72 - Y398
57	43879-73	ROD, torsion spring	73 - Y398, Y440
58	43888-71	SPROCKET, rear axle (2)	71 & 72 - Y398
59	43888-73	SPROCKET, rear axle (2)	73 - Y398, Y440
60	43889-72	SPROCKET, front axle (2)	72 - Y398
61	43889-73	SPROCKET, front axle; front & rear axle - 1974 & later (2 or 4)	73 to * - Y398, Y440
62	43890-73	SPROCKET KIT, front axle; front & rear axle - 1974 & later (includes 9 - 4410 & 7683) (2 or 4)	73 to * - Y398, Y440
63	43891-73	SPROCKET KIT, rear axle (includes 9 - 4410 & 7683) (2)	73 - Y398, Y440
64	43893-71	FLANGE, sprocket to rear axle (2)	71 & 72 - Y398
65	43901-71	TORSION SPRING, right	71 & 72 - Y398
66	43901-73	TORSION SPRING, right	73 to * - Y398, Y440
67	43902-71	TORSION SPRING, left	71 & 72 - Y398
68	43902-73	TORSION SPRING, left	73 to * - Y398, Y440
69	60558-71	SHIELD, front axle bearing - left	71 to 73 - Y398, Y440
70	60558-74	SHIELD, front axle bearing - left	74 to * - Y398, Y440
71	60559-74	RETAINER, front axle bearing - right	74 to * - Y398, Y440
72	60671-71	BALL BEARING, front and rear axle (4)	71 to * - Y398, Y440
73	67035-74	RETAINER, front axle bearing - right	74 to * - Y398, Y440
74	82132-72	SUPPORT ARM, rear axle - right	71 & 72 - Y398
75	82132-73	SUPPORT ARM, rear axle - right	73 to * - Y398, Y440
76	82133-72	SUPPORT ARM, rear axle - left	71 & 72 - Y398
77	82133-73	SUPPORT ARM, rear axle - left	73 to * - Y398, Y440
78	82136-71	BLOCK, track adjustment (2)	71 to 73 - Y398, Y440
79	83036-71A	BRACKET, track adjustment - right	71 to 73 - Y398, Y440
80	83036-74	BRACKET, track adjustment - right	74 to * - Y398, Y440
81	83037-71A	BRACKET, track adjustment - left	71 to 73 - Y398, Y440
82	83037-74	BRACKET, track adjustment - left	74 to * - Y398, Y440
83	83038-74	BLOCK, track adjustment (2)	74 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.

SLIDE RAIL SUSPENSION




SLIDE RAIL SUSPENSION

INDEX NO.	PART NO.	NAME	USED ON
1	2879W	BOLT, 5/8-16 x 1 hex. hd. (8)	73 to * - Y398, Y440
2	3960W	BOLT, 5/16-24 x 1 hex. hd. (6)	73 - Y398, Y440
3	4034W	BOLT, 5/16-24 x 1-1/4 (2)	73 - Y398, Y440
4	4057	BOLT, 5/16-18 x 1 hex. hd. (8)	74 to * - Y398, Y440
5	4712	BOLT, 3/8-16 x 3-1/4 hex. hd.	73 to * - Y398, Y440
6	6329W	WASHER, 5/16 x 7/8 x 3/16 (14)	73 to * - Y398, Y440
7	6337	WASHER, 5/16 x 15/16 x 5/32 (2)	73 - Y398, Y440
8	6701	WASHER, 3/8 x 13/16 x 1/16 (9)	73 to * - Y398, Y440
9	6714W	WASHER, 5/8 x 1 x 1/32 (2)	73 to * - Y398, Y440
10	7038	LOCKWASHER, 3/8 (16)	73 to * - Y398, Y440
10A	7041	LOCKWASHER, 5/16 (2)	74 to * - Y398, Y440
11	7725	LOCKNUT, 5/16-24 (8)	73 - Y398, Y440
12	7739	LOCKNUT, 5/16-18 (8)	74 to * - Y398, Y440
13	7778	LOCKNUT, 3/8-16	73 to * - Y398, Y440
14	8529	POP RIVET, wear strip (18)	73 to * - Y398, Y440
15	36487-72	WASHER (8)	73 to * - Y398, Y440
	39201-73	SLIDE RAIL SUSPENSION ASSEMBLY, complete	73 - Y398, Y440
	39201-74	SLIDE RAIL SUSPENSION ASSEMBLY, complete	74 to * - Y398, Y440
16	39210-73	FRAME, left	73 - Y398, Y440
17	39210-74	FRAME, right	74 to * - Y398, Y440
18	39211-73	FRAME, right	73 - Y398, Y440
19	39211-74	FRAME, left	74 to * - Y398, Y440
20	39212-73	SWING ARM, front	73 - Y398, Y440
	39212-74	SWING ARM, front	74 to * - Y398, Y440
21	39213-73	SWING ARM, front center	73 - Y398, Y440
	39213-74	SWING ARM, front center	74 to * - Y398, Y440
22	39214-73	SWING ARM, rear	73 - Y398, Y440
	39214-74	SWING ARM, rear	74 to * - Y398, Y440
23	39215-73	SWING ARM, rear center	73 - Y398, Y440
	39215-74	SWING ARM, rear center	74 to * - Y398, Y440
24	39216-73	SHAFT, front - lower	73 to * - Y398, Y440
25	39217-73	SHAFT (2)	73 to * - Y398, Y440
26	39218-73	SHAFT, shock absorber - lower	73 to * - Y398, Y440
27	39219-73	SHAFT, upper (3)	73 - Y398, Y440
	39219-74	SHAFT, upper (3)	74 to * - Y398, Y440
28	39220-73	SHAFT, upper - rear	73 - Y398, Y440
	39220-74	SHAFT, upper - rear	74 to * - Y398, Y440
29	39221-73	SLIDE RAIL ASSEMBLY, front (2)	73 - Y398, Y440
	39221-74	SLIDE RAIL ASSEMBLY, front (2)	74 to * - Y398, Y440
30	39222-73	SLIDE RAIL ASSEMBLY, rear (2)	73 - Y398, Y440
	39222-74	SLIDE RAIL ASSEMBLY, rear (2)	74 to * - Y398, Y440
31	39223-73	SPRING, right - front (55") (2)	73 to * - Y398, Y440
32	39224-73	SPRING, left - front (55") (2)	73 to * - Y398, Y440
33	39225-73	SPRING, right - rear (75") (2)	73 to * - Y398, Y440
34	39226-73	SPRING, left - rear (75") (2)	73 to * - Y398, Y440
35	39227-73	FRONT WHEEL (2)	73 to * - Y398, Y440
36	39228-73	REAR WHEEL	73 to * - Y398, Y440
37	39229-73	SPACER, front wheel (2)	73 to * - Y398, Y440
38	39230-73	SPACER, rear wheel (2)	73 to * - Y398, Y440
39	39231-73	SPACER, shock absorber (2)	73 to * - Y398, Y440
40	39232-73	SHOCK ABSORBER	73 to * - Y398, Y440
41	39233-73	WASHER, frame - upper, 3/8 x 1-1/2 x 1/16 (8)	73 to * - Y398, Y440
42	39234-73	BOLT, frame - upper, 3/8-18 x 1 hex. hd. (8)	73 - Y398, Y440
43	39234-74	SCREW, frame - upper, 3/8-16 x 1 ctsk. socket hd. (8)	74 to * - Y398, Y440
44	39235-73	WEAR STRIP KIT, front	73 - Y398, Y440
	39235-74	WEAR STRIP KIT, front	74 to * - Y398, Y440
45	39237-73	WEAR STRIP KIT, rear	73 to * - Y398, Y440
46	39239-74	WASHER, frame (6)	74 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.


BRAKE



BRAKE

INDEX NO.	PART NO.	NAME	USED ON
1	515	COTTER PIN, 1/16 x 1/2	71 to * - Y398, Y440
2	2752W	PINCH SCREW, No. 10-32 x 1-3/8 rd. hd.	71 to * - Y398, Y440
3	2831	SCREW, No. 6-32 x 3/8 Pozidriv hd. (2)	71 to * - Y398, Y440
4	2882W	BOLT, 5/16-18 x 5/8 hex. hd. (2)	73 to * - Y398, Y440
5	4065	BOLT, 5/16-18 x 2-3/4 hex. hd. (2)	71 to * - Y398, Y440
6	6321H	WASHER, 5/16 x 1 x 1/16	71 to * - Y398, Y440
7	7041	LOCKWASHER, 5/16 (2)	71 to * - Y398, Y440
8	7626W	LOCKNUT, No. 10-32	71 to * - Y398, Y440
9	7725	LOCKNUT, 5/16-24 (2)	71 to * - Y398, Y440
10	7728	CASTLE NUT, 5/16-24	71 to * - Y398, Y440
11	10006	CABLE STRAP, brake cable (2)	73 to * - Y398, Y440
12	11000	RETAINING RING, brake return spring pin	71 to * - Y398, Y440
13	41398-73	STOPLIGHT SWITCH	73 to * - Y398, Y440
	41403-71A	BRAKE ASSEMBLY, complete	71 to * - Y398, Y440
14	41611-71	STOP PIN, cam	71 to * - Y398, Y440
15	41612-71A	PUSH PIN, caliper (2)	71 to * - Y398, Y440
16	41613-71	SPACER, caliper to bracket bolts (4)	71 to * - Y398, Y440
17	41838-71	SPRING, brake cam	71 to * - Y398, Y440
18	41839-71	SPRING, brake return	71 & 72 - Y398
19	41839-73	SPRING, brake return	73 to * - Y398, Y440
20	41859-71	BRAKE PUCK SET	71 to * - Y398, Y440
21	41863-71	DISC, push pin	71 to * - Y398, Y440
22	41864-72	BRACKET, caliper	72 to * - Y398, Y440
23	41865-71	CALIPER, cam side	71 to * - Y398, Y440
24	41866-71	CALIPER, carrier side	71 to * - Y398, Y440
25	41867-72	CAM, brake	72 to * - Y398, Y440
26	41869-71	PIN, brake return spring	71 to * - Y398, Y440
27	45140-71B	BRAKE CABLE ASSEMBLY	71 to * - Y398, Y440
28	45164-71	NUT, brake cable (2)	71 to * - Y398, Y440
29	45176-71	CLEVIS, brake cable	71 & 72 - Y398, Y440
	56034-71B	BRAKE CONTROL ASSEMBLY, complete	71 to * - Y398, Y440
30	56039-71	CLAMP, brake control	71 to * - Y398, Y440
31	56032-74	BRAKE LEVER (chrome)	71 to * - Y398, Y440
32	56041-71	SPACER, brake lever (2)	71 to * - Y398, Y440
33	56092-71	SPACER, under brake control	71 to * - Y398, Y440

SKIS AND FRONT SUSPENSION




SKIS AND FRONT SUSPENSION

INDEX NO.	PART NO.	NAME	USED ON
1	492W	CLEVIS PIN, 1/2 x 2-9/16 lg. (2).....	71 to * - Y398, Y440
2	493W	CLEVIS PIN, 1/2 x 2-13/16 lg. (2).....	71 & 72 - Y398
3	495	CLEVIS PIN, ski - rear (2).....	74 to * - Y398, Y440
4	520W	COTTER PIN, 1/8 x 1 (4).....	72 to * - Y398, Y440
5	2271	SCREW, 5/16-18 x 3/4 Posidriv hd. (2).....	73 to * - Y398, Y440
6	2863W	BOLT, 7/16-14 x 3-1/4 hex. hd. (2).....	71 & 72 - Y398
7	2870W	BOLT, 7/16-14 x 3 hex. hd. (2).....	71 & 72 - Y398
8	4712	BOLT, 3/8-16 x 3-1/4 hex. hd. (2).....	73 to * - Y398, Y440
9	4717	BOLT, 7/16-14 x 2-1/4 hex. hd. (4).....	73 to * - Y398, Y440
10	4721	BOLT, 3/8-16 x 1-1/2 hex. hd. (4).....	71 & 72 - Y398, Y440
11	4724	BOLT, 3/8-24 x 1-1/2 hex. hd. (4).....	73 - Y398, Y440
12	6400HB	WASHER, 3/8 x 13/16 x 7/64 (2 in 1972) (4 in 1973).....	72 & 73 - Y398, Y440
13	7233	LOCKWASHER, ski handle, 5/16 cksk. external tooth (2).....	73 to * - Y398, Y440
14	7683	LOCKNUT, 1/4-28 (2).....	71 & 72 - Y398
15	7725	LOCKNUT, 5/16-24 (4).....	73 to * - Y398, Y440
16	7775	LOCKNUT, 3/8-24 (4).....	73 - Y398, Y440
17	7778	LOCKNUT, 3/8-16 (4).....	71 to * - Y398, Y440
18	7827W	LOCKNUT, 7/16-24 (4).....	71 to * - Y398, Y440
19	8482	POP RIVET, ski rubber bumper (4).....	73 - Y398, Y440
20	9160	RETAINER CLIP, spindle pad (2).....	72 & 73 - Y398, Y440
21	45304-73	SKI (black) (2).....	73 - Y398, Y440
22	45309-73	LEAF SPRING SET, less bracket (2).....	73 - Y398, Y440
23	45310-73	RUBBER BUMPER, ski - rear (2).....	73 - Y398, Y440
24	45311-73	WEAR PLATE, leaf spring - front (2).....	73 to * - Y398, Y440
25	45312-73	SKI HANDLE (2).....	73 to * - Y398, Y440
26	45316-73	WEAR ROD, ski bottom (2).....	73 to * - Y398, Y440
27	45317-73	SKI (chrome) (2).....	73 - Y398, Y440
28	45317-74	SKI (chrome) (2).....	74 to * - Y398, Y440
29	45320-73	BRACKET, leaf spring to shock absorber - right.....	73 - Y398, Y440
30	45323-73	BRACKET, leaf spring to shock absorber - left.....	73 - Y398, Y440
31	45324-74	LEAF SPRING WITH BRACKET, left.....	74 to * - Y398, Y440
32	45325-74	LEAF SPRING WITH BRACKET, right.....	74 to * - Y398, Y440
33	45326-74	RUBBER BUMPER, leaf center (2).....	74 to * - Y398, Y440
34	45332-74	DAMPER PLATE, spindle pad (2).....	74 to * - Y398, Y440
35	45553-71	WEAR PLATE, leaf spring - front (2).....	71 & 72 - Y398
36	45554-71	RUBBER BUMPER, main leaf (2).....	71 & 72 - Y398
37	45563-71	BRACKET, leaf spring to shock absorber (2).....	72 & 73 - Y398, Y440
38	45565-72	SKI (black) (2).....	71 & 72 - Y398
39	45570-72	SKI (chrome) (2).....	72 - Y398
40	45578-71	WEAR ROD, ski bottom (2).....	71 & 72 - Y398
41	45579-71	SPINDLE PAD (2).....	71 to 73 - Y398, Y440
42	45579-74	SPINDLE PAD (2).....	74 to * - Y398, Y440
43	54496-72	SHOCK ABSORBER, only (chrome) (2).....	74 to * - Y398, Y440
44	54496-72	SHOCK ABSORBER, with spacers (chrome).....	72 & 73 - Y398, Y440
45	54496-72	SHOCK ABSORBER, with spacers (black).....	71 to 73 - Y398, Y440
46	54519-72	SPACER, shock absorber (thin) (4).....	72 & 73 - Y398, Y440
47	54520-72	SPACER, shock absorber (thick) (4).....	72 & 73 - Y398, Y440
48	88126-71	LEAF SPRING SET, less bracket (2).....	71 & 72 - Y398

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.

FRAME, ENGINE MOUNTING, SEAT AND BUMPERS **1973 & EARLIER**




FRAME, ENGINE MOUNTING, SEAT AND BUMPERS - 1973 & EARLIER

INDEX NO.	PART NO.	NAME	USED ON
1	2851	BOLT, 3/8-16 x 7/8 hex. hd. (4)	72 & 73 - Y398, Y440
2	3420	SCREW, No. 6-32 x 7/8 slotted hex. hd. (2)	72 - Y398
3	3738	BOLT, 1/4-28 x 5/8 hex. hd. (4)	71 to 73 - Y398, Y440
4	3776W	BOLT, 7/16-14 x 2-1/4 hex. hd. (2)	72 & 73 - Y398, Y440
5	3777W	BOLT, 7/16-14 x 3-1/2 hex. hd. (2)	72 & 73 - Y398, Y440
6	4713W	BOLT, 3/8-16 x 3/4 hex. hd. (4)	72 & 73 - Y398, Y440
7	5451W	CARRIAGE BOLT, 3/8-16 x 1-3/4	71 & 72 - Y398
8	5452	CARRIAGE BOLT, 3/8-24 x 1-1/2 (4)	73 - Y398, Y440
9	5972W	SPACER, front bumper (6)	71 to 73 - Y398, Y440
10	5980	SPACER, engine mounting - rear (2 inch) (2)	72 & 73 - Y398, Y440

FRAME, ENGINE MOUNTING, SEAT AND BUMPERS - 1973 & EARLIER (CONT'D)

INDEX NO.	PART NO.	NAME	USED ON
11	5981	SPACER, engine mounting - front (1 inch) (2)	72 & 73 - Y398, Y440
12	6253W	WASHER, 1/4 x 3/4 x 1/16 (8)	72 & 73 - Y398, Y440
13	6415W	WASHER, 3/8 x 1-1/8 x 3/32 (8)	72 & 73 - Y398, Y440
14	6417W	WASHER, 3/8 x 1-1/4 x 1/8 (4)	71 to 73 - Y398, Y440
15	6419	WASHER, 9/16 x 1-3/16 x 5/32 (4)	73 - Y398, Y440
16	6516HW	WASHER, 7/16 x 1-1/8 x 1/16 (4)	71 to 73 - Y398, Y440
17	6701	WASHER, 3/8 x 13/16 x 1/16 (2)	71 to 73 - Y398, Y440
18	6911W	WASHER, 3/16 x 11/16 x 1/16 (2)	72 - Y398
19	7036	LOCKWASHER, 1/4 (2)	71 to 73 - Y398, Y440
20	7045	LOCKWASHER, 3/8 (6)	71 to 73 - Y398, Y440
21	7207W	LOCKWASHER, 3/8 (4)	72 & 73 - Y398, Y440
22	7626W	LOCKNUT, No. 10-32 (4)	72 - Y398
23	7683	LOCKNUT, 1/4-28 (8)	71 to 73 - Y398, Y440
24	7778	LOCKNUT, 3/8-16 (4)	71 & 72 - Y398
25	7780	LOCKNUT, 3/8-24 (4)	73 - Y398, Y440
26	8490	POP RIVET, seat frame stud (12)	72 & 73 - Y398, Y440
27	8528W	POP RIVET, hood catch (4)	71 to 73 - Y398, Y440
28	8690	POP RIVET, seat frame stud - front (4)	72 - Y398
29	16221-72	LOCKPLATE, side brace (2)	72 & 73 - Y398, Y440
30	30064-65	WASHER, seat frame stud (4)	73 - Y398, Y440
31	44903-71A	FRONT BUMPER, right	71 to 73 - Y398, Y440
32	44905-71A	FRONT BUMPER, left	71 to 73 - Y398, Y440
33	44910-71A	CENTER COVER, front bumper	71 to 73 - Y398, Y440
34	44920-71	REAR BUMPER, left	71 & 72 - Y398
35	44920-73	REAR BUMPER, left	73 - Y398, Y440
36	44921-71	REAR BUMPER, right	71 & 72 - Y398
37	44921-73	REAR BUMPER, right	73 - Y398, Y440
38	44926-73	RUBBER SPACER, front bumper - sides (2)	73 - Y398, Y440
39	47021-73	FRAME, with bushings	73 - Y440
40	47026-72	FRAME, with bushings	72 - Y398
41	47026-73	FRAME, with bushings	73 - Y398
42	47076-72	FRAME STUD, seat fastener eyelet (18)	72 & 73 - Y398, Y440
43	47080-72	STUD, snow flap (4)	72 - Y398
44	47080-73	STUD, seat & snow flap mounting - rear (6)	73 - Y398, Y440
45	47231-72	SIDEBRACE, engine mounting (2)	72 & 73 - Y398, Y440
46	47233-72	CROSSBRACE, engine mounting - rear	72 - Y398
47	47233-73	CROSSBRACE, engine mounting - rear	73 - Y398, Y440
48	47246-71	CROSSBRACE, engine mounting - front	71 & 72 - Y398
49	47246-73	CROSSBRACE, engine mounting - front	73 - Y398, Y440
50	47280-71A	NUT, engine crossbrace to frame (large) (4)	71 & 72 - Y398
51	47280-73	NUT, engine crossbrace to frame (large) (4)	73 - Y398, Y440
52	47303-71	FLANGED BUSHING, spindle (4)	71 to 73 - Y398, Y440
53	47364-71	HOOD GUIDE (6)	71 to Early 72 - Y398
54	47366-72	HOOD GUIDE, left	Late 72 to 73 - Y398, Y440
55	47367-72	HOOD GUIDE, right	Late 72 to 73 - Y398, Y440
56	47411-71	FOOT PAD (2)	71 to 73 - Y398, Y440
57	52021-71A	SEAT	71 & 72 - Y398
58	52021-73	SEAT	73 - Y398, Y440
59	52066-71A	SEAT COVER	71 to 73 - Y398, Y440
60	53231-71	HOOD CATCH (2)	71 to 73 - Y398, Y440
61	59255-72	REFLECTOR, red (3)	73 - Y398, Y440
62	59300-72	BRACKET, snow flap (2)	72 & 73 - Y398, Y440
63	59301-72	SNOW FLAP	72 - Y398
64	59301-73	SNOW FLAP	73 - Y398, Y440
65	60031-61	NUT, snow flap (2)	72 - Y398
66	61169-72	DECAL, frame side - rear - "No. 1" (2)	72 - Y398
67	61169-73	DECAL, frame side - rear - "No. 1" (2)	73 - Y398, Y440
68	61544-71	BRACKET, fuel tank strap	71 to 73 - Y398, Y440
69	89104-72	TONGUE, hitch pin	73 - Y398, Y440
70	89105-72	HITCH PIN	73 - Y398, Y440
71	89105-72	RETAINING RING, hitch pin (2)	73 - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




FRAME, ENGINE MOUNTING, SEAT AND BUMPERS—1974 & LATER

FRAME, ENGINE MOUNTING, SEAT AND BUMPERS — 1974 & LATER

INDEX NO.	PART NO.	NAME	USED ON
1	2820	BOLT, 5/8-16 x 5/8 hex. hd. (2)	74 to * — Y398, Y440
2	2851	BOLT, 3/8-16 x 7/8 hex. hd. (4)	74 to * — Y398, Y440
3	3560W	SCREW, No. 10 x 1/2 self tapping hex. hd. (4)	74 to * — Y398, Y440
4	3738	BOLT, 1/4-28 x 5/8 hex. hd. (2)	74 to * — Y398, Y440
5	3776W	BOLT, 7/16-14 x 2-1/4 hex. hd. (2)	74 to * — Y398, Y440
6	3777W	BOLT, 7/16-14 x 3-1/2 hex. hd. (2)	74 to * — Y398, Y440
7	3825	BOLT, 1/4-28 x 1 hex. hd. (5)	74 to * — Y398, Y440
8	3960W	BOLT, 5/16-24 x 1 hex. hd. (4)	74 to * — Y398, Y440
9	3990	BOLT, 5/16-24 x 7/8 hex. hd. (7)	74 to * — Y398, Y440
10	4713W	BOLT, 3/8-16 x 3/4 hex. hd. (6)	74 to * — Y398, Y440
11	5380	SPACER, engine mounting — rear (2)	74 to * — Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




HOOD AND WINDSHIELD

HOOD AND WINDSHIELD

INDEX NO.	PART NO.	NAME	USED ON
1	2665	SCREW, No. 10-24 x 5/8 Pozidriv hd. (7 or 11)	73 to * - Y398, Y440
2	2697W	SCREW, No. 10-24 x 1/2 Phillips hd. (6)	72 - Y398
3	6165W	WASHER, 3/16 x 3/8 x 1/32 (2)	72 to * - Y398, Y440
4	6187W	WASHER, No. 10 x 9/16 x 1/16 (6 or 10)	72 - Y398
5	6716	WASHER, 3/16 x 1/2 x 1/16 (14 or 22)	73 to * - Y398, Y440
6	7613A	SPEED NUT (4)	72 - Y398
7	7624	LOCKNUT, No. 10-24 (7 or 11)	73 to * - Y398, Y440
8	8133W	SPEEDNUT (2)	73 to * - Y398, Y440
9	8687	POP RIVET (10)	71 to * - Y398, Y440
10	53200-71	HOOD, with trim - white	71 & 72 - Y398
	53200-73	HOOD, with trim - white	73 to * - Y398, Y440
	53201-73	HOOD, with trim - black	73 to * - Y440
11	53206-72	TRIM PLATE, hood latch (2)	72 to * - Y398, Y440
12	53207-72	HOOD CATCH, front	72 to * - Y398, Y440
13	53221-73	NAMEPLATE - "398 cc"	73 to * - Y398
	53222-73	NAMEPLATE - "440 cc"	73 to * - Y440
14	53223-73	HOOD TRIM, right - red (silver outline)	73 to * - Y440
15	53224-73	HOOD TRIM, left - red (silver outline)	73 to * - Y440
16	53225-73	HOOD TRIM, left - white & blue (silver outline)	73 to * - Y440
17	53226-73	HOOD TRIM, right - white & blue (silver outline)	73 to * - Y440
18	53230-71	LATCH, hood (2)	71 to * - Y398, Y440
19	53247-73	HOOD TRIM, right - white & blue (black outline)	72 to * - Y398
20	53248-73	HOOD TRIM, right - red (black outline)	72 to * - Y398
21	53249-73	HOOD TRIM, left - white & blue (black outline)	72 to * - Y398
22	53250-73	HOOD TRIM, left - red (black outline)	72 to * - Y398
	53258-74	FOAM, hood - upper center	74 to * - Y398, Y440
	53259-74	FOAM, hood - lower center	74 to * - Y398, Y440
	53260-74	FOAM, hood - right	74 to * - Y398, Y440
	53261-74	FOAM, hood - left	74 to * - Y398, Y440
23	57997-73	WINDSHIELD, large	73 to * - Y398, Y440
24	58000-72	WINDSHIELD, small	72 - Y398
25	58000-73	WINDSHIELD, small	73 to * - Y398, Y440
26	58010-72	WINDSHIELD KIT, large	72 - Y398
27	61121-71A	RUBBER GASKET, tank pipe	71 to * - Y398, Y440
28	67718-60	SCREW (4)	72 - Y398

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




STEERING—1973 & EARLIER

STEERING - 1973 & EARLIER

INDEX NO.	PART NO.	NAME	USED ON
1	514W	COTTER PIN, 3/16 x 1-3/4.....	71 to 73 - Y398, Y440
2	2825W	SCREW, 1/4-20 x 1 socket hd. (4).....	71 & 72 - Y398
3	2829	SCREW, 1/4-20 x 1-1/4 socket hd. (2).....	73 - Y398, Y440
4	2869W	BOLT, 7/16-14 x 3-1/4 hex. hd.....	71 to 73 - Y398
5	4088	BOLT, 1/2-13 x 3-1/2 hex. hd. (2).....	72 - Y398
6	4089	BOLT, 1/2-20 x 3-1/4 hex. hd. (2).....	73 - Y398, Y440
8	4719W	BOLT, 3/8-16 x 2-1/2 hex. hd. (2).....	71 to 73 - Y398, Y440
9	4721	BOLT, 3/8-16 x 1-1/2 hex. hd. (2).....	71 to 73 - Y398, Y440
10	4722	BOLT, 3/8-16 x 2-1/4 hex. hd. (2).....	71 to 73 - Y398, Y440
11	5421W	CARRIAGE BOLT, 3/8-16 x 2-1/2.....	71 to 73 - Y398, Y440
12	5984	SPACER, 1-1/2 in. lg.....	71 to 73 - Y398, Y440
13	6400HB	WASHER, 3/8 x 13/16 x 7/64 (2).....	72 & 73 - Y398, Y440
14	6584B	WASHER, 1/2 x 1 x 1/32.....	72 - Y398
15	6607W	WASHER, 3/8 x 7/8 x 3/16 (4).....	71 to 73 - Y398, Y440
16	6860	WASHER, 1 x 2 x 1/8.....	71 to 73 - Y398, Y440
17	7572W	NUT, 1/2-20.....	72 - Y398
18	7686	LOCKNUT, 1/4-20 (4).....	71 to 73 - Y398, Y440
19	7725	LOCKNUT, 5/16-24 (4).....	73 - Y398, Y440
20	7741	LOCKNUT, 1/2-20.....	73 - Y398, Y440
21	7768W	LOCKNUT, 1/2-13 (2).....	72 - Y398
22	7778	LOCKNUT, 3/8-16 (7).....	71 to 73 - Y398, Y440
23	7827W	LOCKNUT, 7/16-14.....	71 to 73 - Y398, Y440
24	7849W	JAM NUT, 3/8-24 (2).....	71 to 73 - Y398, Y440
25	7851W	JAM NUT, 3/8-24 (2).....	71 to 73 - Y398, Y440
26	45560-71	SPINDLE (2).....	71 to 73 - Y398, Y440
27	45565-71	BUSHING, steering column support.....	71 to 73 - Y398, Y440
28	45603-71A	TIE ROD END, outer R.H. threads (2).....	71 to 73 - Y398, Y440
29	45604-71A	TIE ROD END, inner L.H. threads (2).....	71 to 73 - Y398, Y440
30	47303-71	FLANGED BUSHING, spindle (4).....	71 to 73 - Y398, Y440
31	54503-71	SHOCK ABSORBER, steering.....	71 to 73 - Y398, Y440
32	56019-71	HANDLEBAR, bare.....	71 to 73 - Y398, Y440
33	56107-73	CLAMP, handlebar.....	73 - Y398, Y440
34	56109-71	CAP, handlebar to steering column clamp (black).....	71 & 72 - Y398
35	56111-72	CLAMP, handlebar to steering column (black).....	71 & 72 - Y398
36	56112-72	CLAMP, handlebar to steering column (chrome).....	71 & 72 - Y398
37	56113-72	CAP, handlebar to steering column clamp (chrome).....	71 & 72 - Y398
38	56228-72	PAIR OF HANDLEBAR GRIPS (2).....	72 & 73 - Y398, Y440
39	57028-72	STEERING COLUMN.....	72 - Y398
40	57028-73	STEERING COLUMN.....	73 - Y398, Y440
41	57034-71	SPACER, tie rod ends (8).....	71 to 73 - Y398, Y440
42	57036-71B	TIE ROD (2).....	71 to 73 - Y398, Y440
43	57040-71	SPINDLE ARM (2).....	71 to 73 - Y398, Y440
44	57045-71A	SUPPORT SLEEVE, steering column - upper.....	71 to 73 - Y398, Y440
45	57061-73	BUSHING, steering column upper support sleeve (2).....	73 - Y398, Y440
46	57064-73	U-BOLT, handlebar clamp (2).....	73 - Y398, Y440
47	57069-71	U-BOLT, steering column (2).....	71 to 73 - Y398, Y440
48	57089-71	SPACER, tie rod to spindle arm - long (2).....	71 to 73 - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




STEERING—1974 & LATER

STEERING - 1974 & LATER

INDEX NO.	PART NO.	NAME	USED ON
1	716	PLUG, 1/8-27 (2)	74 to * - Y398, Y440
2	2634	BOLT, 1/4-28 x 2 hex. hd. (2)	74 to * - Y398, Y440
3	2635	BOLT, 1/4-28 x 2-1/4 hex. hd.	74 to * - Y398, Y440
4	2821	BOLT, 1/4-20 x 2-1/4 hex. hd. (2)	74 to * - Y398, Y440
5	3825	BOLT, 1/4-28 x 1 hex. hd. (5)	74 to * - Y398, Y440
6	4089	BOLT, 1/2-20 x 3-1/4 hex. hd. (2)	74 to * - Y398, Y440
7	4722	BOLT, 3/8-16 x 2-1/4 hex. hd. (2)	74 to * - Y398, Y440
8	6607W	WASHER, 3/8 x 7/8 x 3/16 (4)	74 to * - Y398, Y440
9	6663HB	WASHER, 5/16 x 1-1/8 x 1/16 (4)	74 to * - Y398, Y440
10	6703	WASHER, 1/4 x 5/8 x 1/16 (6)	74 to * - Y398, Y440
11	7683	LOCKNUT, 1/4-28 x 5/16 x 7/16 hex (8)	74 to * - Y398, Y440
12	7686	LOCKNUT, 1/4-20 (6)	74 to * - Y398, Y440
13	7725	LOCKNUT, 5/16-24 (4)	74 to * - Y398, Y440
14	7741	LOCKNUT, 1/2-20 (2)	74 to * - Y398, Y440
15	7778	LOCKNUT, 3/8-16 (6)	74 to * - Y398, Y440
16	7849W	JAM NUT, 3/8-24 L. H. thread (2)	74 to * - Y398, Y440
17	7851W	JAM NUT, 3/8-24 R. H. thread (2)	74 to * - Y398, Y440
18	36392-74	SPRING, steering damper	74 to * - Y398, Y440
19	45560-74	SPINDLE (2)	74 to * - Y398, Y440
20	45565-74	BUSHING, steering column support	74 to * - Y398, Y440
21	45603-71A	TIE ROD END, outer - R. H. thread (2)	74 to * - Y398, Y440
22	45604-71A	TIE ROD END, inner - L. H. thread (2)	74 to * - Y398, Y440
23	47303-74	FLANGED BUSHING, spindle (4)	74 to * - Y398, Y440
24	56019-71	HANDLEBAR	74 to * - Y398, Y440
25	56107-74	CLAMP, handlebar	74 to * - Y398, Y440
26	56226-74	HANDLEBAR GRIP (2)	74 to * - Y398, Y440
27	56900-74	BRACKET, steering column	74 to * - Y398, Y440
28	57036-71B	TIE ROD (2)	74 to * - Y398, Y440
29	57040-74	SPINDLE ARM (2)	74 to * - Y398, Y440
30	57042-74	STEERING ARM, steering column	74 to * - Y398, Y440
31	57045-71A	SUPPORT SLEEVE, steering column - upper	74 to * - Y398, Y440
32	57051-73	BUSHING, steering column upper support sleeve (2)	74 to * - Y398, Y440
33	57054-73	U-BOLT, handlebar clamp (2)	74 to * - Y398, Y440
34	57069-71	U-BOLT, steering column (2)	74 to * - Y398, Y440
35	57106-74	STEERING COLUMN	74 to * - Y398, Y440
36	57107-74	SLEEVE, steering column	74 to * - Y398, Y440
37	57108-74	DAMPER PLATE, fixed	74 to * - Y398, Y440
38	57110-74	DAMPER PLATE, rotating	74 to * - Y398, Y440
39	57112-74	ADJUSTER, spring	74 to * - Y398, Y440
40	57113-74	SLEEVE, steering column (threaded)	74 to * - Y398, Y440
41	57114-74	RETAINER, spring adjuster	74 to * - Y398, Y440


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



FUEL TANK

INDEX NO.	PART NO.	NAME	USED ON
1	2073W	SCREW, No. 4-40 self-tapping rd. hd.	71 to 73 - Y398, Y440
2	3738	BOLT, 1/4-28 x 5/8 hex. hd. (2)	71 to 73 - Y398, Y440
3	4410	BOLT, 1/4-28 x 7/8 hex. hd. (2)	74 to * - Y398, Y440
4	6260	WASHER, 2-1/8 x 3-1/2 x 1/16	72 - Y398
5	7036	LOCKWASHER, 1/4 (2)	71 to 73 - Y398, Y440
6	7683	LOCKNUT, 1/4-28 x 5/16 x 7/16 hex.	74 to * - Y398, Y440
7	8491	POP RIVET, hose clamp	74 to * - Y398, Y440
8	9093	WIRE HOSE CLAMP, carburetor end (2 or 4)	71 to * - Y398, Y440
9	9996	HOSE CLAMP, in fuel tank (2)	72 to * - Y398, Y440
10	10006	STRAP, fuel line - black plastic	71 to 73 - Y398, Y440
11	10014	BAND HOSE CLAMP, tank end (2)	71 to 73 - Y398, Y440
12	10022	HOSE CLAMP, gas lines	72 to * - Y398, Y440
13	11068	RETAINING RING, fuel tank strap pin (4)	74 to * - Y398, Y440
14	61099-71A	HOSE JUNCTION, fuel tank	71 to * - Y398, Y440
15	61105-74	VENT, fuel tank	74 to * - Y398, Y440
16	61108-73	CAP, fuel tank - with fuel gage	73 - Y398, Y440
17	61108-74	CAP, fuel tank - with fuel gage	74 to * - Y398, Y440
18	61117-71	GASKET, fuel tank cap	71 to * - Y398, Y440
19	61118-72	NUT, fuel tank cap dip stick	72 - Y398
20	61119-72	DIP STICK, fuel tank cap	72 - Y398
21	61123-71	CAP, fuel tank - with nut & dipstick	71 & 72 - Y398
22	61250-71	FUEL TANK	71 to 73 - Y398, Y440
23	61250-74	FUEL TANK	74 to * - Y398, Y440
24	61256-74	STRAP, fuel tank (2)	74 to * - Y398, Y440
25	61542-71	STRAP, fuel tank	71 & 72 - Y398
26	61542-73	STRAP, fuel tank	73 - Y398, Y440
27	61544-71	BRACKET, fuel tank strap	71 to 73 - Y398, Y440
28	61554-71	GASKET, fuel tank outlet	71 to * - Y398
29	61632-71	PAD, fuel tank - bottom (4 or 5)	71 to 73 - Y398, Y440
30	61632-74	PAD, fuel tank - upper & lower rear (6)	74 to * - Y398, Y440
31	61633-71	PAD, fuel tank - sides (4)	71 to 73 - Y398, Y440
32	61633-74	PAD, fuel tank - lower front (6)	74 to * - Y398, Y440
33	61637-74	PIN, fuel tank strap (2)	74 to * - Y398, Y440
34	61640-74	EYE BOLT, fuel tank strap (2)	74 to * - Y398, Y440
35	61784-71	LUBRICATION LABEL	71 to 73 - Y398
36	61789-73	LUBRICATION LABEL	73 - Y440
37	61789-74	LUBRICATION LABEL	74 to * - Y398, Y440
38	62349-71B	FUEL FILTER, in fuel tank	71 to * - Y398, Y440
39	62366-71A	FUEL HOSE, in fuel tank	71 to * - Y398, Y440
40	63501-68	HOSE, 1/4 I.D. x 1/2 O.D., fabric reinforced rubber, 25 ft. lg.	71 to * - Y398, Y440
41	63578-74	HOSE, fuel tank to carburetor - feed (red)	74 to * - Y398, Y440
42	63583-73	CONDUIT, fuel hoses	74 to * - Y398, Y440
	99801-SN	50/1 SNO-OIL, case 24 quarts	71 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




EXHAUST SYSTEM—1973 & EARLIER Y398

EXHAUST SYSTEM - 1973 & EARLIER Y398

INDEX NO.	PART NO.	N A M E	USED ON
1	4716W	BOLT, 3/8-16 x 1-1/4 hex. hd.	71 & 72 - Y398
2	7041	LOCKWASHER, 5/16 (4)	71 to 73 - Y398
3	7756P	NUT, 8 mm. (4)	71 to 73 - Y398
4	7778	LOCKNUT, 3/8-16	71 & 72 - Y398
5	16220-71	CLAMP, flexible muffler pipe	71 & 72 - Y398
6	27055-71	STUD, exhaust pipe (4)	71 & 72 - Y398
7	27055-72	STUD, exhaust pipe (4)	Last 100 in 72 to 73 - Y398
8	41839-71	SPRING, muffler pipe to frame	73 - Y398
9	65225-71	MUFFLER	71 & 72 - Y398
10	65225-73	MUFFLER	73 - Y398
11	65380-73	MUFFLER PIPE, flexible	73 - Y398
12	65434-71	MUFFLER PIPE, flexible	71 & 72 - Y398
13	65437-71	EXHAUST PIPE, left cylinder	71 to 73 - Y398
14	65438-71	EXHAUST PIPE, right cylinder	71 to 73 - Y398
15	65472-71A	FLANGE, exhaust pipe to cylinder (2)	71 to 73 - Y398
16	65829-71	GASKET, exhaust pipe to cylinder (2)	71 to 73 - Y398


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



EXHAUST SYSTEM
1973 & LATER Y440 - 1974 & LATER Y398

EXHAUST SYSTEM - 1973 & LATER Y440; 1974 & LATER Y398

INDEX NO.	PART NO.	N A M E	U S E D O N
1	2791W	SCREW, 1/4-20 x 1-5/16 rd. hd. (2)	73 to * - Y440; 74 to * - Y398
2	3787	BOLT, 1/4-20 x 3/4 hex. hd.	73 - Y440
3	6240B	WASHER, 1/4 x 9/16 x 1/16	73 - Y440
4	6253W	WASHER, 1/4 x 3/4 x 1/16 (4)	73 to * - Y440; 74 to * - Y398
	6314W	WASHER, 5/16 x 9/16 x 1/8 (2) (replaces muffler under manual starter housing)	Early 73 - Y440 (Below 9C-10203-H3)
5	7041	LOCKWASHER, 5/16 (4)	73 to * - Y440; 74 to * - Y398
6	7688	NUT, 1/4-20 x 7/32 x 7/16 (2)	73 to * - Y440; 74 to * - Y398
7	7742	LOCKNUT, 1/4-20 x 7/32 x 7/16 hex. (4)	73 to * - Y440; 74 to * - Y398
8	7756P	NUT, 8 mm. (4)	73 to * - Y440; 74 to * - Y398
9	8490	POP RIVET (2)	73 to * - Y440; 74 to * - Y398
10	27055-72	STUD, exhaust pipe (4)	73 to * - Y440; 74 to * - Y398
11	40509-63	SPRING (2)	73 to * - Y440; 74 to * - Y398
12	65289-73	MUFFLER	73 to * - Y440; 74 to * - Y398
13	65391-73	PAD, muffler clamp (2)	73 to * - Y440; 74 to * - Y398
14	65392-73	MOUNTING PLATE (1 in 73 - 2 in 74)	73 to * - Y440; 74 to * - Y398
15	65393-73	CLAMP, muffler (2)	73 to * - Y440; 74 to * - Y398
16	65427-73	DISC, muffler outlet	73 to * - Y440; 74 to * - Y398
17	65429-73	SEAL, muffler outlet	73 to * - Y440; 74 to * - Y398
18	65436-73	EXHAUST MANIFOLD	73 to * - Y440; 74 to * - Y398
19	65468-73	MOUNTING PLATE	73 - Y440
	65600-73	MUFFLER CONVERSION KIT	Early 73 - Y440 (Below 9C-10203-H3)
	65829-71	GASKET, exhaust pipe to cylinder (2)	73 to * - Y440; 74 to * - Y398
21	65831-61P	GASKET, exhaust manifold (2)	73 to * - Y440; 74 to * - Y398




BATTERY AND BOX

BATTERY AND BOX

INDEX NO.	PART NO.	NAME	USED ON
1	6165W	WASHER, 3/16 x 3/8 x 1/32 (2).....	72 - Y398
2	7710W	LOCKNUT, 5/16-18 (4).....	71 to 73 - Y398, Y440
3	8506W	RIVET, box lock (2).....	72 - Y398
4	8507W	RIVET, box lock and latch (4).....	73 - Y398, Y440
5	8527B	RIVET, hinge (10).....	71 & 72 - Y398
5A	8528W	POP RIVET (6).....	74 to * - Y398, Y440
6	8693	POP RIVET, latch (4).....	72 - Y398
7	53231-71	LOCK.....	72 - Y398
8	53231-73	LOCK.....	73 - Y398, Y440
9	65999-74	BATTERY - 12 V.....	74 to * - Y398, Y440
10	66000-71	BATTERY - 12 V.....	71 to 73 - Y398, Y440
11	66049-72	WING NUT, positive battery terminal.....	71 to 73 - Y398, Y440
12	66050-72	WING NUT, negative battery terminal.....	71 to 73 - Y398, Y440
13	66054-72	FILLER CAP, battery (6).....	71 to 73 - Y398, Y440
14	66181-74	STRAP, battery mounting.....	74 to * - Y398, Y440
15	66182-74	CLIP, battery mounting strap.....	74 to * - Y398, Y440
16	66201-72A	BATTERY BOX, complete with cover.....	72 & 73 - Y398, Y440
17	66221-71	DECAL, caution/for your safety.....	71 to 73 - Y398, Y440
18	66233-72	LOCKPLATE, under lock.....	72 - Y398
19	66234-72	PLATE, mounting (2).....	72 & 73 - Y398, Y440
20	66235-72	BACKING PLATE, latch (2).....	72 & 73 - Y398, Y440
21	66256-74	CLIP, battery hold-down.....	74 to * - Y398, Y440
22	66265-71	HINGE, battery box and carry-all case.....	71 & 72 - Y398
23	66354-71	PAD, battery - bottom.....	71 to 73 - Y398, Y440
24	66355-71	CUSHION, battery box cover.....	71 to 73 - Y398, Y440
25	66363-73	BACKING PLATE, latch.....	73 - Y398, Y440
26	66376-72	COVER.....	72 - Y398
27	66380-72	LATCH (2).....	72 & 73 - Y398, Y440
28	66382-73P	STRAP, battery hold-down.....	74 to * - Y398, Y440


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



ELECTRICAL COMPONENTS

INDEX NO.	PART NO.	NAME	USED ON
1	1207W	SCREW, No. 10-24 x 5/8 fil. hd. (4)	71 to * - Y398, Y440
2	2633	SCREW, No. 8-32 x 3/8 self-tapping rd. hd. (2)	72 to * - Y398, Y440
3	2646	SCREW, No. 8-32 x 3/4 Pozidriv hd.	71 to * - Y398, Y440
4	2661W	SCREW, No. 10-24 x 1/2 self-tapping Phil. hd. (7)	71 to * - Y398, Y440
4A	6716	WASHER, spark coil bracket, 3/16 x 1/2 x 1/16 (4)	73 to * - Y398, Y440
4B	7069	LOCKWASHER, circuit breaker, No. 10 (2)	74 to * - Y398, Y440
5	7115	LOCKWASHER, No. 8 internal tooth	71 to * - Y398, Y440
6	7118	LOCKWASHER, No. 10 internal tooth	72 to * - Y398, Y440
7	7608	NUT, No. 8-32	71 to * - Y398, Y440
8	7609W	LOCKNUT, No. 8-32	72 - Y398
9	7624	LOCKNUT, No. 10-24 (4)	71 to * - Y398, Y440
9A	7638	NUT, circuit breaker, No. 10-32 x 1/8 x 3/8 hex. (2)	74 to * - Y398, Y440
10	9914	WIRE TERMINAL, female spade type - 1/4 slot (2)	71 to * - Y398, Y440
11	9925	WIRE TERMINAL, female flag type - 1/4 slot - #16-18 wire (2)	71 to * - Y398, Y440
11A	9952	CLIP, circuit breaker	74 to * - Y398, Y440
12	11424	GROMMET, stator to ignition module wire	72 to * - Y398, Y440
13	20018-72	CAUTION LABEL	72 - Y398
13A	31607-64	RUBBER CAP, spark plug wire (2)	71 to * - Y398, Y440
14	31608-71	SPARK COIL (2)	71 to * - Y398, Y440
15	31611-65P	BRACKET, spark coil (2)	71 & 72 - Y398
	31619-73	BRACKET, spark coil (2)	73 to * - Y398, Y440
16	31971-71	SPARK PLUG CABLE (2)	71 to * - Y398, Y440
17	32308-71	SPARK PLUG (2)	71 to * - Y398, Y440
18	32343-72	SLEEVE, spark plug (2)	71 to * - Y398, Y440
19	32728-71	CAPACITOR	71 to 73 - Y398, Y440
	32728-74	CAPACITOR, w/o wire terminal	74 to * - Y398, Y440
20	70584-69	INSULATOR, flag terminal (2)	71 to * - Y398, Y440
21	70589-69	INSULATOR, straight terminal (2)	71 to * - Y398, Y440
22	71497-72A	IGNITION MODULE	72 to * - Y398, Y440
23	71537-72	CONNECTOR PLUG, with wires - ignition module	72 to * - Y398, Y440
24	71731-71	RECTIFIER (2 black wires)	71 to * - Y398, Y440
25	72034-71	CONNECTOR, double socket - regulator	71 to * - Y398, Y440
26	72035-71	CONNECTOR, double pin - rectifier	71 to * - Y398, Y440
27	72038-71	SOCKET, wire ends (11)	71 to * - Y398, Y440
28	72039-71	PIN, wire ends (11)	71 to * - Y398, Y440
29	72040-71	CONNECTOR, triple socket - diode	71 to * - Y398, Y440
30	72043-71	CONNECTOR, single pin - diode	71 to * - Y398, Y440
31	74502-71	REGULATOR (black & red wire)	71 to * - Y398, Y440
32	74588-72	CIRCUIT BREAKER	72 to * - Y398, Y440
	74589-73	CIRCUIT BREAKER	74 to * - Y398, Y440
33	74852-71	DIODE (black, blue & white wires)	71 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




**HEAD LAMP AND TAIL LAMP
1971 & 1972**

HEADLAMP AND TAIL LAMP - 1971 & 1972

INDEX NO.	PART NO.	NAME	USED ON
1	1190W	SCREW, No. 10-32 x 3/8 rd. hd. (6).....	71 & 72 - Y398
2	1199B	SCREW, No. 10-24 x 1/2 fil. hd. (3).....	71 & 72 - Y398
3	2637	SCREW, No. 4-24 x 3/8 Phillips hd. (4).....	71 & 72 - Y398
4	2806	SCREW, No. 6-32 x 3/4 Pozidriv hd. (4).....	71 & 72 - Y398
5	6075W	WASHER, No. 6 x 5/16 x 1/32 (4).....	71 & 72 - Y398
6	6165W	WASHER, 3/16 x 3/8 x 1/32 (5).....	71 & 72 - Y398
7	7220	LOCKWASHER, No. 10 external tooth (7).....	71 & 72 - Y398
8	8094	POP RIVET, headlamp cover grill (5).....	71 & 72 - Y398
9	10006	STRAP, headlamp bracket (2).....	71 & 72 - Y398
10	11410	GROMMET, headlamp bracket (3).....	71 & 72 - Y398
11	47077-71	O-RING, headlamp seal (2).....	71 & 72 - Y398
12	52118-71	BACKING PLATE, tail lamp housing.....	71 & 72 - Y398
13	53214-71	COVER GRILLE, headlamp.....	71 & 72 - Y398
14	53232-71	CLAMP.....	71 & 72 - Y398
15	60031-61	NUT, tail lamp housing (4).....	71 & 72 - Y398
16	67701-71	HEADLAMP - 35 watt - 12 V. (2).....	71 & 72 - Y398
17	67718-71	SUPPORT, headlamp.....	71 & 72 - Y398
18	67722-71	BRACKET, headlamp.....	71 & 72 - Y398
19	67723-71	BRACKET, headlamp back (2).....	71 & 72 - Y398
20	67727-71	NUT, headlamp support (2).....	71 & 72 - Y398
21	67728-71	SPRING, headlamp support (4).....	71 & 72 - Y398
22	68014-71	HOUSING, tail lamp (2).....	71 & 72 - Y398
23	68090-71	LENS, tail lamp (2).....	71 & 72 - Y398
24	68462-64	BULB, tail lamp (2).....	71 & 72 - Y398
25	70373-71	WIRING HARNESS, tail lamp.....	71 & 72 - Y398
26	70576-68	WIRE CONNECTOR (2).....	72 - Y398


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



HEADLAMP AND TAIL LAMP - 1973 & LATER

INDEX NO.	PART NO.	NAME	USED ON
1	1176	SCREW, No. 8-16 x 3/4 self tapping Phillips hd. (3)	73 to * - Y398, Y440
2	1177	SCREW, No. 8-16 x 1/2 self tapping Phillips hd. (5)	73 to * - Y398, Y440
3	2625	SCREW, No. 8-32 x 5/8 Pozidriv hd. (2)	73 to * - Y398, Y440
4	2661W	SCREW, No. 10-24 x 1/2 self tapping Phillips hd.	73 - Y398, Y440
5	2697W	SCREW, No. 10-24 x 1/2 Phillips hd. (6)	73 to * - Y398, Y440
6	2810	SCREW, No. 10-32 x 2 Pozidriv hd. (2)	73 to * - Y398, Y440
7	5967	SPACER, headlamp bracket grommet - upper (3)	73 to * - Y398, Y440
8	6716	WASHER, 3/16 x 1/2 x 1/16 (5)	73 to * - Y398, Y440
9	7220	LOCKWASHER, No. 10 external tooth	73 to * - Y398, Y440
10	8483	POP RIVET, tail lamp (4)	73 - Y398, Y440
11	11425	GROMMET, headlamp bracket - upper (3)	73 to * - Y398, Y440
12	11426	GROMMET, headlamp support (2)	73 to * - Y398, Y440
13	36508-60	SPRING, headlamp support (2)	73 to * - Y398, Y440
14	47077-71	O-RING, headlamp seal (2)	73 to * - Y398, Y440
15	53214-73	COVER GRILLE, headlamp	73 to * - Y398, Y440
16	53232-71	CLAMP	73 to * - Y398, Y440
17	67701-71	HEADLAMP - 35 watt - 12 V. (2)	73 to * - Y398, Y440
18	67718-73	SUPPORT, headlamp	73 to * - Y398, Y440
19	67722-73	BRACKET, headlamp	73 to * - Y398, Y440
20	67723-71	BRACKET, headlamp back (2)	73 to * - Y398, Y440
21	67736-73	CUP, headlamp adjuster screw (2)	73 to * - Y398, Y440
22	67737-73	CLIP, headlamp bracket (3)	73 to * - Y398, Y440
23	67738-73	MOUNTING PLATE, headlamp cover grill (5)	73 to * - Y398, Y440
	68014-73	TAIL LAMP ASSEMBLY	73 - Y398, Y440
	68014-74	TAIL LAMP ASSEMBLY	74 to * - Y398, Y440
24	68018-74	HOUSING, tail lamp	74 to * - Y398, Y440
25	68022-73	LENS, tail lamp	73 to * - Y398, Y440
26	68023-73	SOCKET, tail lamp	73 to * - Y398, Y440
27	68024-73	GASKET, tail lamp lens	73 to * - Y398, Y440
28	68165-64	BULB, tail lamp	73 to * - Y398, Y440
29	70373-73	WIRING HARNESS, tail lamp	73 to * - Y398, Y440
30	71795-63A	CLAMP, tail lamp wiring harness	73 - Y398, Y440


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.



**CONSOLE-1973
CONSOLE KIT 1971 & 1972**

CONSOLE - 1973 (CONSOLE KIT - 1971 & 1972)

INDEX NO.	PART NO.	N A M E	U S E D O N
1	3767B	BOLT, 1/4-20 x 5/8 hex. hd. (4)	71 to 73 - Y398, Y440
2	3802W	BOLT, 1/4-20 x 7/8 hex. hd. (4)	71 to 73 - Y398, Y440
3	6253W	WASHER, 1/4 x 3/4 x 1/16 (2)	73 - Y398, Y440
4	7686	LOCKNUT, 1/4-20 (4)	71 to 73 - Y398, Y440
5	8211	POP RIVET, screw plate to instrument panel (4)	71 to 73 - Y398, Y440
6	8528W	POP RIVET, choke knob bracket	73 - Y398, Y440
7	27076-71	WASHER, air silencer to carburetor (3)	71 to 73 - Y398, Y440
8	27869-73	CONSOLE, with rivets & decal	73 - Y398, Y440
9	27861-73	SCREW, console mounting - front (2)	73 - Y398, Y440
10	27862-73	BACKING PLATE, console to battery box	73 - Y398, Y440
11	27864-73	PAD, console - front	73 - Y398, Y440
12	27865-73	SILENCER SHROUD, with choke bracket	73 - Y398, Y440
13	27866-73	BRACKET, choke knob	73 - Y398, Y440
14	27868-73	CUSHION, silencer shroud	73 - Y398, Y440
15	27869-73	LABEL, Caution/running without air inlet silencer	71 to 73 - Y398, Y440
16	27870-73	CHOKE CONTROL ASSEMBLY	71 to 73 - Y398, Y440
17	27871-73	SCREW PLATE, console to instrument panel	71 to 73 - Y398, Y440
18	27872-73	RETAINER, console mounting screw (2)	73 - Y398, Y440
	27874-72	AIR INTAKE SILENCER KIT	71 & 72 - Y398
19	66221-71	DECAL, Caution/for your safety	71 - Y398, Y440




CONSOLE—1974 & LATER

CONSOLE - 1974 & LATER

INDEX PART NO.	NO.	N A M E	USED	O N
1	1374	SCREW, 1/4-28 x 3/4 Pozidriv pan hd.	74 to *	- Y398, Y440
2	2573W	SCREW, No. 6 x 1/4 self tapping hex. slot hd. (10)	74 to *	- Y398, Y440
3	3991	BOLT, 5/16-18 x 7/8 hex. hd. (2)	74 to *	- Y398, Y440
4	4017	BOLT, 5/16-18 x 1 hex. hd. (4)	71 to *	- Y398, Y440
5	5408B	CARRIAGE BOLT, 5/16-18 x 7/8 (2)	74 to *	- Y398, Y440
7	6328W	WASHER, 5/16 x 7/8 x 1/16 (2)	74 to *	- Y398, Y440
8	6702	WASHER, 5/16 x 11/16 x 1/16 (6)	74 to *	- Y398, Y440
9	6703	WASHER, 1/4 x 5/8 x 1/16 (4)	74 to *	- Y398, Y440
10	7041	LOCKWASHER, 5/16 (4)	74 to *	- Y398, Y440
11	7693	LOCKNUT, 1/4-28 x 5/16 x 7/16 hex. (6)	74 to *	- Y398, Y440
12	7710W	NUT, 5/16-18 (2)	74 to *	- Y398, Y440
13	7739	LOCKNUT, 5/16-18 (2)	74 to *	- Y398, Y440
14	8211	POP RIVET (4)	74 to *	- Y398, Y440
14A	8476	POP RIVET (8)	74 to *	- Y398, Y440
15	8482	POP RIVET (6)	74 to *	- Y398, Y440
16	8488B	POP RIVET, hinge (8)	74 to *	- Y398, Y440
17	27861-73	THUMB SCREW, console mounting (2)	74 to *	- Y398, Y440
18	27871-73	SCREW PLATE (2)	74 to *	- Y398, Y440
19	27872-73	RETAINER, console thumb screw (4)	74 to *	- Y398, Y440
20	27875-74	LOUVERED PANEL, right	74 to *	- Y398, Y440
21	27876-74	LOUVERED PANEL, left	74 to *	- Y398, Y440
22	27878-74	CONSOLE BASE	74 to *	- Y398, Y440
23	27879-74	CONSOLE PLATE	74 to *	- Y398, Y440
24	27880-74	DOOR, console	74 to *	- Y398, Y440
25	27881-74	CONSOLE	74 to *	- Y398, Y440
26	33238-59A	WASHER, console mounting (2 or as req'd)	74 to *	- Y398, Y440
27	45327-74	CASTING, hood and console support tube - right	74 to *	- Y398, Y440
28	45330-74	CASTING, hood and console support tube - left	74 to *	- Y398, Y440
28A	45340-74	STUD, casting (2)	74 to *	- Y398, Y440
29	53006-74	U-BOLT, support tube (2)	74 to *	- Y398, Y440
30	53007-74	BRACKET, support tube u-bolt (2)	74 to *	- Y398, Y440
	53209-74	CONSOLE ASSEMBLY, upper	74 to *	- Y398, Y440
	53218-74	CONSOLE ASSEMBLY, lower	74 to *	- Y398, Y440
31	53251-74	HINGE, door	74 to *	- Y398, Y440
32	53252-74	SLOTTED PANEL, upper (2)	74 to *	- Y398, Y440
33	53253-74	MOUNTING TAB, louvered panel (10)	74 to *	- Y398, Y440
34	53254-74	PAD, console floor (2)	74 to *	- Y398, Y440
35	53255-74	PAD, console door - upper	74 to *	- Y398, Y440
36	53257-74	FOAM PAD, console door	74 to *	- Y398, Y440
	53262-74	FOAM, console - left	74 to *	- Y398, Y440
	53263-74	FOAM, console - upper	74 to *	- Y398, Y440
	53264-74	FOAM, console - right	74 to *	- Y398, Y440
	53265-74	FOAM, console - upper center	74 to *	- Y398, Y440
	53266-74	FOAM, console - left	74 to *	- Y398, Y440
	53267-74	FOAM, console - right	74 to *	- Y398, Y440
	53268-74	FOAM, console - lower center	74 to *	- Y398, Y440
37	57018-74	SUPPORT TUBE, hood and console	74 to *	- Y398, Y440
38	57046-74	BOOT, steering column	74 to *	- Y398, Y440
39	57072-74	BRACKET, console mounting (2)	74 to *	- Y398, Y440
40	66221-74	DECAL, caution/for your safety	74 to *	- Y398, Y440
41	91885-73	CLAMP, support tube to console bracket (2)	74 to *	- Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.










SWITCHES AND INSTRUMENTS

SWITCHES & INSTRUMENTS

INDEX NO.	PART NO.	NAME	USED ON
1	2639W	SCREW, No. 8 x 5/8 self-tapping rd. hd.	72 - Y398
2	5446W	CARRIAGE BOLT, 5/16-18 x 3/4 (3)	71 to 73 - Y398, Y440
3	6379W	WASHER, 3/8 x 5/8 x 1/16 (3)	72 & 73 - Y398, Y440
4	6807W	WASHER, 15/32 x 3/4 x 1/64 (2)	71 to 73 - Y398, Y440
5	7739	LOCKNUT, 5/16-18 (3)	71 to * - Y398, Y440
6	10006	PLASTIC STRAP (black)	72 to * - Y398, Y440
7	10007	PLASTIC STRAP (white)	72 to * - Y398, Y440
8	11126	O-RING, speedometer mounting	71 to 73 - Y398, Y440
9	53212-71	DECAL, ignition switch	71 to 73 - Y398, Y440
10	53213-72	DECAL, ignition switch	72 to * - Y398, Y440
11	56162-72	CUT-OUT SWITCH, engine	72 to * - Y398, Y440
12	67027-72	SPEEDOMETER	71 & 72 - Y398
13	67029-73	SPEEDOMETER	73 to * - Y398, Y440
14	67035-71	ADAPTER PLATE, speedometer drive	71 to 73 - Y398, Y440
15	67035-74	ADAPTER PLATE, speedometer drive	74 to * - Y398, Y440
16	67037-71	SOCKET, speedometer bulb - with screw	71 & 72 - Y398
17	67037-73	SOCKET, speedometer bulb	73 to * - Y398, Y440
18	67038-71	BRACKET, speedometer mounting	71 to * - Y398, Y440
19	67039-71	NUT, speedometer mounting (2)	71 to * - Y398, Y440
20	67046-72	ANGLE GEAR, speedometer drive	72 to * - Y398, Y440
21	67054-72A	DRIVE COUPLING, speedometer	72 to * - Y398, Y440
22	67067-72A	CABLE, speedometer	72 to * - Y398, Y440
23	67111-72	DRIVE KEY, speedometer	72 to * - Y398, Y440
24	68167-71	BULB, speedometer	71 to * - Y398, Y440
25	70576-68	WIRE CONNECTOR, speedometer ground wire	72 - Y398
26	71477-72	BOOT, ignition switch	71 to * - Y398, Y440
27	71489-63	NUT, toggle switch	71 to 73 - Y398, Y440
28	71494-71	IGNITION SWITCH	71 to 73 - Y398, Y440
29	71494-74	IGNITION SWITCH	74 to * - Y398, Y440
30	71544-74	HEADLAMP DIMMER SWITCH	74 to * - Y398, Y440
31	71618-71	KEY, ignition switch (E-1 to E-50)	71 to 73 - Y398, Y440
32	71618-74	KEY, ignition switch	74 to * - Y398, Y440
33	71630-71	TOGGLE SWITCH, headlamp dimmer	71 to 73 - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.





ACCESSORIES

ACCESSORIES (MORE LISTED ON NEXT PAGES)

INDEX NO.	PART NO.	NAME	USED ON
1	52540-71	BACKREST KIT	71 to 73 - Y398, Y440
		Includes:	
2	2833	SCREW, 1/4-28 x 1-1/8 Phillips hd. (6)	
3	7682	LOCKNUT, 1/4-28 (6)	
4	52544-72	SUPPORT TUBE, backrest	
5	52545-72	CLAMP, backrest support tube (4)	
6	52540-74	BACKREST KIT	74 to * - Y398, Y440
		Includes:	
7	2833	SCREW, 1/4-28 x 1-1/4 Phillips hd. (6)	
8	6340	WASHER, 3/4 x 1-1/2 x 1/8 (2)	
9	7682	LOCKNUT, 1/4-28 (6)	
10	52544-74	SUPPORT TUBE, backrest	
11	52545-72	CLAMP, backrest support tube (4)	
12	58010-72	WINDSHIELD KIT, large	72 - Y398
		Includes:	
13	2697W	SCREW, No. 10-24 x 1/2 Phillips hd. (6)	
14	6187W	WASHER, No. 10 x 9/16 x 1/16 (10)	
15	7613A	SPEED NUT (4)	
16	67718-60	SCREW (4)	72 - Y398
17	89100-72	HITCH KIT	71 & 72 - Y398
		Includes:	
18	4713W	BOLT, 3/8-16 x 3/4 hex. hd.	
19	89104-72	TONGUE, hitch pin	
20	89105-72	HITCH PIN	
21	89106-72	RETAINING RING, hitch pin (2)	
22	91816-72	CIGARET LIGHTER KIT	71 to * - Y398
		Includes:	
23	70372-72	WIRE, lighter to spark coil	
24	70374-72	WIRE, lighter to ignition switch	
25	70576-68	WIRE CONNECTOR	
26	91813-68	ELEMENT AND KNOB	
27	91862-72	MIRROR, complete	71 to * - Y398
		Includes:	
28	2859	SCREW, No. 10-24 x 7/8 Pozidriv hd. (2)	
29	6187W	WASHER, No. 10-9/16 x 1/16 (2)	
30	7414	LOCKWASHER, No. 8	
31	7624	NUT, No. 10-24	
32	91863-72	MIRROR HEAD, only	
33	91866-72	SCREW, mirror adjustment	
34	91867-72	RING, mirror head	
35	91868-72	SCREW, mounting bracket - front	
36	91869-72	MOUNTING BRACKET, mirror	
37	91870-72	MOUNTING PAD	
38	92046-72	TACHOMETER KIT	71 to * - Y398
		Includes:	
39	53213-72	DECAL, ignition switch (used with tachometer)	
40	70296-72	WIRE, alternator and ground (2)	
41	70576-68	WIRE CONNECTOR (3)	
42	92081-72	BULB, tachometer	
	99801-SN	50/1 SNO-OIL, case 24 quarts	71 to * - Y398
	99890-61	TRANSMISSION LUBRICANT (chain case) - 12 oz. can	71 to * - Y398

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.




ACCESSORIES

ACCESSORIES (MORE LISTED ON PREVIOUS PAGES)

INDEX NO.	PART NO.	NAME	USED ON
1	33233-73	ELECTRIC START CONVERSION KIT.....	71 to 73 - Y398, Y440
		NOTE: For 1972, Wiring Harness Part No. 70273-72 must be ordered.	
		Consists of:	
2	2533	SCREW, No. 8-32 x 3/8 self tapping rd. hd. (2)	
3	3967P	SCREW, 8 mm. x 30 socket hd. (2)	
4	10006	CABLE STRAP (7)	
5	31454-71A	STARTER MOTOR, with solenoid (See Electric Starter Section for Parts)	
6	33229-72	SHIM, starter mounting	
7	66000-71	BATTERY - 12 V.	
8	66355-71	CUSHION, battery box cover	
9	70349-71	WIRE, battery positive terminal to solenoid	
10	70377-72	WIRE, battery negative terminal to ground	
11	70378-71	WIRE, solenoid to circuit breaker	
12	70576-68	WIRE CONNECTOR	
13	74588-72	CIRCUIT BREAKER	
14	33233-74	ELECTRIC START CONVERSION KIT.....	74 to * - Y398, Y440
		Consists of:	
15	3967P	SCREW, No. 8-32 x 3/8 self-tapping rd. hd. (2)	
16	7069	LOCKWASHER, No. 10 (2)	
17	7638	NUT, No. 10-32 x 1/8 x 3/8 (2)	
18	8528W	POP RIVET, circuit breaker clip	
19	9952	CLIP, circuit breaker	
20	10006	CABLE STRAP (7)	
21	31454-71A	STARTER MOTOR, with solenoid (See Electric Starter Section for Parts)	
22	33229-72	SHIM, starter mounting	
23	65999-74	BATTERY, 12 V.	
24	66256-74	CLIP, battery hold-down	
25	66382-73P	STRAP, battery	
26	70349-74	WIRE, battery positive terminal to solenoid	
27	70377-74	WIRE, battery negative terminal to ground	
28	70378-74	WIRE, solenoid to circuit breaker	
29	70576-68	WIRE CONNECTOR	
30	74589-73	CIRCUIT BREAKER	
31	67013-72	SPEEDOMETER KIT	71 & 72 - Y398
		Consists of:	
32	2539W	SCREW, No. 8 x 5/8 self-tapping rd. hd.	
33	6379W	WASHER, 3/8 x 5/8 x 1/16 (3)	
34	67027-72	SPEEDOMETER (See Instrument Panel Section for Parts)	
35	67035-71	ADAPTER PLATE, speedometer drive	
36	67046-72	ANGLE GEAR, speedometer drive	
37	67054-72A	DRIVE COUPLING, speedometer	
38	67057-72A	CABLE, speedometer	
39	67111-72	DRIVE KEY, speedometer	
40	70576-68	WIRE CONNECTOR, speedometer ground wire	
41	67013-73	SPEEDOMETER KIT	73 - Y398, Y440
		Consists of:	
42	6379W	WASHER, 3/8 x 5/8 x 1/16 (3)	
43	64694W	WASHER, 7/16 x 3/4 x 1/8	
44	10006	CABLE STRAP	
45	67029-73	SPEEDOMETER (See Instruction Panel Section for Parts)	
46	67035-71	ADAPTER PLATE, speedometer drive	
47	67046-72	ANGLE GEAR, speedometer drive	
48	67057-72A	CABLE, speedometer	
49	67111-72	DRIVE KEY, speedometer	
50	70322-73	WIRE, speedometer light (includes insulator 70589-69)	
51	70576-68	WIRE CONNECTOR	
52	70273-72	WIRING HARNESS.....	72 - Y398
53	88530-71C	COVER, snowmobile	71 to * - Y398, Y440


NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.

TOOLS



TOOLS

INDEX NO.	PART NO.	NAME	USED ON
1	2697W	SCREW, No. 10-24 x 1/2 Phillips hd. (2)	72 to * - Y398, Y440
2	6716	WASHER, 3/16 x 1/2 x 1/16 (2)	72 to * - Y398, Y440
3	36445-71	EMERGENCY STARTER CORD	71 to * - Y398, Y440
4	94410-72	TOOL CASE	72 to * - Y398, Y440
5	94415-65P	TOOL BAG	72 to * - Y398, Y440
6	94512-64P	ALLEN WRENCH, 6 mm.	71 to * - Y398, Y440
7	94515-68P	SOCKET WRENCH, 21 mm.	71 to * - Y398, Y440
8	94572-61P	SOCKET WRENCH HANDLE	71 to 73 - Y398, Y440
	94576-72A	TOOL KIT	71 to * - Y398, Y440
9	94577-72A	ADJUSTABLE WRENCH, 6"	71 to * - Y398, Y440
10	95001-12	PLIERS	71 to * - Y398, Y440
11	95002-45	SCREWDRIVER	71 to 73 - Y398, Y440
12	95005-74	SCREWDRIVER, 1/4" & #2 phillips combination	74 to * - Y398, Y440
13	95006-74	WRENCH, box end - 1/2 & 9/16	74 to * - Y398, Y440



CUTTER

CUTTER

INDEX NO.	PART NO.	NAME	USED ON
1	1206	SCREW, No. 10-24 x 3/4 Pozidriv pan hd. (8)	71 to * - Y398, Y440
2	2543W	SCREW, seat bottom cushion, 1/4-10 x 1-3/4 hex. hd. (4).....	71 to * - Y398, Y440
3	2828W	BOLT, 3/8-16 x 3 hex. hd. (3)	71 to * - Y398, Y440
4	3779	BOLT, 1/4-20 x 3/4 hex. hd. (4)	71 to * - Y398, Y440
5	4337W	BOLT, 3/8-24 x 1-1/4 hex. hd. (4).....	71 to * - Y398, Y440
6	6253W	WASHER, 1/4 x 3/4 x 1/16 (4)	71 to * - Y398, Y440
7	6703	WASHER, 1/4 x 5/8 x 1/16 (4)	71 to * - Y398, Y440
8	7624	LOCKNUT, No. 10-24 x 1/4 x 3/8 hex. (8).....	71 to * - Y398, Y440
9	7725	LOCKNUT, 5/16-24 x 11/32 x 1/2 hex. (6)	71 to * - Y398, Y440
10	7775	LOCKNUT, 3/8-24 x 7/16 x 9/16 hex. (4).....	71 to * - Y398, Y440
11	7778	LOCKNUT, 3/8-16 x 7/16 x 9/16 hex. (3)	71 to * - Y398, Y440
12	10502	STUD, seat snap (4)	71 to * - Y398, Y440
13	52201-74	SEAT KIT, cutter	71 to * - Y398, Y440
14	52202-74	SEAT BACK CUSHION.....	71 to * - Y398, Y440
15	52203-74	SEAT BOTTOM CUSHION.....	71 to * - Y398, Y440
16	59988-72	REFLECTOR (2)	71 to * - Y398, Y440
17	89477-74V	CUTTER, complete	71 to * - Y398, Y440
18	89478-74	FRAME	71 to * - Y398, Y440
19	89479-74	BODY	71 to * - Y398, Y440
20	89480-74	WINDSHIELD	71 to * - Y398, Y440
21	89481-74	LEAF SPRING (2)	71 to * - Y398, Y440
22	89482-74	SKI (2)	71 to * - Y398, Y440
23	89483-74	WEAR ROD, cutter ski (2)	71 to * - Y398, Y440
24	89484-74	HITCH, cutter	71 to * - Y398, Y440
25	89485-74	REFLECTIVE TRIM	71 to * - Y398, Y440

NOTE: Asterisk (*) indicates part is used for latest model year shown on cover.