

MUSTANG MODELS

All MUSTANG Models use the Polaris clutch.
See section #18.


ENGINE & CARBURETORS

See section #17, Engines.

J-90-H	JLO 252	w/Tillotson	#HL-187-A
H-12-H	Hirth	w/Tillotson	#184-A
K-80-H	Kohler	Manual	
K-60-H	Kohler	Manual	

Table of Contents


	Page
Main Body	1
Hood & Windshield	2
Shields	3
Cushions	4
Throttle	5
Jackshaft & Drive Sprockets	6 & 7
Steering Assembly	8 & 9
Motor Mounts - Hirth & JLO	10
Motor Mounts - Kohler	11
Exhaust & Muffler	12
Electrical	13
Gas Tanks	14
Steering Ski (old style)	15
Brake	16
Track	17
Drive Shaft & Sprockets	18 & 19
Rear Idler	20 & 21
Idler Assembly	22
Steering Ski	23
Clutch	
Engines	
Carburetor	



-Main Body Assembly


64C-11340

Main Body




Hood & Windshield

62A-757-P61	#10 Lock Washer	5
62A-760-P60	#10-24 Hex Nut	5
62A-774	1/4-20 Truss Hd. Machine Screw	8
64C-11308	Windshield	1
62A-11309	Trim	1
64C-11400	Hood	1
62A-11409	U clip	5
62A-11420	#10-24 X 5/8 Phillips Hd. Mach. Screw	5



Shields

64C-10692	Tool Box	1
62A-11374	1/4-20 Speed Nut	2
62A-11390	Spacer	2
64C-11401	Shield	1
62A-11419	1/4-20 X 2 Thread Head Machine Screw	2
62A-11421	1/4 Ex. Lock Washer	1
64C-11432	Combination Lock	1



Seats

64C-11386


Seat Cushion

1

64C-11385


Back Cushion

1



Throttle Parts


62A-3175	Swivel Joint Lock	2
62A-10625	Handle	1
62A-11117	3/16 X 1 1/4 Clevis Pin	1
62A-11294	Spring (Kohler)	1
62A-11398	Throttle Cable Complete	1
62A-11430	Bracket (Kohler)	1



Jackshaft & Drive Sprockets

62A-559	Bearing w/lock collar	2
62A-735	5/16-18 X 1 1/2 Hex. Hd. Cap Screw	1
62A-748	5/16 Flat Washer	1
62A-770-P61	5/16-18 X 3/4 Carriage Bolt	6
62A-5669	#40 Connector Link	
62A-10090	5/16-18 Hex. Nut (locking)	7
62A-10152	5/16-18 X 1 Hex. Hd. Cap Screw	1
62A-10616	Sprocket	1
62A-10846	5/16 Lock Washer	1
62A-11139	# 9 Woodruff Key	1
63B-11307	Jackshaft	1
62A-11344	5/16 Dome Lock Washer	1
62A-11345	Spacer	1
62A-11361	5/16-18 X 5/16 Soc. Hd. Set Screw	2


62A-11402	Drive Chain w/connector	1
62A-11403	Chain Tightener Block	1
63B-11406	Sprocket	1
62A-11407	Bearing Flange (pair)	2
62A-11416	1/4-20 x 1 Hex hd. cap screw	2
62A-11422	1/4 Dome Lock Washer	2



Steering Assembly


62A-708-P61	1/4-20 X 3/4 Hex. Head Cap Screw	2
62A-737	3/8 SAE Flat Washer	2
62A-741	1/4 Lock Washer	2
62A-752	1/4-20 Hex. Nut (locking)	2
62A-754	3/8-16 Hex. Nut	1
62A-10028	1/8 X 1 Cotter Pin	2

62A-11139	#9 Woodruff Key	2
62A-11176	Grease Fitting	2
62A-11204	Grip	2
62A-11290	1/4-20 x 1 Hex. Hd. cap screw	2
62A-11361	5/16-18 x 5/16 Soc. hd. set screw	2
62A-11356	Spindle	2
64C-11362	Steering Post	1
62A-11363-L	Steering Arm (left)	1
62A-11363-R	Steering Arm (right)	1
62A-11364	Tie Rod	2
62A-11365	Adjusting End	2
62A-11381	Spindle Bushing	2
62A-11417	1/4-E1 Lk. Washer	2



Motor Mounts—Hirth & JLO

62A-730	3/8-16 X 1 1/4 Hex. Head Cap Screw	4
62A-743	3/8 Lock Washer	8
62A-749	3/8 Flat Washer	8
62A-753-P61	3/8-16 X 3 Hex. Hd. Cap Screw (JLO)	4
62A-774-P59	3/8-16 X 2 1/4 Hex. Hd. Cap Screw (HIRTH)	4
62A-9011	Rubber Mount	4
62A-10031	3/8-16 Hex. Nut (locking)	8
62A-10956	Bushing	4
63B-11392	Motor Mount Strap	2
62A-11393	Spacer (HIRTH)	2
62A-11394	Spacer, (JLO)	2
62A-11425	Base Plate (JLO)	1
62A-11426	Base Plate (HIRTH)	1



Motor Mounts-Kohler

62A-730	3/8-16 X 1 1/4 Hex. Hd. Cap Screw	4
62A-731	3/8-16 X 1 1/2 Hex. Hd. Cap Screw	4
62A-743	3/8 Lock Washer	8
62A-749	3/8 Flat Washer	4
62A-9011	Rubber Mount	4
62A-10031	3/8-16 Hex. Nut (locking)	8
62A-10956	Bushing	4
62A-11391	Mounting Strap	2

638-11427
638-11428
638-11429


SEE ENGINE MANUAL

62A-10090
62A-10846
62A-748

64C-10376


Exhaust & Muffler

62A-748	5/16 Flat Washer	1
62A-10090	5/16-18 Hex. Nut (locking)	1
64C-10376	Muffler	1
62A-10846	5/16 Lock Washer	1
638-11427	Exhaust Tube (JLO)	1
638-11428	Exhaust Tube (HIRTH)	1
638-11429	Exhaust Tube (KOHLER)	1




Electrical

62A-2530-12	Headlight Complete	1
62A-2530A12	Sealed Beam Unit	1
62A-10045	Electrical Connector	2
62A-11213	Toggle Switch	2
62A-11395	Headlight Base	1
62A-11396	Wire (headlight to Switch)	1
62A-11397	Wire (Switch to headlight)	1




Gas Tanks

62A-10136A	Gas Cap	1
64C-11383	Round Tank	1
64C-11384	Flat Tank	1
62A-11399	Gas Line	1
62A-11408	Hose Clamp	2




62A-730	3/8-16 X 1 1/4 Hex. Head Cap Screw	2
62A-760-P61	3/8-16 X 3 3/4 Hex. Hd. Cap Screw	4
62A-10031	3/8-16 hex. Nut (self locking)	7
63B-10368	Spring	1
62A-10440	3/8-16 X 2 3/4 Hex. Hd. Cap Screw	2
62A-10613	Hanger	4
62A-10639	Bushing	2
62A-10664	Bushing	1
62A-10915	Spring Saddle	1
62A-11034	Spring Plate	1
63B-11378	Skag	1

*** Note: When ordering parts marked SEE NOTE specify Old Style Mustang.



Brake

62A-769	Hair Pin Cotter	1
62A-3175	Swivel Joint Lock	1
62A-10259	Spring	1
62A-10625	Handle	1
62A-11366	Pin	1
62A-11382	Brake Arm w/Pad	1
62A-11398	Brake Cable Complete	1



Track

62A-11141


Pop Rivet w/washer

62A-11369

Cleat

64C-11415


Track Complete



Drive Shaft & Sprockets

62A-741	1/4 Lock Washer	6
62A-767-P61	1" X 18 Ga. Machinery Bushing	4
62A-799-P59	1/4-20 X 1 1/4 Hex. Hd. Cap Screw	6
62A-10152	5/16-18 X 1 Hex. Hd. Cap Screw (Nylock)	1
62A-10392	Bearing w/lock collar	2
62A-10561	Rubber Tire (Flat)	4
62A-11089	Rubber Sprocket	1
62A-11291	Pulley	2
62A-11343	Shaft	1


62A-11344	5/16 Dome Washer	1
62A-11346	#91 Woodruff Key	1
62A-11361	5/16-18 x 5/16 Soc. hd set screw	4
62A-11370	Lock Collar	2
62A-11373	Spacer	2
62A-11404	Drive Flange	1
62A-11405	Flange (pair)	2



Rear Idler


62A-559	Bearing w/lock collar	2
62A-705	5/16 X 1 3/8 Flat Washer	2
62A-707	5/16-18 X 3/4 Hex. Hd. Cap Screw	2
62A-741	1/4 Lock Washer	2
62A-748	5/16 Flat Washer	6
62A-749	3/8 Flat Washer	2
62A-10031	3/8-16 Hex. Nut (self locking)	2

62A-10090	5/16-18 Hex. Nut (locking)	4
62A-10152	5/16-18 x 1 Hex Hd. Cap Screw (Nylock)	2
62A-10561	Rubber Tire (flat)	4
62A-10846	5/16 Lock Washer	2
62A-10964-L	Spring (left)	1
62A-10964-R	Spring (right)	1
62A-11277	1/4-28 x 3/8 hex hd. screw	2
62A-11305-L	Rear Bogie Arm (left)	1
62A-11305-R	Rear Bogie Arm (right)	1
62A-11306-L	Bogie Arm Hanger (left)	1
62A-11306-R	Bogie Arm Hanger (right)	1
63B-11350	Shaft	1
62A-11352	Track Adjusting Bolt	2
62A-11361	5/16-18 x 5/16 Soc. hd. set screw	2
62A-11367	Pulley	2
62A-11371	Lock Collar	2
62A-11372	Spacer	1
62A-11418	3/4 18 ga. Machinery Bushing	4



Idler Assembly

62A-743	3/8 Lock Washer	6
62A-749	3/8 Flat Washer	6
62A-10028	Cotter Key 1/8 X 1	12
62A-10245	3/8-16 X 1 Hex. Hd. Cap Screw (nylock)	6
62A-10560	Rubber Tire	12
62A-10851	Idler Pulley	12
62A-10897	5/8-11 Hex. Nut (slotted)	12
62A-10963	Spring	6
62A-10966	Shaft	6
62A-11299	Shaft	3
63B-11389	Bogie Tube	6



Steering Ski

62A-730	3/8-16 X 11/4 Hex. Head Cap Screw	4
62A-741	1/4 Lock Washer	2
62A-743	3/8 Lock Washer	4
62A-10016	1/4-20 Hex. Nut Self Locking	2
62A-10028	1/8 X 1 Cotter Key	2
62A-10031	3/8-16 Hex. Nut (locking)	4
62A-10090	5/16-18 Hex. Nut (locking)	2
62A-10846	5/16-Lock Washer	2

62A-11186	5/16-18 x 2 3/4 hex hd cap screw	2
63B-11280	Main Leaf - Spring	2
63B-11281	Top Leaf - Spring	2
64C-11377	Steering Ski	2
63B-11378	Skag - Ski	2
62A-11379	Ski Saddle	2
62A-11380	Spring Plate	2
62A-11424	3/8 x 3 3/4 Clevis Pin	2