

KE-24-H


FOR MOTOR PARTS SEE KOHLER 24 H.P. SECTION 17.

FOR CLUTCH PARTS SEE SALSURY 1110 SECTION 18.

FOR TRANSMISSION PARTS SEE SNO-NABSTEDT MODEL 5131
SECTION 18.


Table of Contents

	Page
Nose Section & Windshield	1
Steering Wheel & Throttle Post	2
Seat Cushions	3
Steering Section	4 & 5
Ski & Spring	6 & 7
Shock Absorber	8
Power Unit & Skid Rails	9
Gas Tank & Accessories	10
Rear Drive Assembly	11
Track Assembly	12 & 13
Rear Drive Sprockets & Chain	14 & 15
Front Idler	16
Drive Belt & Transmission Bolts	17
Engine Mounting Accessories	18
Shifting & Throttle Controls	19
Electrical	20 & 21
Solenoid	22
Shields	23
Brake Assembly	24




Nose Section & Windshield

64C-10925	Nose Section	1
64C-10926	Frame-Windshield	1
64C-10928	Hood	1
64C-11066	Windshield	1
62A-11067	Rubber-Windshield Frame	1




Steering Wheel & Throttle Post

62A-719	5/16 Lock Washer	1
62A-748	5/16 Flat Washer	1
62A-10152	5/16-18 X 1 Hex. Head Bolt	1
62A-10474	Rubber Grip	1
62A-10832	3/16 X 3/16 X 3/4 Key	1
62A-10848	Grip Shift Lever	2
62A-10929	Steering Post	1
64C-11051	Steering Wheel	1



Seat Cushions

64C-11030	Front Cushion	1
64C-11031	Main Cushion	1
64C-11032	Back Cushion	1




Steering Section

62A-705	5/16 X 1 3/8 O.D. Washer	2
62A-719	5/16 Lock Washer	2
62A-728	5/16-18 X 1 Hex. Head Cap Screw(Nylock)	2
62A-740	1/2 Flat Washer	4
62A-748	5/16 Flat Washer	3
62A-755	1/2 Hex. Head Nut	2
62A-768	5/8 Flat Washer	1
62A-5669	Connector Link	1
62A-5904B	Tie Rod End	2
62A-6004-P62	Flange Bearing	1
62A-10028	1/8 X 1 Cotter Key	4
62A-10090	5/16-18 X Hex. Nut (Self Locking)	3

(Continued on next page)

63B-10202	Sprocket	1
62A-10203	Adjusting Plate	1
62A-10204	Chain	1
62A-10503	Steering Arm	2
62A-10781-A	Tie Rod	2
62A-11036	Spindle	2
62A-11175	1/4 x 1/4 x 1 1/4 Key	2
62A-11176	Grease Fitting	2




Ski & Spring

62A-731	3/8-16 X 1 1/2 Hex. Head Cap Screw	4
62A-743	3/8 Lock Washer	4
62A-760-P61	3/8-16 X 3 3/4 Hex. Head Cap Screw	2
62A-10031	3/8-16 Hex. Nut (Self Locking)	4
64C-10367	Spring Main Leaf	2
63B-10368	Spring Middle	2
62A-10440	3/8-16 X 2 3/4 Hex. Head Bolt	6
62A-10613	Shackle Plate	4
62A-10639	Bushing	4
62A-10664	Bushing	2
64C-10888	Spring	2


(Continued on next page)

62A-10915	Spring Saddle	2
64C-10927	Ski	2
62A-11034	Plate Ski	2




Shock Absorber

62A-743	3/8 Lock Washer
62A-774-p59	3/8-16 X2 1/4 Hex. Head Cap Screw
62A-10031	3/8-16 Hex. Nut (Self Locking)
64C-10194	Shock Absorber
62A-10195	Rubber Bushing (Lower End)
62A-10196	Rubber Bushing (Upper End)
62A-11145	Steel Bushing




Power Unit & Skid Rails

62A-719	5/16 Lock Washer	20
62A-728	5/16 -18 X 1 Hex. Head Cap Screw	20
62A-735	5/16-18 X 1 1/2 Hex. Head Cap Screw	10
62A-740	1/2 Flat Washer	2
62A-748	5/16 Flat Washer	20
62A-10028	1/8 X 1 Cotter Pin	2
62A-10090	5/16-18 Hex. Nut (Self Locking)	20
64C-10918	Skid Rail (Lower)	4
64C-10919	Skid Rail (Upper)	4
64C-10920	Housing Power Unit	1
62A-11103	5/16-18 X 3 Hex. Head Cap Screw	20
62A-11174	1/2 X 4 1/2 Cleviss Pin	2




Gas Tank & Accessories

62A-719	5/16 Lock Washer	4
62A-789	5/16-18 X 1 1/4 Hex. Head Bolt	4
62A-5724-C	Hose Fitting	1
62A-10090	5/16-18 Hex. Head Nut (Self Locking)	4
62A10136-A	Gas Cap	1
64C-11028	Gas Tank	1
62A-11029	Bracket	2
62A-11033	Gas Line	1
62A-11048	Bracket Liner	2
62A-11049	Hose Clamp	2
A-201073 (Kohler)	Gasculator	1



Rear Drive Assembly

62A-719	5/16 Lock Washer	4
62A-740	1/2 Flat Washer	4
62A-747	1/2 Lock Washer	4
62A-748	5/16 Flat Washer	8
62A-797	1/2-13 Hex. Head Cap Screw 1 3/4	4
62A-10051	1/2-13 Hex. Nut (self Lock)	4
62A-10090	5/16-18 Hex. Nut (Self Lock)	4
62A-10913	Bearing Block	1
64C-11039	Rear Drive Shaft	1
62A-11061	Pillow Block Bearing	2
62A-11186	5/16-18 Hex. Head Cap Screw 2 3/4	4




Track Assembly

62A-701-P61	1/4-20 X 1/2 Hex. Head Cap Screw
62A-775-P61	1/4-20 X 2 1/4 Hex. Head Cap Screw
63B-2540-C	Rubber Cleat
62A-5804	Connector Link
62A-5808	Apron Attaching Cleat
62A-5819	#10-32 X 1/2 Hex. Head Bolt w/nut

(continued on next page)

62A-5822	Attaching Link
62A-5824	Roller Link
62A-10016	1/4-20 Hex. Nut (Self Locking)
64C-11151	Complete Track
63B-11152	Cleat (Replaces Cleat #10856)
* 62A-11153	Apron (Specify Complete Apron or Feet Required)
* 62A-11154	Complete Chain

* Not Shown on Drawing




Rear Drive Sprockets & Chain

62A-723	3/8-16 X 3/8 Socket Head Set Screw	4
62A-747	1/2 Lock Washer	1
62A-10051	1/2-13 Nut (self Locking)	1
62A-10327	Spacer Bushing	1
62A-10370	Idler Sprocket	1
62A-10382	Connector Link	
62A-10840	5/16-18 X 3/8 Set Screw	1
63B-11040	Sprocket	1
62A-11041	Sprocket	1
62A-11062	Chain	1


(Continued on next page)

62A-11071	Spacer	1
62A-11172	5/16 x 5/16 x 2 1/4 Key	1
62A-11173	1/4 x 1/4 x 2 Key	1
62A-11177	1/2-13 x 2 1/4 Hex. Hd. Bolt	1




Front Idler

62A-762	5/8-11 Hex. Nut	8
62A-5810	Spring	4
62A-10038	Bearing with Collar	4
62A-10323	5/8-11 Hex. Nut (Self Locking)	4
62A-10324	Adjusting Rod	4
62A-10912	Bearing Block	4
64C-11038	Front Idler	2




Drive Belt & Transmission Bolts

62A-719	7/16-20 X 4 Hex. Head Cap Screw	1
62A-743	7/16 Lock Washer	1
62A-748	5/16 Wrought Washer	1
62A-749	3/8 Wrought Washer	1
62A-760-P61	3/8-16 X 3 3/4 Hex Head Cap Screw	1
62A-11112	7/16-20 X 4 Hex. Head Cap Screw	1
62A-11149	7/16 Flat Washer	1
62A-11159	Drive Belt	1
62A-11170	1/4 X 1/4 X 5 1/2 Key	1
62A-11171	1/4 X 1/4 X 4 3/4 Key	1




Engine Mounting Accessories

62A-740	1/2 Wrought Washer	4
62A-747	1/2 Lock Washer	4
62A-9011	Rubber Mount	4
62A-9016	Stud	4
62A-10051	1/2-13 Hex. Nut (Self Locking)	4
~~62A-10223~~	Motor Mounting Plate	4



Shifting & Throttle Controls

62A-11052	Clamp	2
62A-11053	Clamp	2
62A-11054	Clevis	2
62A-11055	Clevis	1
63B-11056	Shift Lever	1
64C-11057	Shift Cable	1
64C-11058	Shift Cable	1
62A-11069	Bracket	1
64C-11070	Throttle Cable	1
62A-11143	Swivel Clamp	1




Electrical

62A-2530	Headlight (Complete)	2
62A-2530-A	Sealed Beam Unit	2
62A-2558	Light Switch	1
62A-10045	Electrical Connector	
62A-10090	5/16-18 Hex. Nut (Self Locking)	4
64C-10506	Battery	1
63B-10508	Battery Hold Down	2
64C-10910	Frame Battery Hold Down	1
64C-11035	Battery Cover	1
62A-11068-1	Ground Cable	1
62A-11068-2	Battery Cable	1
62A-11158	Starter Switch	1
62A-11162	Ammeter	1


(Continued on Next Page)

62A-11163	Ignition Switch with Key	1
62A-11165	Wiring Harness	1
62A-11166	Wire (Switch to Headlight)	1
62A-11167	Wire (Ground)	1
62A-11168	Ammeter Wire	1
62A-11169	Ammeter Wire	1




Solenoid

62A-11182	Bracket	1
62A-11183	Solenoid	1
62A-11184	Arm	1
62A-11185	Arm	1



Shields

62A-769	Hair Pin Cotter	3
64C-10752-2	Clutch Shield	1
64C-11037	Chain Shield	1
62A-11063	Pin	2
62A-11064	Pin	1



BRAKE ASSEMBLY

62A-11042	CONNECTOR ARM	1
62A-11044	BRAKE DISC	1
62A-11045	CYLINDER	1
62A-11046	BRAKE ACTUATOR (COMPLETE WITH DISCS)	1
62A-11046A	STATIONARY PAD	1
62A-11046B	MOVABLE PAD	1
62A-11047	BRAKE PAD	1
62A-11117	CLEVIS PIN	2
62A-11155	HYDRAULIC FITTING	1
62A-11156	HYDRAULIC FITTING	1

62A-11357

3/8-16 x 3/4 Flat Hd. Soc. Cap
Screw

3

62A-11358

3/8 C'sk. Lock Washer

3