



1977

Parts Manual

Colt - Colt S/S

COLT AND COLT SS MODEL NUMBERS

0771024

0771025

0771126

0771138


CONTENTS

BODY & TRIM	2 - 3
CONSOLE	4 - 5
SEAT ASSEMBLY	6 - 7
STEERING ASSEMBLY	8 - 9
CHAINCASE ASSEMBLY	10 - 11
CHAINCASE MOUNTING	12
DRIVE CLUTCH	13
DRIVEN CLUTCH	14
TRACK ASSEMBLY	15
DRIVE SHAFT	16
MAIN WIRE HARNESS	17
SUSPENSION	18 - 19
ENGINE MOUNTING	20 - 23
CRANKCASE & CYLINDER	24 - 29
CRANKSHAFT & PISTON	30 - 33
RECOIL STARTER	34 - 39
MAGNETO	40 - 45
BLOWER HOUSING	46 - 49
CARBURETOR	50 - 55
FUEL PUMP	56 - 59

BODY & TRIM

[illegible]


BODY & TRIM



CONSOLE

[illegible]


CONSOLE



SEAT ASSEMBLY

[illegible]


SEAT ASSEMBLY



STEERING ASSEMBLY

ITEM NO.	PART NO.	PART DESCRIPTION	ITEM NO.	PART NO.	PART DESCRIPTION
1	7661619	Retaining Pin	23	7060112	Tie Rod End Bearing
2	5430436	Throttle Lever - Standard	24	7512410	Bolt
	5430404	Throttle Lever - SS	25	5020247	Tie Rod
3	5410205	Handle Bar Grip	26	3573904	Bushing
4	5430437	Throttle Block - Standard	27	7558403	Washer
	5430405	Throttle Block - SS	28	3574202	Bushing
5	5430403	Throttle Control Spacer - SS	29	1821010	Spindle
6	7512465	Set Screw	30	5410055	Ski Stop
7	7080187	Throttle Cable - 244 Single	31	5010059	Ski Pivot Bushing
	7080188	Throttle Cable - 250 Standard	32	7512405	Bolt
	7080157	Throttle Cable - 250, 340 SS	33	5221227	Spring Saddle - Standard
8	7710502	Cable Retainer - Standard	34	7043003	Top Support Spring
	7710501	Cable Retainer - SS	35	7515417	Bolt
9	4110039	Shut Off Switch - Standard	36	7043002	Center Support Spring
	4110026	Shut Off Switch - SS	37	7043022	Main Leaf Spring
10	7080138	Panduit Strap - SS	38	1820142	Ski Spring Stop
11	5430407	Handle Bar Cover - SS	39	1820190	Ski
12	5430406	Brake Control Spacer - SS	40	7661407	Cotter Pin
13	4110040	Hi-Lo Dimmer Switch - Standard	41	7662001	Clevis Pin
	4110025	Hi-Lo Dimmer Switch - SS	42	7542320	Lock Nut
14		Master Cylinder (See Page 10)	43	1820132	Ski Skag
15	7080138	Harness Tie	44	5430003	Wear Plate
16	7512239	Bolt	45	7512522	Bolt - SS
17	1823097	Steering Post - Standard	46	7542513	Lock Nut - SS
	1823098	Steering Post - SS	47	5430264	Bottom Shock Bushing - SS
18	7542101	Lock Nut	48	7041044	Shock Absorber - SS
19	7542403	Lock Nut	49	7512542	Bolt - SS
20	5221701	Steering Arm	50	5221550	Spring Saddle - SS
21	7512483	Bolt	51	7710401	"E" Ring
22	7542401	Hex Nut	52	7542403	Flange Nut


STEERING ASSEMBLY



CHAINCASE ASSEMBLY


ITEM NO.	PART NO.	PART DESCRIPTION	ITEM NO.	PART NO.	PART DESCRIPTION
1	5020222	Bleeder Adapter Fitting	33	7512234	Bolt
2	5020214	Bleeder Fitting	34	7512497	Machine Screw
3	4110035	Stop Light Switch	35	3221012	13 Tooth Sprocket - 244
4	7052020	Male Elbow		3221008	15 Tooth Sprocket - 250, 250 SS
5	7712801	Retaining Ring		3221009	17 Tooth Sprocket - 340 SS
6	7555813	Washer	36	7577901	Washer
7	7041023	Compression Spring	37	7512325	Bolt
8	5410158	'O' Ring	38	5410193	'O' Ring
9	5020202	Disc Brake Plunger	39	7512220	Screw
10	5410159	'O' Ring	40	4110025	Hi/Lo Dimmer Switch - SS
11	1930521	Disc Brake Puck	41	5420120	Brake Line
12	7512390	Screw	42	7052019	Male Connector
13	7661806	Locator Pin	43	5410210	Cover Gasket - SS
14	5630039	Rear Chaincase Cover	44	5430402	Reservoir Cover - SS
15	3514303	Bearing	45	7511836	Screw - SS
16	5020213	Input Shaft	46	7661615	Retaining Pin - SS
17	7721202	Square Key	47	5630118	Brake Lever - SS
18	1332043	Brake Disc Assembly	48	7512465	Set Screw - SS
19	5630133	Chaincase - 244 & 340 SS	49	5430401	Master Cylinder Housing - SS
	5630166	Chaincase - 250 & 250 SS	50	5020318	Cylinder Bore Slug - SS
20	7512342	Adjusting Bolt	51	7710401	Retaining Ring - SS
21	7542301	Hex Nut	52	7041067	Compression Spring
22	1332070	Tightener Block	53	5410164	U Pack Seal
23	5210121	Retaining Plate	54	5410163	'O' Ring
24	7511968	Screw	55	5020319	Master Cylinder Piston
25	3224014	84 Pitch Roller Chain - 244	56	5410176	Cover Gasket
	3224016	86 Pitch Roller Chain - 250, 250 SS, 340 SS	57	5630125	Master Cylinder Housing
26	3222027	35 Tooth Sprocket	58	7512308	Set Screw
27	7577908	Washer	59	5630126	Brake Lever
28	5410177	Rubber Seal	60	5332326	Brake Lever Bushing
29	5630113	Chaincase Cover	61	7511841	Screw
30	5430380	Chaincase Plug	62	5630127	Reservoir Cover
31	5210609	Back-Up Plate	63	7511975	Screw
32	5020285	Jamb Nut	64	7555708	Washer

CHAINCASE ASSEMBLY




CHAINCASE MOUNTING


ITEM NO.	PART NO.	PART DESCRIPTION	ITEM NO.	PART NO.	PART DESCRIPTION
1	7512328	Bolt	7	7721103	Square Key
2	7577908	Lock Washer	8		See Chaincase Assembly
3	5221207	Clutch Cap	9	7512487	Carriage Bolt
4	3211021	Drive Belt <i>3211044</i>	10	7512497	Bolt
5	1322088	Driven Clutch	11	7542423	Flanged Nut
6	7556401	Machinery Bushing			




DRIVE CLUTCH

[illegible]

DRIVEN CLUTCH


[illegible]

TRACK ASSEMBLY

[illegible]


DRIVE SHAFT

ITEM NO.	PART NO.	PART DESCRIPTION	ITEM NO.	PART NO.	PART DESCRIPTION
1	7713901	Retaining Ring	8	7512394	Carriage Bolt
2	7511967	Cap Screw	9	5221172	Flangette
3	5221337	Sprocket Hub	10	7542320	Lock Nut
4	5430282	Sprocket	11	7512308	Set Screw
5	7541906	Lock Nut	12	5332417	Spacer
6	1590167	Drive Shaft Weldment	13	7558403	Washer
7	3514501	Bearing w/Lock Collar			



MAIN WIRE HARNESS


ITEM NO.	PART NO.	PART DESCRIPTION	ITEM NO.	PART NO.	PART DESCRIPTION
	2460186	Main Harness (Incl. 1 - 7)	5	2200020	2 Circuit Housing Kit
1	2200022	Receptacle Housing w/Receptacles	6	2200094	3 Circuit Housing Kit
2	2200074	6 Circuit Tab Housing w/Tabs	7	2200095	2 Circuit Housing Kit
3	2200156	2 Circuit Housing Kit	8	2200082	Brake Light Connector Kit
4	7080046	Panduit Strap			



SUSPENSION

[illegible]


SUSPENSION



ENGINE MOUNTING – 244

[illegible]


ENGINE MOUNTING - 244



ENGINE MOUNTING – 250, 250 & 340 SS

[illegible]


ENGINE MOUNTING – 250, 250 & 340 SS
(Fan Cooled Engine Not Shown)



CRANKCASE & CYLINDER – 244

[illegible]


CRANKCASE & CYLINDER - 244




CRANKCASE & CYLINDER – 250

[illegible]


CRANKCASE & CYLINDER - 250



CRANKCASE & CYLINDER - 250 & 340 SS




CRANKSHAFT & PISTON — 244



CRANKSHAFT & PISTON – 250, 250 & 340 SS

[illegible]


CRANKSHAFT & PISTON — 250, 250 & 340 SS



RECOIL STARTER – 244

[illegible]

RECOIL STARTER - 244




RECOIL STARTER – 250

ITEM NO.	PART NO.	PART DESCRIPTION	ITEM NO.	PART NO.	PART DESCRIPTION
	3082208	Recoil Starter Ass'y. (Incl. 1 - 12, 14 - 19)	11	3081087	Spring Washer
1	3080903	Starter Case	12	3081086	Nut
2	3081234	Power Spring	13	3081084	Starting Pulley
3	3080904	Reel	14	3080620	Wire Rope
4	3082115	Ratchet	15	3080335	Wire Guide
5	3082116	Return Spring (B)	16	3080212	Starter Handle
6	3080500	Washer (A)	17	3080336	Wire Clamp (A)
7	3081238	Friction Spring	18	3080337	Wire Clamp (B)
8	3082118	Return Spring	19	7080072	Eye Bolt
9	3082119	Friction Plate	20	3080146	Bolt
10	3081240	Washer (B)	21	3080077	Spring Washer
			22	3080146	Bolt

FOR ENGINES EQUIPPED WITH NYLON ROPE

	3082413	Recoil Starter Ass'y.	11	3081087	Spring Washer
1	3082417	Recoil Case	12	3081086	Nut
2	3082415	Power Spring	13	3082326	Starting Pulley
3	3082317	Reel	14	3082416	Rope
4	3082318	Ratchet	15		Not Used
5	3082319	Return Spring	16	3081578	Starter Handle
6	3082320	Washer (A)	17		Not Used
7	3081238	Friction Spring	18		Not Used
8	3082118	Return Spring	19	7080072	Eye Bolt
9	3082322	Friction Plate	20	3080146	Bolt
10	3081240	Washer (B)	21	3080077	Spring Washer
			22	3080291	Bolt


RECOIL STARTER - 250



RECOIL STARTER – 250 & 340 SS

[illegible]

RECOIL STARTER — 250 & 340 SS



MAGNETO – 244

[illegible]


This exploded view diagram illustrates the assembly of a vehicle's rear wheel and suspension components. The parts are numbered as follows:

- 1**: Rear wheel hub assembly
- 2**: Brake caliper
- 3**: Caliper pin
- 4**: Brake pad
- 5**: Brake pad
- 6**: Piston pin
- 7**: Piston pin
- 8**: Piston pin
- 9**: Piston pin
- 10**: Piston pin
- 11**: Piston pin
- 12**: Brake line
- 13**: Brake line
- 14**: Brake line
- 15**: Brake line
- 16**: Brake line
- 17**: Brake line
- 18**: Brake line
- 19**: Brake line
- 20**: Brake line
- 21**: Brake line
- 22**: Brake line
- 23**: Brake line
- 24**: Brake line
- 25**: Brake line
- 26**: Brake line
- 27**: Brake line
- 28**: Brake line
- 29**: Brake line
- 30**: Brake line
- 31**: Brake line

MAGNETO – 250

[illegible]


MAGNETO - 250



MAGNETO – 250 & 340 SS

[illegible]


MAGNETO - 250 & 340 SS



BLOWER HOUSING – 244

[illegible]


BLOWER HOUSING - 244



BLOWER HOUSING – 250 & 340 SS

[illegible]


BLOWER HOUSING – 250 & 340 SS




CARBURETOR – 244

[illegible]

CARBURETOR - 244



CARBURETOR - 250




This technical diagram illustrates the exploded view of a carburetor assembly, showing the relationship between various components. The parts are numbered as follows:

- 1**: Main carburetor body
- 2**: Top cap
- 3**: Spring
- 4**: Gasket
- 5**: Pin
- 6**: Needle
- 7**: Needle valve
- 8**: Needle screw
- 9**: Jet
- 10**: Jet gasket
- 11**: Jet holder
- 12**: Jet holder nut
- 13**: Jet holder screw
- 14**: Jet holder spring
- 15**: Jet holder pin
- 16**: Jet holder pin
- 17**: Jet holder pin
- 18**: Jet holder pin
- 19**: Jet holder pin
- 20**: Jet holder pin
- 21**: Jet holder pin
- 22**: Jet holder pin
- 23**: Jet holder pin
- 24**: Jet holder pin
- 25**: Jet holder pin
- 26**: Jet holder pin
- 27**: Jet holder pin
- 28**: Jet holder pin
- 29**: Jet holder pin
- 30**: Jet holder pin
- 31**: Jet holder pin
- 32**: Jet holder pin

FUEL PUMP – 244

[illegible]


FUEL PUMP - 244



FUEL PUMP – 250, 250 & 340 SS

[illegible]

FUEL PUMP — 250, 250 & 340 SS





9740







Polaris E-Z-Go Division of Textron Inc.

Part No. 9910416

\$3.00

PRINTED IN U.S.A.
Polaris
IN-PLANT