

YAMAHA

PARTS LIST

SW-396




FOREWORD

This Parts List relates to the parts in use for the YAMAHA SNOW MOBILE SW-396. When you are ordering replacement parts for the SW-396, refer to this Parts List and quote both part numbers and part names correctly.

1. Structure of Part No.

Yamaha parts are divided largely into two categories; regular parts and standard parts, and each part No. has the following structure:



Note: Every standard No. begins with 9.

2. How to Use this Parts List

- (1) Except for steel balls (whose size is indicated in inches), the size of all parts is indicated in millimeters in the following manner.

Pipe (rubber or vinyl) Inside diameter - length

O-ring Sectional area - inside diameter

Washer, shim, collar Inside diameter - outside diameter - thickness (length)

- (2) Parts, which are to be supplied in the form of assemblies, are listed with an indention of one letter's space, and a dot (.) is put

against the name of each part. If any two different assemblies (e.g., right and left side components) consist of almost the same type components, these two assemblies are listed in two lines, and then the names of component parts are listed in the subsequent lines with an indentation as mentioned earlier. The quantity of parts is given in the following manner; that is, in the case of parts being the same in type between the right and left, a total quantity of parts is given. On the other hand, if the right and left side parts are different in type, the quantity of part(s) on each side is given.

Example

Description	Qt'y
CARBURETOR ASS'Y, left	1
CARBURETOR ASS'Y, right	1
. JET, pilot	2
. NOZZLE, main	2
.	
.	
.	
. LEVER, starter, left	1
. LEVER, starter, right	1

(3) Key to Symbols

L.H		Left hand side (viewed from rider's seat facing forward).
R.H		Right hand side (viewed from rider's seat facing forward).
S. R		Suggested retail price
U. R		Use size (thickness) and/or number as required
		Government inspected parts
T		Number of teeth in a gear
V		Voltage for light bulbs
S		"S" type oil seal or "S" type circlip
SD		"SD" type oil seal

SO "SO" type oil seal
SW "SW" type oil seal
E "E" type circlip
R "R" type circlip
F/No. . . Frame No. (Applicable machine No.)

- (4) The right and left in relation to parts are determined on the basis of the rider facing toward the front.
- (5) This Parts List is based on the model in the production line on June 1, 1970. Accordingly, if any modifications which have been made to parts will be announced in the Yamaha Parts News. Frame Nos. of motorcycles, to which this Parts List is applicable, are referred to in the Parts List, so that you will be able to check whether your motorcycles are covered by this Parts List. It is advisable that according to the Yamaha Parts News, you will make necessary corrections to the Parts List on hand to keep it u-to-dated.

Fig. 28	Seat & Luggage Box	79
Fig. 29	Bumper	83
Fig. 30	Head Lamp	85
Fig. 31	Tail Lamp	87
Fig. 32	Electrical	89

ALTERNATE PARTS


Fig. 33	Starting Pump	93
Fig. 34	Speedometer	95
Fig. 35	Tachometer	97
No Fig. 36	Electric Starter	99
Fig. 37	Accessory Parts	105

NUMERICAL INDEX

ENGINE



ENGINE



CRANKCASE


Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
1- 0-1	811-15100-00	CRANK CASE ASS'Y	1		
1- 1	811-15111-00	. CASE, crank 1	1		Not for sale
1- 2	811-15121-00	. CASE, crank 2	1		Not for sale
1- 3	91810-08016	PIN, dowel A (9.8-12-16)	2		
1- 4	810-15491-00	PROTECTOR	1		
1- 5	97101-08060	BOLT	5		
1- 6	97101-08070	BOLT	3		
1- 7	97101-08050	BOLT	4		
1- 8	92901-08200	WASHER, plain	12		
1- 9	248-11361-00	BOLT, cylinder holding	8		
1-10	811-11351-00	GASKET, cylinder	2		
1-11	811-11311-00	CYLINDER, left	1		
1-12	811-11321-00	CYLINDER, right	1		
1-13	811-11181-00	GASKET, cylinder head	2		
1-14	811-11111-00	HEAD, cylinder left	1		
1-15	811-11121-00	HEAD, cylinder right	1		
1-16	807-11171-00	NUT, cylinder holding	8		
1-17	92901-12200	WASHER, plain	8		
1-18	92501-06010	SCREW, pan head	2		
1-19	137-15384-00	GASKET, screw	2		
1-20	807-24461-00	PIPE, joint	1		
1-21	806-24356-00	CLIP, pipe	1		
1-22	807-24462-09	CAP, blind	1		
1-23	94700-00004	PLUG, spark (B-7HZ)	2		

[illegible]

FAN CASE & AIR SHROUD

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
2-25	92901-08200	WASHER, plain	2		
2-26	98801-08100	NUT	1		


Fig. 3 CRANK & PISTON



CRANK & PISTON

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
3- 0-1	811-11400-00	CRANK ASS'Y	1		
3- 1	811-11412-00	. CRANK 1, left	1		
3- 2	811-11422-00	. CRANK 1, right	1		
3- 3	807-11432-00	. CRANK 2, left	1		
3- 4	807-11442-00	. CRANK 2, right	1		
3- 5	235-11651-00	. ROD, connecting	2		
3- 6	93310-42434	. BEARING, con-rod big end (24-31-7) ..	2		
3- 7	152-11685-00	. WASHER, crank pin (24.2-38-1) ..	4		
3- 8	168-11681-00	. PIN, crank	2		
3- 9	93306-20602	. BEARING (6206C3)	2		
3-10	811-11515-00	. SEAL, labyrinth	1		
3-11	93306-30603	. BEARING (6303C3)	1		
3-12	93306-20602	. BEARING (6206C3)	1		
3-13	93310-21824	BEARING, con-rod small end (18-22-22) .	2		
3-14	811-11631-00-96	PISTON (0.96) (STD).....	} U. R 2		
	811-11631-00-97	PISTON (0.97) (STD).....			
	811-11631-00-98	PISTON (0.98) (STD).....			
	811-11631-00-99	PISTON (0.99) (STD).....			
	811-11635-00	PISTON (1st O.S)	2		
	811-11636-00	PISTON (2nd O.S)	2		
3-15	807-11601-00	PISTON RING SET (STD)	2s		
	807-11601-10	PISTON RING SET (1st O.S)	2s		
	807-11601-20	PISTON RING SET (2nd O.S)	2s		

Fig. 3 CRANK & PISTON




FWD

CRANK & PISTON

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
3-16	168-11633-00	PIN, piston	2		
3-17	604-11634-00	CLIP, piston pin	4		
3-18	93440-78011	CIRCLIP	1		
3-19	93103-32054	OIL SEAL (SW-32-78-10)	1		
3-20	214-11545-01	KEY, woodruff	1		
3-21	93103-32055	OIL SEAL (SW-32-48-10)	1		
3-22	93604-12037	PIN, dowel (4-12)	5		


Fig. 4 INTAKE



INTAKE

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
4- 1	811-13557-00	GASKET, carburetor 1	1		
4- 2	811-13555-00	JOINT	2		
4- 3	811-13563-00	GASKET 2	2		
4- 4	811-13565-00	JOINT, manifold	1		
4- 5	92901-08200	WASHER, plain	4		
4- 6	92901-08100	WASHER, spring	4		
4- 7	97101-08035	BOLT	2		
4- 8	93210-07003	O-RING (1.9-6.8)	2		
4- 9	91308-08030	BOLT	2		
4-10	811-13558-00	STUD	2		
4-11	811-13567-00	GASKET, carburetor 2	1		
4-12	98801-08300	NUT	2		
4-13	810-14479-00	FUNEL	1		
4-14	92501-06010	SCREW, pan head	3		
4-15	810-13566-00	GASKET 3	1		
4-16	811-13556-00	GASKET 4	1		
4-17	811-13571-00	WASHER, special	2		


Fig. 5 CARBURETOR



CARBURETOR

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
5- 0-1	811-14101-00	CARBURETOR ASS'Y	1		
5- 1	127-14195-00	. WASHER, valve seat	1		
5- 2	620-14190-20	. VALVE SEAT ASS'Y	1		
5- 3	812-24423-00	. SPRING, diaphragm	1		
5- 4	812-14387-00	. ARM, diaphragm	1		
5- 5	812-14186-00	. PIN, lever	1		
5- 6	98602-03007	. SCREW, oval head	1		
5- 7	812-24471-00	. DIAPHRAGM, main	1		
5- 8	812-24412-00	. BODY 1	1		
5- 9	812-24434-00	. GASKET	3		
5-10	812-24411-00	. DIAPHRAGM, pump	1		
5-11	812-24413-00	. BODY 2	1		
5-12	812-24435-00	. GASKET, body 2	1		
5-13	812-24421-00	. VALVE, check	1		
5-14	812-24414-00	. BODY 3	1		
5-15	812-24451-00	. NET, filter	1		
5-16	812-24468-00	. GASKET	1		
5-17	812-24452-00	. COVER	1		
5-18	812-24453-00	. SCREW	1		
5-19	92901-04100	. WASHER, spring	9		
5-20	98501-04032	. SCREW, pan head	6		
5-21	812-14147-00	. O-RING	2		
5-22	812-14235-00	. WASHER, needle	2		
5-23	137-14134-00	. SPRING, air adjusting	2		


Fig. 5 CARBURETOR



CARBURETOR

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
5-24	812-14123-00	. SCREW, slow adjusting	1		
5-25	811-14582-00	. LEVER, pump	1		
5-26	812-14596-00	. WASHER	1		
5-27	812-14594-00	. NUT	1		
5-28	812-14125-00	. SCREW, main adjusting	1		
5-29	193-14486-00	. SCREW, rod	1		
5-30	811-14117-00	. WASHER, screw plug	1		
5-31	98302-23003	. SCREW, cylinder head	1		
5-32	811-14133-00	. SPRING, throttle stop	1		
5-33	98302-04014	. SCREW, cylinder head	1		
5-34	193-14486-00	. SCREW, rod	1		
5-35	811-14571-00	. BRACKET, throttle	1		
5-36	98502-04008	. SCREW, pan head	2		
5-37	811-14243-00	. PLATE, choke	1		
5-38	811-14486-00	. SCREW, rod	1		


Fig. 6 PIPING



PIPING

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
6- 1	807-24314-00	PIPE 4 (7-555)	1		
6- 2	811-24312-00	PIPE 2 (7-750)	1		
6- 3	810-24315-00	PIPE 5 (6-150)	1		
6- 4	810-24357-00	CLIP, pipe 2	4		
6- 5	810-24360-00	PRIMER PUMP ASS'Y	1		
6- 6	601-24353-00	. BAND, fuel pipe 3	2		
6- 7	810-24328-00	PROTECTOR, pipe rear	1		
6- 8	806-24356-00	CLIP, pipe 1	2		
6- 9	811-24322-00	PROTECTOR, pipe	1		


Fig. 8 STARTER



STARTER

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
8- 0-1	811-15710-00	STARTER ASS'Y	1		
8- 1	811-15711-00	. CASE, starter	1		
8- 2	811-15714-00	. DRUM, sheave	1		
8- 3	811-15713-00	. SPRING, starter	1		
8- 4	811-15741-00	. PAWL, drive	3		
8- 5	811-15719-00	. WASHER, thrust	1		
8- 6	807-15715-00	. SPRING, drive plate	1		
8- 7	811-15734-00	. SPRING, return	3		
8- 8	811-15784-00	. SPRING, return	1		
8- 9	811-15716-00	. PLATE, drive	1		
8-10	807-15726-01	. WASHER, flat	1		
8-11	92901-08100	. WASHER, spring	1		
8-12	98801-08300	. NUT	1		
8-13	807-15751-00	. ROPE	1		
8-14	807-15755-00	. HANDLE, starter	1		
8-15	619-15756-00	. CONNECTOR	1		
8-16	807-15782-00	. COVER, sheave	1		
8-17	98501-05008	. SCREW, pan head	3		
8-18	92901-05100	. WASHER, spring	3		
8-19	811-15723-00	PULLEY, starter	1		
8-20	97201-08015	BOLT	3		
8-21	92901-08100	WASHER, spring	3		
8-22	91201-06015	BOLT	4		
8-23	92901-06100	WASHER, spring	4		


Fig. 9 FLYWHEEL MAGNETO



FLYWHEEL MAGNETO

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
9-23	92901-06100	WASHER, spring	8		
9-24	92901-06200	WASHER, plain	8		
9-25	168-11555-00	NUT, crank shaft	1		
9-26	92901-16100	WASHER, spring	1		
9-27	807-11557-00	WASHER, plain	1		

Fig. 10 OIL PUMP




FWD

OIL PUMP

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
10- 1	126-13116-00	GASKET, pump case	1		
10- 2	802-13175-00	SHAFT, worm	1		
10- 3	93603-22028	PIN, dowl (3-21.8)	1		
10- 4	137-13176-00	METAL, worm shaft outer	1		
10- 5	807-13199-00	BRACKET, pump	1		
10- 6	93101-10002	OIL SEAL (S-10-22-7)	1		
10- 7	810-13178-00	PULLEY, pump drive	1		
10- 8	810-13189-00	BELT	1		
10- 9	137-13129-00	WASHER, wave	1		
10-10	137-13148-00	PLATE, cam thrust (10.2-16.5-0.3)	1		
10-11	93410-10001	CIRCLIP (S-10)	1		
10-12	98501-05015	SCREW, pan head	2		
10-13	92501-06020	SCREW, pan head	3		
10-14	92901-06100	WASHER, spring	2		
10-15	806-77323-00	PROTECTOR, drive	1		
10- 0-1	811-13101-00	OIL PUMP ASS'Y	1		
10-16	137-13137-00	. SHIM, plunger (5.8-10-0.1)	U.R		
10-17	137-13138-01	. PLATE, adjusting	1		
10-18	92901-05100	. WASHER, spring	1		
10-19	98801-05200	. NUT	1		
10-20	93101-10001	. OIL SEAL (S-10-21-5)	1		
10-21	137-13128-00	. PLATE, starter	1		
10-22	91401-12018	. PIN, cotter	1		

Fig. 10 OIL PUMP




OIL PUMP

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
----------	-----------	-------------	------	---------------------------	---------

10-45	91402-12008	PIN, cotter	1		
-------	-------------	-------------------	---	--	--

10-46	98801-03200	NUT	2		
-------	-------------	-----------	---	--	--

Fig. 11 ENGINE COWL



FWD

ENGINE COWL

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
11- 1	811-77411-00	COWL, engine	1		
11- 2	807-77424-00	BRACKET, spring	1		
11- 3	811-77459-00	RIVET	10		
11- 4	811-77478-00	HINGE, lid lower	2		
11- 5	811-77436-00	WASHER, special (4.1-8-1)	8		
11- 6	811-77461-00	DAMPER, lid	2		
11- 7	91206-06020	BOLT	4		
11- 8	92906-06100	WASHER, spring	4		
11- 9	811-77728-00	WASHER	4		
11-10	811-77425-00	LID, engine cowl	1		
11-11	811-77475-00	HINGE, lid upper left	1		
11-12	811-77476-00	HINGE, lid upper right	1		
11-13	807-77446-00	BUSHING	1		
11-14	615-42751-00	WASHRR, plain (8.5-22-1)	1		
11-15	811-42753-00	FASTNER	1		
11-16	811-77351-00	EMBLEM	1		




DRIVE



DRIVE




Fig. 12 PRIMARY SHEAVE



PRIMARY SHEAVE

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
12- 1	810-17630-00	PRIMARY SHEAVE CAP COMP.	1		
12- 2	806-17647-00	BOLT	1		
12- 3	810-17646-00	WASHER, lock	1		
12- 4	810-17658-00	WASHER	1		
12- 5	93410-30012	CLIP (S-30)	1		
12- 6	806-17645-00	COLLAR	2		
12- 7	810-17620-01	PRIMARY SLIDING SHEAVE COMP. 1			
12- 8	806-17643-01	SPRING, primary	1		
12- 9	810-17642-00	NUT, bearing	1		
12-10	806-17648-00	WASHER (28-36-2)	1		
12-11	806-17644-00	SEAT, spring	1		
12-12	93306-20512	BEARING (6205)	1		
12-13	810-17610-00	PRIMARY FIXED SHEAVE COMP. ...	1		
12-14	806-17641-00	V-BELT	1		


Fig. 13 SECONDARY SHEAVE



SECONDARY SHEAVE

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
13- 1	810-17660-00	SECONDARY FIXED SHEAVE COMP.	1		
13- 2	810-17670-00	SECONDARY SLIDING SHEAVE COMP.	1		
13- 3	810-17681-00	SHAFT, secondary	1		
13- 4	91609-80040	PIN, spring	1		
13- 5	805-17683-00	SPRING, secondary	1		
13- 6	810-17684-00	SEAT, spring	1		
13- 7	801-17688-10	SHOE, lamp	3		
13- 8	802-17685-00	COLLAR, distance 1	1		
13- 9	806-17682-30	SPROCKET, chain drive (13T)	1		
13-10	802-17695-00	COLLAR, distance 3	1		
13-11	810-17686-00	COLLAR 2	1		
13-12	150-17417-00-02	SHIM (17.2-25-0.2)	} U. R. 1		
	150-17417-00-03	SHIM (17.2-25-0.3)			
	150-17417-00-04	SHIM (17.2-25-0.4)			
	150-17417-00-05	SHIM (17.2-25-0.5)			
	150-17417-00-06	SHIM (17.2-25-0.6)			
	150-17417-00-07	SHIM (17.2-25-0.7)			


Fig. 14 TRACK DRIVE



TRACK DRIVE

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
14- 1	810-47541-00	HOUSING, chain	1		
14- 2	93210-25070	O-RING (3.2-24.5)	1		
14- 3	810-47571-00	JOURNAL	1		
14- 4	93102-40080	OIL SEAL (SD-40-55-8)	1		
14- 5	93420-55028	CIRCLIP (R-55)	2		
14- 6	93306-90701	BEARING (6907)	2		
14- 7	802-47549-00	COLLAR	1		
14- 8	802-47548-40	SPROCKET, chain driven (25T)	1		
14- 9	810-47554-00	WASHER, lock	1		
14-10	810-47553-00	BOLT	1		
14-11	94804-25062	CHAIN (DA425-2 62L)	1		
14-12	94904-25001	. JOINT, chain	1		
14-13	806-47543-00	CAP, housing	1		
14-14	806-47558-00	RING, rubber housing	1		
14-15	806-47542-00	BOLT	6		
14-16	802-47545-00	WASHER	6		
14-17	802-47546-01	LEVEL, oil	1		
14-18	97202-08070	BOLT	4		
14-19	92902-08100	WASHER, spring	4		
14-20	92902-08200	WASHER, plain	4		
14-21	810-47559-00	CAP 2	1		
14-22	93306-00301	BEARING (6003)	1		
14-23	93102-22082	OIL SEAL (SD-22-32-6)	1		
14-24	93211-13109	O-RING (3.1-113)	2		

Fig. 14 TRACK DRIVE




FWD

TRACK DRIVE

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
14-25	810-47561-00	HOUSING, secondary shaft left	1		
14-26	97202-08060	BOLT	2		
14-27	92901-08100	WASHER, spring	2		
14-28	93306-30401	BEARING (6304)	1		
14-29	93102-30083	OIL SEAL (SD-30-47-7)	1		
14-30	810-47562-00	HOUSING, secondary shaft right	1		
14-31	93604-18058	PIN, dowel (4-17,8)	2		


Fig. 16 FRONT AXLE



FRONT AXLE

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
16- 1	811-47510-00	FRONT AXLE COMP.	1		
16- 2	810-47575-00	PLUG 1	1		
16- 3	810-47531-00	WHEEL, sprocket 1	1		
16- 4	810-47526-00	COLLAR	4		
16- 5	810-47522-00	RIM, sprocket wheel 2	1		
16- 6	91102-06035	BOLT	4		
16- 7	810-47517-00	WASHER, lock	2		
16- 8	810-47530-00	GUIDE WHEEL COMP.	2		
16- 9	810-47536-00	COLLAR	4		
16-10	810-47539-00	WASHER, lock	4		
16-11	97102-05015	BOLT	8		
16-12	93102-25084	OIL SEAL (SD-25-34-7)	1		
16-13	93306-00412	BEARING (6004)	1		
16-14	93420-44029	CIRCLIP (R-44)	1		
16-15	810-47551-00	HOUSING, front axle	1		
16-16	91202-06025	BOLT	3		
16-17	92901-06100	WASHER, spring	3		
16-18	810-47581-00	WASHER	1		
16-19	810-47579-00	NUT	1		
16-20	810-47552-00	CAP	1		


Fig. 17 REAR AXLE



REAR AXLE

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
17- 1	811-47520-00	REAR AXLE COMP.	1		
17- 2	810-47522-00	RIM, sprocket wheel 2	1		
17- 3	810-47532-00	WHEEL, sprocket 2	1		
17- 4	810-47526-00	COLLAR	4		
17- 5	91102-06035	BOLT	4		
17- 6	810-47517-00	WASHER, lock	2		
17- 7	810-47530-00	GUIDE WHEEL COMP.	2		
17- 8	810-47536-00	COLLAR	2		
17- 9	97102-05015	BOLT	8		
17-10	810-47539-00	WASHER, lock	4		
17-11	810-47361-00	ARM, pivot rear left	1		
17-12	810-47362-00	ARM, pivot rear right	1		
17-13	806-47363-00	SPRING, rear left	1		
17-14	806-47364-00	SPRING, rear right	1		
17-15	810-47367-00	SCREW, pivot rear	2		
17-16	810-47369-00	COLLAR	2		
17-17	810-47374-00	WASHER, inside	2		
17-18	619-42546-00	NUT	2		
17-19	92902-08200	WASHER, plain	2		
17-20	91402-30025	PIN, cotter	2		
17-21	806-47373-00	SCREW, track adjust	2		
17-22	810-47378-00	WASHER, lock	2		
17-23	93102-25081	OIL SEAL (SD-25-44-6)	2		
17-24	93420-44029	CIRCLIP (R-44)	4		

Fig. 18 TRACK & SUSPENSION WHEEL



← FWD

TRACK & SUSPENSION WHEEL


Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
18- 1	811-47110-00	TRACK ASS'Y	1		
18- 2	807-47331-00	ARM, pivot	6		
18- 3	810-47335-00	SPRING	6		
18- 4	807-47337-00	SHAFT, pivot	3		
18- 5	97101-08030	BOLT	6		
18- 6	806-47347-00	WASHER, lock	6		
18- 7	810-47310-00	SUSPENSION WHEEL ASS'Y	12		
18- 8	802-47338-01	COLLAR	12		



BODY




Fig. 19 FRAME



FRAME

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
19- 1	811-21910-00	FRAME COMP.	1		
19- 0-1	807-77170-00	LATCH ASS'Y	2		
19- 2	807-77172-00	. BODY, latch lower	2		Not for sale
19- 3	806-77173-00	. LEVER, latch	2		
19- 4	214-24758-00	. SPRING, seat	2		
19- 5	214-24727-00	. PIN, seat fitting	2		
19- 6	97201-05015	BOLT	4		
19- 7	92901-05100	WASHER, spring	4		
19- 8	806-77178-00	WASHER 1 (5.5-14-1.2)	4		
19- 9	806-27413-00	COVER, footrest, left	1		
19-10	806-27423-00	COVER, footrest, right	1		
19-11	802-77592-00	BRACKET, hich 2	1		
19-12	91201-06040	BOLT	2		
19-13	92901-06100	WASHER, spring	2		
19-14	802-77591-00	BRACKET, hich 1	1		
19-15	91701-08102	PIN, clevis	1		
19-16	92901-08200	WASHER, plain	1		
19-17	91401-25012	PIN, cotter	1		
19-18	811-77354-00	EMBLEM 4	2		
19-19	807-77595-01	FLAP	1		
19-20	807-77593-00	PLATE, flap	2		
19-21	91201-06015	BOLT	2		
19-22	92901-06100	WASHER, spring	2		


Fig. 20 SHROUD



SHROUD

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
20- 1	807-77111-00	SHROUD	1		
20- 2	806-77171-00	BODY, latch upper	2		
20- 3	811-77138-00	CLAMP, upper	2		
20- 4	806-77155-00	RIVET	16		
20- 5	807-77166-00	TRIM, shroud rear	1		
20- 6	811-77163-00	ORNAMENT, shroud left	1		
20- 7	811-77164-00	ORNAMENT, shroud right	1		
20- 8	806-77145-00	HINGE, upper	2		
20- 9	806-77147-00	HINGE, lower	2		
20-10	806-77157-00	PIN, hinge	2		
20-11	806-77198-00	DAMPER, front	2		
20-12	810-77199-00	DAMPER, rear	2		
20-13	810-77153-00	PLATE, back up	2		
20-14	92901-06100	WASHER, spring	8		
20-15	98801-06100	NUT	8		
20-16	811-84311-00	BODY, head lamp	1		
20-17	98906-05012	SCREW, bind	1		
20-18	807-77139-00	HOLDER, rod upper	1		
20-19	811-77118-00	STOPPER, shroud	1		
20-20	807-77159-00	CLAMP, rod	1		
20-21	97206-05015	BOLT	3		
20-22	807-84344-00	WASHER, plain	5		
20-23	97206-05020	BOLT	2		
20-24	92906-05100	WASHER, spring	2		


Fig. 20 SHROUD



SHROUD

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
20-25	92906-05200	WASHER, plain	2		
20-26	807-77210-00	WIND SHIELD COMP.	1		
20-27	807-77213-00	, TRIM, upper	1		Not for sale
20-28	807-77214-00	TRIM, lower	1		
20-29	98903-05015	SCREW, bind	7		
20-30	802-77217-00	NUT	7		
20-31	810-77179-00	WASHER 2	2		
20-32	810-77136-00	CLAMP, upper 2	2		
20-33	806-77178-00	WASHER 1	6		
20-34	92901-05100	WASHER, spring	6		
20-35	97201-05010	BOLT	6		


Fig. 21 ENGINE BRACKET



ENGINE BRACKET

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
21- 1	810-21411-00	BRACKET, engine upper	1		
21- 2	91201-10050	BOLT	4		
21- 3	92901-10100	WASHER, spring	4		
21- 4	92901-10200	WASHER, plain	4		
21- 5	807-15316-00	DAMPER, engine mount	8		
21- 6	807-15317-00	SPACER, damper	4		
21- 7	807-21491-00	WASHER 1 (10.5-52-3.2)	4		
21- 8	807-21492-00	WASHER 2 (10.5-52-1.6)	4		
21- 9	810-15176-00	WASHER, lock	4		
21-10	98801-10300	NUT	4		
21-11	807-21482-00	BOLT	4		
21-12	807-21419-00	BRACKET, engine lower	2		
21-13	810-21482-00	BOLT, engine mounting 2	3		
21-14	810-21492-00	WASHER, lock 2	3		
21-15	806-21481-00	BOLT, engine mounting	1		
21-16	806-21491-01	WASHER, lock	1		
21-17	806-77315-01	BRACKET, drive guard	1		
21-18	810-77311-00	GUARD, drive	1		
21-19	806-77314-00	ARM, fitting	1		
21-20	93430-06005	CIRCLIP (E-6)	1		
21-21	806-77324-00	KNOB	1		
21-22	802-77318-00	WASHER	2		
21-23	806-77325-00	SPRING	1		
21-24	91609-25016	PIN, spring	1		


Fig. 22 STEERING GATE



STEERING GATE

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
22- 1	811-23871-00	GATE, steering	1		
22- 2	97206-08018	BOLT	2		
22- 3	810-23895-00	WASHER, lock	2		
22- 4	810-77137-00	CLAMP, lower	2		
22- 5	810-77188-00	STOPPER	2		
22- 6	97206-08065	BOLT	2		
22- 7	806-77526-00	WASHER, lock	2		
22- 8	811-77711-00	PANEL, instrument	1		
22- 9	811-77746-00	GROMMET, steering column	1		
22-10	810-77715-00	ORNAMENT, instrument panel	2		
22-11	810-77716-00	ORNAMENT, instrument panel 2 ...	1		
22-12	102-82598-00	GROMMET, wire harness	1		
22-13	811-26331-00	WIRE, choke	1		
22-14	810-27411-00	FOOTREST, left	1		
22-15	810-27421-00	FOOTREST, right	1		
22-16	91201-06012	BOLT	4		
22-17	92901-06200	WASHER, plain	6		
22-18	92901-06100	WASHER, spring	4		
22-19	98801-06100	NUT	4		
22-20	810-82591-00	BAND	2		

Fig. 23 STEERING



STEERING

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
23- 1	811-23811-00	COLUMN, steering	1		
23- 2	806-23875-00	BEARING, steering lower	1		
23- 3	811-23821-00	ROD, steering relay	2		
23- 4	802-23833-00	NUT 1	2		
23- 5	802-23834-00	NUT 2	2		
23- 6	806-23841-00	JOINT, universal 1	2		
23- 7	806-23845-00	JOINT, universal 2	2		
23- 8	810-23846-00	NUT	4		
23- 9	91401-25025	PIN, cotter	4		
23-10	810-23851-00	ARM, outside, left	1		
23-11	810-23852-00	ARM, outside, right	1		
23-12	810-23853-00	COLUMN, ski, left	1		
23-13	810-23854-00	COLUMN, ski, right	1		
23-14	801-23855-00	SPRING, damper	2		
23-15	98806-12100	NUT	2		
23-16	810-23857-00	WASHER, lock	2		
23-17	93700-06001	NIPPLE, grease	2		
23-18	810-23861-00	BAR, tension	1		
23-19	98806-06300	NUT	2		
23-20	92906-06200	WASHER, plain	3		
23-21	156-83525-00	CLIP	1		
23-22	91106-06015	BOLT	2		
23-23	810-23894-00	WASHER, lock	1		
23-24	168-83936-00	BAND, switch cord	3		


Fig. 24 SKI



SKI

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
24- 1	806-23710-00	SKI COMP.	2		
24- 2	806-23731-00	RUNNER	2		
24- 3	806-23738-00	WASHER, runner stud (6.3-14-2) ...	2		
24- 4	603-24149-00	NUT	4		
24- 0-1	811-23760-00	SPRING ASS'Y, left	1		
24- 0-2	811-23770-00	SPRING ASS'Y, right	1		
24- 5	811-23761-00	. LEAF 1	2		
24- 6	811-23762-00	. LEAF 2	2		
24- 7	811-23763-00	. LEAF 3	2		
24- 8	810-23763-00	. LEAF 3	2		
24- 9	810-23764-00	. LEAF 4	2		
24-10	811-23769-00	. BOLT	4		
24-11	802-23768-00	. SEAT, spring lower	2		
24-12	806-23766-00	. SADDLE	2		
24-13	806-23779-00	. WASHER	2		
24-14	92806-10100	. NUT	4		
24-15	801-23733-00	PIN, retaining	4		
24-16	92906-08200	WASHER, plain	4		
24-17	91401-30020	PIN, cotter	4		
24-18	802-23735-00	PLATE, wear	2		
24-19	810-23767-00	BOLT	2		
24-20	92806-10500	NUT, slotted	2		
24-21	91401-20025	PIN, cotter	2		


Fig. 25 GRIP & WIRING



GRIP & WIRING

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
25- 1	801-26241-00	GRIP	2		
25- 2	803-83912-00	LEVER, left	1		
25- 3	802-83913-00	COLLAR, lever	1		
25- 4	803-83915-00	SCREW, lever fitting	1		
25- 5	98801-05300	NUT	1		
25- 6	806-26340-00	BRAKE WIRE ASS'Y	1		
25- 7	806-42138-00	LEVER, throttle	1		
25- 8	810-82821-00	HOLDER, lever throttle	1		
25- 9	802-83923-00	COLLAR, lever	2		
25-10	810-83925-00	SCREW, lever fitting	1		
25-11	98801-06300	NUT	1		
25-12	92901-06200	WASHER, plain	2		
25-13	810-26311-00	WIRE, throttle	1		
25-14	168-83936-00	BAND, switch cord	1		


Fig. 26 FUEL TANK



FUEL TANK

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
26- 1	811-24111-00	TANK, fuel	1		
26- 2	810-24611-00	BODY, cap	1		
26- 3	806-24612-00	PACKING, cap	1		
26- 4	811-24181-00	DAMPER, tank locating left	1		
26- 5	811-24182-00	DAMPER, tank locating right	1		
26- 6	807-24184-00	DAMPER, tank locating front	2		
26- 7	810-24173-00	BAND, tank fitting 1	2		
26- 8	811-24199-00	BAND, tank fitting 2	2		
26- 9	806-24135-01	CLAMP	2		
26-10	806-24146-00	NUT, fuel tank	2		
26-11	806-24176-01	BOLT, tank fitting	2		
26-12	806-24169-00	WASHER, lock	2		
26-13	807-24183-00	DAMPER, tank locating upper	2		
26-14	810-24514-00	NET, filter	1		
26-15	256-11188-00	CLIP, pipe	1		
26-16	806-24335-00	PIPE, suction	1		
26-17	810-24357-00	CLIP, pipe 2	4		
26-18	806-24314-00	PIPE 4 (7-570)	1		
26-19	810-24326-00	PROTECTOR, pipe front	1		
26-20	810-24327-00	PROTECTOR, pipe	1		
26-21	809-24560-01	FILTER ASS'Y	1		
26-22	811-24558-00	HOLDER, filter	1		
26-23	97201-05010	BOLT	2		
26-24	92901-05100	WASHER, spring	2		


Fig. 26 FUEL TANK



FUEL TANK

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
26-25	92901-05200	WASHER, plain	2		
26-26	810-24644-00	BODY, cap 2	1		
26-27	810-24358-00	CLIP, pipe 3.	1		
26-28	811-24319-00	PIPE, Oil (5-755)	1		


Fig. 28 SEAT & LUGGAGE BOX



SEAT & LUGGAGE BOX

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
28- 1	811-24730-00	DOUBLE SEAT ASS'Y	1		
28- 1-1	811-24731-00	. COVER, double seat	1		
28- 2	809-24744-00	PLATE, seat fitting	2		
28- 3	92501-06015	SCREW, pan head	2		
28- 4	92901-06100	WASHER, spring	2		
28- 5	811-77391-00	LUGGAGE BOX	1		
28- 6	806-77352-00	EMBLEM 2	2		
28- 7	806-77353-00	EMBLEM 3	1		
28- 8	91201-06012	BOLT	4		
28- 9	806-77396-01	WASHER, lock	4		
28-10	810-24738-00	BRACKET, hook lower	1		
28-11	92506-06012	SCREW, pan head	3		
28-12	92906-06200	WASHER, plain	3		
28-13	98806-08100	NUT	1		
28-14	92906-08100	WASHER, spring	1		
28-15	92906-08200	WASHER, plain	1		
28-16	811-24760-00	SEAT LEVER ASS'Y	1		
28-17	810-24797-00	. BRACKET, seat back	1		
28-18	810-24794-00	. SPRING, seat back	1		
28-19	810-24793-00	. PIN, seat back	1		
28-20	810-24796-00	. HOOK, seat back	1		
28-21	811-24798-00	. BAND, seat back	1		
28-22	98506-05012	SCREW, pan head	2		
28-23	92906-05200	WASHER, plain	6		


Fig. 28 SEAT & LUGGAGE BOX



SEAT & LUGGAGE BOX

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
28-24	92906-05100	WASHER, spring	6		
28-25	811-24790-00	SEAT BACK ASS'Y	1		
28-26	806-24714-00	STOPPER, cushion	2		
28-27	97206-05010	BOLT	4		
28-28	811-28100-00	TOOL ASS'Y	1		☆
28-29	116-82131-00	BAND, battery	1		


Fig. 29 BUMPER



BUMPER

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
29- 1	807-77510-00	FRONT BUMPER COMP.	1		
29- 2	806-77523-00	END, bumper	2		
29- 3	98801-08100	NUT	2		
29- 4	92901-08100	WASHER, spring	4		
29- 5	92901-08200	WASHER, plain	2		
29- 6	97201-08015	BOLT	2		
29- 7	807-77541-00	BUMPER, rear	1		
29- 8	97203-08045	BOLT	2		
29- 9	97203-08018	BOLT	4		
29-10	92901-08100	WASHER, spring	6		
29-11	92901-08200	WASHER, plain	4		
29-12	807-77571-00	GRIP, passenger	1		
29-13	807-77575-00	COVER, passenger grip	2		
29-14	806-77515-00	BUSHING, rubber	4		
29-15	92603-06050	SCREW, orval head	4		
29-16	806-77573-00	NUT, special	4		


Fig. 30 HEAD LAMP



HEAD LAMP

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
30- 0-1	811-84310-00	HEAD LAMP UNIT ASS'Y	1		
30- 1	811-84320-00	. LENS ASS'Y	1		
30- 2	807-84314-00	. BULB, head lamp (12V 35/35W) ..	1		☆
30- 3	811-84312-00	. SOCKET	1		
30- 4	811-84315-00	. RIM, head lamp	1		
30- 5	807-84331-00	. SCREW, rim adjuster	2		
30- 6	807-84332-00	. SPRING, adjust screw	2		
30- 7	807-84334-00	. NUT, adjust	2		
30- 8	811-84338-00	. SCREW	1		
30- 9	807-84316-00	. NUT, special	1		
30-10	807-84351-00	. PIN, cotter	1		
30-11	98603-04015	SCREW, oval head	4		
30-12	807-84316-00	NUT, body fitting	1		
30-13	807-84318-00	STAY, head lamp left	1		
30-14	807-84319-00	STAY, head lamp right	1		


Fig. 31 TAIL LAMP



TAIL LAMP

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
31- 0-1	806-84710-01	TAIL LAMP UNIT ASS'Y	1		
31- 1	806-84711-00	. BASE, tail lamp	1		
31- 2	806-84714-00	. BULB, tail lamp (12V 10/5W).....	1		☆
31- 3	806-84712-00	. SEAT, base	1		
31- 4	806-84721-00	. LENS, tail lamp	1		
31- 5	806-84724-00	. SCREW, lens fitting	2		
31- 6	98802-04100	NUT	2		
31- 7	92902-04100	WASHER, spring	2		
31- 8	806-84717-00	CORD, tail lamp	1		
31- 9	102-82598-00	GROMMET, tail lamp	1		

Fig. 32 ELECTRICAL




ELECTRICAL

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
32- 1	810-82310-40	IGNITION COIL ASS'Y 1	1		
32- 2	810-82320-41	IGNITION COIL ASS'Y 2	1		
32- 3	98506-06020	SCREW, pan head	4		
32- 4	92906-06100	WASHER, spring	4		
32- 5	810-82314-00	COVER, ignition coil	1		
32- 6	117-82370-20	PLUG CAP ASS'Y	2		
32- 7	168-83936-00	BAND, switch cord	1		
32- 8	810-82508-20	MAIN SWITCH ASS'Y	1		
32- 9	806-82516-00	CAP, main switch	1		
32-10	806-82530-00	STOP SWITCH ASS'Y	1		
32-11	810-82591-00	BAND	3		

ALTERNATE PARTS



Fig. 33 STARTING PUMP (ALTERNATE PARTS)



STARTING PUMP (ALTERNATE PARTS)

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
33- 1	814-24360-00	STARTING PUMP ASS'Y	1		
33- 2	807-13171-02	PIPE, delivery right (3-150)	1		
33- 3	807-13161-02	PIPE, delivery left (3-90)	1		
33- 4	814-24362-00	VALVE, check	1		
33- 5	814-24515-00	PIPE 5 (3-330)	1		
33- 6	814-24379-00	PIPE, joint	1		
33- 7	810-24357-00	CLIP, pipe 2	2		


C



SPEEDOMETER (ALTERNATE PARTS)

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
34- 1	809-83510-40	SPEEDOMETER ASS'Y	1		
34- 2	102-83514-00	. PLATE, fitting	1		
34- 3	92901-05100	. WASHER, spring	2		
34- 4	98801-05100	. NUT	2		
34- 5	102-83517-20	. BULB, meter (12V 2W)	1		☆
34- 6	809-83536-40	. SOCKET, meter	1		
34- 7	803-83577-00	PLATE, fitting	1		
34- 8	809-83513-00	DAMPER 1	1		
34- 9	810-83550-00	SPEEDOMETER CABLE ASS'Y ...	1		
34-10	810-47721-10	COVER, housing	1		
34-11	98501-05012	SCREW, pan head	2		
34-12	810-47727-10	GASKET	1		
34-13	810-47723-10	BUSHING	1		
34-14	810-47741-10	GEAR, driven	1		
34-15	810-47714-10	BUSHING	2		
34-16	810-47711-10	HOUSING	1		
34-17	810-47717-10	SHIM (8.1-14-0.5)	1		
34-18	810-47731-10	GEAR, drive	1		
34-19	150-17843-00	BUSHING	1		
34-20	810-47712-10	JOURNAL	1		
34-21	98202-04012	SCREW, flat head	3		
34-22	93210-43141	O-RING (2.62-42.52)	1		
34-23	91201-06015	BOLT.....	2		


Fig. 35 TACHOMETER (ALTERNATE PARTS)



TACHOMETER (ALTERNATE PARTS)

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
35- 1	813-13199-00	BRACKET, pump	1		
35- 2	93101-10001	OIL SEAL (SD-10-21-5)	1		
35- 3	813-13176-00	METAL, worm shaft outer	1		
35- 4	813-13175-00	SHAFT, worm	1		
35- 5	813-17841-00	GEAR, driven	1		
35- 6	813-17843-00	BUSHING, gear driven	1		
35- 7	93104-06035	OIL SEAL (S0-6-14-4)	1		
35- 8	813-17819-00	CAP, housing	1		
35- 9	98502-05010	SCREW, pan head	2		
35-10	813-83550-00	SPEEDOMETER CABLE ASS'Y	1		
35-11	811-83540-00	TACHOMETER ASS'Y	1		
35-12	102-83517-20	. BULB (12V 2W)	1		☆
35-13	811-83536-00	. SOCKET	1		
35-14	102-83514-00	. PLATE, fitting	1		
35-15	92901-05100	. WASHER, spring	2		
35-16	98801-05100	. NUT	2		
35-17	809-83513-00	DAMPER 1	1		
35-18	803-83577-00	PLATE, fitting	1		

Fig. 36 ELECTRICAL STARTER (ALTERNATE PARTS)




ELECTRICAL STARTER (ALTERNATE PARTS)

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
36- 1	807-81800-20	ELECTRIC MOTOR ASS'Y	1		
36- 2	807-81810-20	. STATOR ASS'Y	1		
36- 3	807-81320-20	. REAR BRACKET ASS'Y	1		
36- 4	807-81821-20	.. METAL, rear	1		
36- 5	807-81826-20	. BOLT (5-108)	2		
36- 6	92901-05100	. WASHER, spring	2		
36- 7	807-81811-20	. BRUSH (+)	1		
36- 8	807-81812-20	. BRUSH (-)	1		
36- 9	92901-03100	. WASHER, spring	2		
36-10	98501-03005	. SCREW, pan head	2		
36-11	807-81813-20	. SPRING, brush	2		
36-12	807-81825-20	. WASHER, insulator (10.5-22-1)...	1		
36-13	807-81824-20	. WASHER, 2 (10.2-20-0.3)	1		
36-14	807-81823-20	. WASHER 1 (10.2-20-1)	1		
36-15	807-81850-20	. ARMATURE ASS'Y	1		
36-16	807-81832-20	. CLUTCH, over run	1		
36-17	807-81833-20	. RING, stop	1		
36-18	807-81834-20	. RING	1		
36-19	807-81835-20	. WASHER (11.2-18.5-1.2)	1		
36-20	807-81830-20	. FRONT BRACKET ASS'Y	1		
36-21	807-81831-20	.. METAL, front	1		
36-22	92901-06100	. WASHER, spring	3		
36-23	807-81846-20	. SCREW 2	3		
36-24	807-81839-20	. LEVER ASS'Y	1		

ELECTRICAL STARTER (ALTERNATE PARTS)

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
36-25	807-81838-20	. HOLDER, spring	1		
36-26	807-81836-20	. SPRING, lever 1	1		
36-27	807-81837-20	. SPRING, lever 2	1		
36-28	807-81860-20	. SWITCH ASS'Y	1		
36-29	807-81862-20	. CAP	1		
36-30	806-77481-00	BOLT	2		
36-31	806-77471-00	WASHER, special	2		
36-32	92501-08020	SCREW, pan head	2		
36-33	92901-08100	WASHER, spring	2		
36-34	811-82117-00	WIRE, lead	1		
36-35	120-81970-41	RECTIFIER ASS'Y	1		
36-36	811-81891-00	GEAR, ring	1		
36-37	807-81892-00	BOLT, special	4		
36-38	807-81893-00	WASHER, special	4		
36-39	92890-06200	NUT	4		
36-40	93210-61117	O-RING (2.2-61)	1		
36-41	811-82115-00	WIRE, plus lead	1		
36-42	807-82116-00	WIRE, minus lead	1		
36-43	807-82122-01	SEAT, battery	1		
36-44	807-82136-00	PLATE, battery fitting	1		
36-45	807-82133-00	SCREW, fitting	2		
36-46	92902-06100	WASHER, spring	2		
36-47	92802-06100	NUT	4		


Fig. 36 ELECTRICAL STARTER (ALTERNATE PARTS)



ELECTRICAL STARTER (ALTERNATE PARTS)


Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
36-48	811-82127-00	WIRE, lead 2	1		
36-49	811-83970-00	STARTER SWITCH ASS'Y	1		

Fig. 37 ACCESSORY PARTS



ACCESSORY PARTS

Ref. No.	Part. No.	Description	Q'ty	Applicable Machine No.	Remarks
37- 1	802-17682-01	SPROCKET, chain drive (9T)	1		
	802-17682-10	SPROCKET, chain drive (10T)	1		
	802-17682-20	SPROCKET, chain drive (11T)	1		
	806-17682-20	SPROCKET, chain drive (12T)	1		
	806-17682-40	SPROCKET, chain drive (14T)	1		
	806-17682-50	SPROCKET, chain drive (15T)	1		
37- 2	802-47548-50	SPROCKET, chain driven (24T)	1		
	802-47548-60	SPROCKET, chain driven (23T)	1		
37- 3	94804-25064	CHAIN (DK425-2 64L)	1		
37- 4	806-24200-00	FUEL TANK ASS'Y	1		
37- 5	806-24282-00	BAND, tank fitting	1		
37- 6	807-77920-00	CAR COVER ASS'Y	1		



NUMERICAL INDEX



NUMERICAL INDEX



NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
22-12	102-82598-00	5-29	193-14486-00	19-14	802-77591-00
31- 9	102-82598-00	5-34	193-14486-00	19-11	802-77592-00
34- 2	102-83514-00	3-20	214-11545-01	9- 9	802-81325-20
35-14	102-83514-00	19- 5	214-24727-00	25- 3	802-83913-00
34- 5	102-83517-20	19- 4	214-24758-00	25- 9	802-83923-00
35-12	102-83517-20	3- 5	235-11651-00	34- 7	803-83577-00
9-15	104-81328-20	1- 9	248-11361-00	35-18	803-83577-00
9-10	110-81346-20	26-15	256-11188-00	25- 2	803-83912-00
9-13	110-81346-20	6- 6	601-24353-00	24- 4	803-83915-00
9- 6	110-81347-20	24- 4	603-24149-00	13- 5	805-17683-00
28-29	116-82131-00	3-17	604-11634-00	7- 7	806-14651-00
9-12	120-81331-20	11-14	615-42751-00	7- 6	806-14661-00
36-35	120-81970-41	8-15	619-15756-00	7- 5	806-14665-00
10- 1	126-13116-00	17-18	619-42546-00	12-14	806-17641-00
5- 1	127-14195-00	5- 2	620-14190-20	12- 8	806-17643-01
10-21	137-13128-00	13- 7	801-17688-10	12-11	806-17644-00
10- 9	137-13129-00	24-15	801-23733-00	12- 6	806-17645-00
10-16	137-13137-00	23-14	801-23855-00	12- 2	806-17647-00
10-17	137-13138-01	25- 1	801-26244-00	12-10	806-17648-00
10-10	137-13148-00	10- 2	802-13175-00	37- 1	806-17682-20
10- 4	137-13176-00	37- 1	802-17682-01	13- 9	806-17682-30
5-23	137-14134-00	37- 1	802-17682-10	37- 1	806-17682-40
1-19	137-15384-00	37- 1	802-17682-20	37- 1	806-17682-50
13-12	150-17417-00-02	13- 8	802-17685-00	21-15	806-21481-00
13-12	150-17417-00-03	13-10	802-17695-00	21-16	806-21491-01
13-12	150-17417-00-04	24-18	802-23735-00	27- 3	806-21772-00
13-12	150-17417-00-05	24-11	802-23768-00	24- 1	806-23710-00
13-12	150-17417-00-06	23- 4	802-23833-00	24- 2	806-23731-00
13-12	150-17417-00-07	23- 5	802-23834-00	24- 3	806-23738-00
34-19	150-17843-00	18- 8	802-47338-01	24-12	806-23766-00
3- 7	152-11685-00	14-16	802-47545-00	24-13	806-23779-00
23-21	156-83525-00	14-17	802-47546-01	23- 6	806-23841-00
9-16	165-81145-21	14- 8	802-47548-40	23- 7	806-23845-00
3-16	168-11633-00	37- 2	802-47548-50	23- 2	806-23875-00
3- 8	168-11681-00	37- 2	802-47548-60	26- 9	806-24135-01
23-24	168-83936-00	14- 7	802-47549-00	26-10	806-24146-00
25-14	168-83936-00	20-30	802-77217-00	26-12	806-24169-00
7-10	183-22143-00	21-22	802-77318-00	26-11	806-24176-01

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
37- 4	806-24200-00	29-14	806-77515-00	8-13	807-15751-00
37- 5	806-24282-00	29- 2	806-77523-00	8-14	807-15755-00
26-18	806-24314-00	22- 7	806-77526-00	21-12	807-21419-00
26-16	806-24335-00	22-16	806-77573-00	21-11	807-21482-00
25- 6	806-26340-00	9- 5	806-81321-20	21- 7	807-21491-00
1-21	806-24356-00	31- 0-1	806-84710-01	21- 8	807-21492-00
6- 8	806-24356-00	31- 1	806-84711-00	26-13	807-24183-00
26- 3	806-24612-00	31- 3	806-84712-00	26- 6	807-24184-00
28-26	806-24714-00	31- 2	806-84714-00	6- 1	807-24314-00
19- 9	806-27413-00	38- 8	806-84717-00	1-20	807-24461-00
19-10	806-27423-00	31- 4	806-84721-00	1-22	807-24462-09
25- 7	806-42138-00	31- 5	806-84724-00	18- 2	807-47331-00
18- 6	806-47347-00	1-16	807-11171-00	18- 4	807-47337-00
17-13	806-47363-00	3- 3	807-11432-00	20- 1	807-77111-00
17-14	806-47364-00	3- 4	807-11442-00	20-18	807-77139-00
17-21	806-47373-00	3-15	807-11601-00	20-20	807-77159-00
14-15	806-47542-00	3-15	807-11601-20	20- 5	807-77166-00
14-13	806-47543-00	9-22	807-12615-00	19- 0-1	807-77170-00
14-14	806-47558-00	2- 6	807-12623-00	19- 2	807-77172-00
20- 8	806-77145-00	2- 7	807-12624-00	20-26	807-77210-00
20- 9	806-77147-00	2- 8	807-12625-00	20-27	807-77213-00
20- 4	806-77155-00	2-11	807-12631-00	20-28	807-77214-00
20-10	806-77157-00	2-19	807-12662-00	11- 2	807-77424-00
20- 2	806-77171-00	33- 3	807-13161-02	11-13	807-77446-00
19- 3	806-77173-00	33- 2	807-13171-02	29- 1	807-77510-00
19- 8	806-77178-00	10- 5	807-13199-00	29- 7	807-77541-00
20-33	806-77178-00	7- 3	807-14613-02	29-12	807-77571-00
20-11	806-77198-00	7- 1	807-14615-01	29-13	807-77575-00
21-19	806-77314-00	7- 8	807-14616-00	19-20	807-77593-00
21-17	806-77315-01	7-12	807-14617-00	19-19	807-77595-01
10-15	806-77323-00	7- 4	807-14623-02	37- 6	807-77920-00
21-21	806-77324-00	7- 2	807-14625-01	36- 3	807-81320-20
21-23	806-77325-00	7-18	807-14718-00	36- 1	807-81800-20
28- 6	806-77352-00	7-11	807-14759-00	36- 2	807-81810-20
28- 7	806-77353-00	21- 5	807-15316-00	36- 7	807-81811-20
28- 9	806-77396-01	21- 6	807-15317-00	36- 8	807-81812-20
36-31	806-77471-00	8- 6	807-15715-00	36-11	807-81813-20
36-30	806-77481-00	8-10	807-15726-01	36- 4	807-81821-20

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
36-14	807-81823-20	28- 2	809-24744-00	17- 6	810-47517-00
36-13	807-81824-20	26-21	809-24560-01	16- 5	810-47522-00
36-12	807-81825-20	10- 7	810-13178-00	16- 4	810-47526-00
36- 5	807-81826-20	10- 8	810-13189-00	17- 4	810-47526-00
36-20	807-81830-20	4-15	810-13566-00	16- 8	810-47530-00
36-21	807-81831-20	4-13	810-14479-00	17- 7	810-47530-00
36-16	807-81832-20	12-13	810-17610-00	16- 3	810-47531-00
36-17	807-81833-20	12- 7	810-17620-01	16- 9	810-47536-00
36-18	807-81834-20	12- 1	810-17630-00	17- 8	810-47536-00
36-19	807-81835-20	12- 9	810-17642-00	16-10	810-47539-00
36-26	807-81836-20	12- 3	810-17646-00	17-10	810-47539-00
36-27	807-81837-20	12- 4	810-17658-00	14- 1	810-47541-00
36-25	807-81838-20	12- 1	810-17660-00	16-15	810-47551-00
36-24	807-81839-20	13- 2	810-17670-00	16-20	810-47552-00
36-23	807-81846-20	13- 3	810-17681-00	14-10	810-47553-00
36-15	807-81850-20	13- 6	810-17684-00	14- 9	810-47554-00
36-28	807-81860-20	13-11	810-17686-00	14-21	810-47559-00
36-29	807-81862-20	6- 3	810-24315-00	14-25	810-47561-00
36-37	807-81892-00	6- 7	810-24328-00	14- 3	810-47571-00
36-38	807-81893-00	6- 4	810-24357-00	16- 2	810-47575-00
36-42	807-82116-00	26-17	810-24357-00	16-19	810-47579-00
36-43	807-82122-01	33- 7	810-24357-00	16-18	810-47581-00
36-45	807-82133-00	6- 5	810-24360-00	9- 0-1	810-81300-20
36-44	807-82136-00	15- 1	810-25711-00	9- 1	810-81312-20
30- 2	807-84314-00	15- 2	810-25730-00	9- 2	810-81313-20
30- 9	807-84316-00	15- 4	810-25734-00	9-18	810-81332-20
30-12	807-84316-00	15- 9	810-25735-00	9-19	810-81350-20
30-13	807-84318-00	15- 3	810-25740-00	21- 9	810-15176-00
30-14	807-84319-00	15- 5	810-25744-00	1- 4	810-15491-00
30- 5	807-84331-00	15-10	810-25745-00	21- 1	810-21411-00
30- 6	807-84332-00	15- 7	810-25754-00	21-13	810-21482-00
30- 7	807-84334-00	17-11	810-47361-00	21-14	810-21492-00
20-22	807-84344-00	17-12	810-47362-00	27- 7	810-21745-00
30-10	807-84351-00	17-15	810-47367-00	27- 1	810-21751-00
34- 1	809-83510-40	17-16	810-47369-00	27- 2	810-21771-00
34- 8	809-83513-00	17-17	810-47374-00	27- 4	810-21776-00
35-17	809-83513-00	17-22	810-47378-00	24- 8	810-23763-00
34- 6	809-83536-40	16- 7	810-47517-00	24- 9	810-23764-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
24-19	810-23767-00	34-10	810-47721-10	2-18	811-12661-00
23- 8	810-23846-00	34-13	810-47723-10	2-22	811-12665-00
23-10	810-23851-00	34-12	810-47727-10	2-12	811-12651-00
23-11	810-23852-00	34-18	810-47731-10	2- 4	811-12633-00
23-12	810-23853-00	34-14	810-47741-10	10- 0-1	811-13101-00
23-13	810-23854-00	20-32	810-77136-00	4- 2	811-13555-00
23-16	810-23857-00	22- 4	810-77137-00	4-16	811-13556-00
23-18	810-23861-00	20-13	810-77153-00	4- 1	811-13557-00
23-23	810-23894-00	20-31	810-77179-00	4-10	811-13558-00
22- 3	810-23895-00	22- 5	810-77188-00	4- 3	811-13563-00
26- 7	810-24173-00	20-12	810-77199-00	4- 4	811-13565-00
26-19	810-24326-00	21-18	810-77311-00	4-11	811-13567-00
26-20	810-24327-00	22-10	810-77715-00	4-17	811-13571-00
26-27	810-24358-00	22-11	810-77716-00	5- 0-1	811-14101-00
27- 9	810-24359-00	25- 8	810-82821-00	5-30	811-14117-00
26-14	810-24514-00	22-20	810-82591-00	5-32	811-14133-00
26- 2	810-24611-00	34- 9	810-83550-00	5-37	811-14243-00
26-26	810-24644-00	25-10	810-83925-00	5-38	811-14486-00
28-10	810-24738-00	1-14	811-11111-00	5-35	811-14571-00
28-19	810-24793-00	1-15	811-11121-00	5-25	811-14582-00
28-18	810-24794-00	1-13	811-11181-00	7-13	811-14710-00
28-20	810-24796-00	1-11	811-11311-00	1- 0-1	811-15100-00
28-17	810-24797-00	1-12	811-11321-00	1- 1	811-15111-00
25-13	810-26311-00	1-10	811-11351-00	1- 2	811-15121-00
22-14	810-27411-00	3- 0-1	811-11400-00	8- 0-1	811-15710-00
22-15	810-27421-00	3- 1	811-11412-00	8- 1	811-15711-00
18- 7	810-47310-00	3- 2	811-11422-00	8- 3	811-15713-00
18- 3	810-47335-00	3-10	811-11515-00	8- 2	811-15714-00
17- 2	810-47522-00	3-14	811-11631-00-96	8- 9	811-15716-00
17- 3	810-47532-00	3-14	811-11631-00-97	8- 5	811-15719-00
17-26	810-47552-00	3-14	811-11631-00-98	8-19	811-15723-00
14-30	810-47562-00	3-14	811-11631-00-99	8- 7	811-15734-00
17-28	810-47579-00	3-14	811-11635-00	8- 4	811-15741-00
17-27	810-47581-00	3-14	811-11636-00	8-16	811-15782-00
34-16	810-47711-10	9-21	811-12611-00	22- 8	811-77711-00
34-20	810-47712-10	2- 1	811-12621-00	11- 9	811-77728-00
34-15	810-47714-10	2- 2	811-12622-00	8- 8	811-15784-00
34-17	810-47717-10	2-13	811-12652-00	19- 1	811-21910-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
24- 0-1	811-23760-00	11- 5	811-77436-00	5-12	812-24435-00
24- 5	811-23761-00	11- 3	811-77459-00	5-15	812-24451-00
24- 6	811-23762-00	11- 6	811-77461-00	5-17	812-24452-00
24- 7	811-23763-00	11-11	811-77475-00	5-18	812-24453-00
24-10	811-23769-00	11-12	811-77476-00	5-16	812-24468-00
24- 0-2	811-23770-00	11- 4	811-77478-00	5- 7	812-24471-00
23- 1	811-23811-00	22- 8	811-77711-00	35- 4	813-13175-00
23- 3	811-23821-00	11- 9	811-77728-00	35- 3	813-13176-00
22- 1	811-23871-00	22- 9	811-77746-00	35- 1	813-13199-00
26- 1	811-24111-00	36-36	811-81891-00	35- 8	813-17819-00
26- 4	811-24181-00	36-41	811-82115-00	35- 5	813-17841-00
26- 5	811-24182-00	36-34	811-82117-00	35- 6	813-17843-00
26- 8	811-24199-00	36-48	811-82127-00	33- 1	814-24360-00
6- 2	811-24312-00	35-13	811-83536-00	33- 4	814-24362-00
26-28	811-24319-00	35-11	811-83540-00	33- 6	814-24379-00
27--8	811-24319-00	35-10	811-83550-00	33- 5	814-24515-00
6- 9	811-24322-00	36-49	811-83970-00	16- 6	91102-06035
28- 1	811-24730-00	30- 0-1	811-84310-00	17- 5	91102-06035
28- 1-1	811-24731-00	20-16	811-84311-00	23-22	91106-06015
28-25	811-24790-00	30- 3	811-84312-00	22-16	91201-06012
26-22	811-24558-00	30- 4	811-84315-00	28- 8	91201-06012
26-18	811-24760-00	30- 1	811-84320-00	8-22	91201-06015
28-21	811-24798-00	30- 8	811-84338-00	19-21	91201-06015
22-13	811-26331-00	5-24	812-14123-00	34-23	91201-06015
28-28	811-28100-00	5-28	812-14125-00	19-12	91201-06040
11-15	811-42753-00	5-21	812-14147-00	21- 2	91201-10050
18- 1	811-47110-00	5- 5	812-14186-00	16-16	91202-06025
16- 1	811-47510-00	5-22	812-14235-00	11- 7	91206-06020
17- 1	811-47520-00	5- 4	812-14387-00	4- 9	91308-08030
20-19	811-77118-00	5-27	812-14594-00	24-21	91401-20025
20- 3	811-77138-00	5-26	812-14596-00	19-17	91401-25012
20- 6	811-77163-00	5-10	812-24411-00	23- 9	91401-25025
20- 7	811-77164-00	5- 8	812-24412-00	24-17	91401-30020
11-16	811-77351-00	5-11	812-24413-00	10-45	91402-12008
19-18	811-77354-00	5-14	812-24414-00	15- 6	91402-20012
28- 5	811-77391-00	5-13	812-24421-00	15-11	91402-20012
11- 1	811-77411-00	5- 3	812-24423-00	17-20	91402-30025
11-10	811-77425-00	5- 9	812-24434-00	21-24	91609-25016

